

SPORTSART 7005-19

SPORTSART Right or Left (Universal) Pedal Foot Pad 7005-19 Instruction Manual

Model: 7005-19

1. INTRODUCTION

This manual provides essential information for the proper installation, operation, and maintenance of your SPORTSART Right or Left (Universal) Pedal Foot Pad, model 7005-19. This foot pad is designed as a replacement part for specific SportsArt self-generating upright steppers. Please read this manual thoroughly before attempting any installation or use to ensure safety and optimal performance.

2. COMPATIBILITY

The SPORTSART Pedal Foot Pad 7005-19 is compatible with the following SportsArt stepper models:

- SportsArt 7003 Vertex Stepper
- SportsArt 7005 Vertex Stepper
- SportsArt 7100 Stepper DC Self Generating
- SportsArt 7100S Stepper DC Self Generating
- SportsArt S7100 Stepper Self Generating

Before purchasing or installing, always verify your equipment's model name and number to ensure compatibility. The part number for this foot pad is 7005-19.

3. SETUP AND INSTALLATION

This foot pad is a replacement component. Installation typically involves removing the old, damaged foot pad and securing the new one in its place. While specific steps may vary by stepper model, general guidelines include:

1. **Safety First:** Ensure the stepper is powered off and unplugged from any power source before beginning installation.
2. **Remove Old Foot Pad:** Carefully detach the existing foot pad. This may involve unscrewing bolts or releasing clips from the underside or top surface of the pedal arm.

3. **Position New Foot Pad:** Align the new 7005-19 foot pad with the mounting points on the stepper's pedal arm.
4. **Secure Foot Pad:** Fasten the new foot pad using the appropriate hardware (e.g., bolts, screws, or clips). Ensure it is securely attached and does not wobble.
5. **Test Stability:** Once installed, gently apply pressure to the foot pad to confirm it is firmly in place before resuming normal operation of the stepper.



Figure 1: Top view of the SPORTSART 7005-19 Universal Pedal Foot Pad. This image displays the textured surface designed for

grip and stability during exercise.



Figure 2: Bottom view of the SPORTSART 7005-19 Universal Pedal Foot Pad. This image highlights the four threaded inserts used for securing the foot pad to the stepper's pedal arm.

4. OPERATING INSTRUCTIONS

Once the foot pad is securely installed, the stepper can be operated according to its original manufacturer's

instructions. The foot pad provides a stable and comfortable surface for your feet during exercise. Ensure your feet are centered on the pad to maintain balance and prevent slippage.

5. MAINTENANCE

Regular maintenance helps prolong the life of your foot pad and ensures safe operation:

- **Cleaning:** Wipe the foot pad surface with a damp cloth to remove dust, dirt, or sweat. Avoid abrasive cleaners or solvents that could damage the material.
- **Inspection:** Periodically inspect the foot pad for any signs of wear, cracks, or damage. Check that it remains securely fastened to the stepper's pedal arm.
- **Replacement:** If the foot pad shows significant wear, becomes loose, or is damaged, replace it promptly to maintain safety and performance.

6. TROUBLESHOOTING

If you encounter issues with your stepper after installing the foot pad, or if you are unsure about diagnosing and treating your machine with the correct replacement parts, it is recommended to consult with a qualified fitness equipment technician. Professional assistance can ensure proper diagnosis and repair.

7. SPECIFICATIONS

Attribute	Detail
Part Number	7005-19
Brand Name	SPORTSART
Manufacturer	SportsArt
Item Dimensions (LxWxH)	10 x 8 x 4 inches
ASIN	B07GCS4VWH
Date First Available	August 11, 2018

8. WARRANTY AND SUPPORT

For specific warranty information regarding the SPORTSART 7005-19 Pedal Foot Pad, please refer to the original purchase documentation or contact SPORTSART directly. If you require assistance with diagnosing issues or finding a qualified fitness technician in your area, you may visit the official [SPORTSART Store on Amazon](#) or contact their customer support.