

ZdalaMit XRT122

ZdalaMit XRT122 Replacement Remote Control for Vizio Smart TVs User Manual

INTRODUCTION

This manual provides instructions for the ZdalaMit XRT122 replacement remote control, designed for various Vizio Smart TV models. This remote control is a direct replacement and requires no programming or pairing to function with compatible Vizio televisions.

SETUP

The XRT122 remote control is ready for use immediately after battery installation. No additional programming or pairing steps are required.

Battery Installation

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery cover downwards to open the compartment.
3. Insert two (2) 1.5V AAA alkaline batteries, ensuring the positive (+) and negative (-) terminals align correctly with the indicators inside the compartment.
4. Slide the battery cover back into place until it clicks securely.



Image: Back view of the XRT122 remote control, showing the battery compartment. The compartment cover is designed to slide open for battery insertion.

OPERATING INSTRUCTIONS

Once batteries are installed, the XRT122 remote control is operational. Point the remote directly at your Vizio Smart TV and press the desired function button.



Image: Front view of the XRT122 remote control, displaying all buttons including power, input, navigation, volume, channel, number pad, and dedicated app buttons.

Key Functions:

- **Power Button:** Turns the TV on or off.
- **Input Button:** Cycles through available input sources (HDMI, AV, etc.).
- **Navigation Pad (Up, Down, Left, Right, OK):** Used to navigate menus and select options.
- **Volume Up/Down:** Adjusts the television's volume.
- **Channel Up/Down:** Changes television channels.
- **Number Pad (0-9):** Direct channel entry.
- **App Buttons (e.g., Xumo, Netflix, iHeartRadio):** Provides direct access to streaming applications.
- **Menu/Guide/Info/Exit/Back:** Standard control buttons for TV functions and navigation.

MAINTENANCE

To ensure optimal performance and longevity of your remote control, follow these maintenance guidelines:

- **Cleaning:** Wipe the remote control with a soft, dry cloth. Avoid using liquid cleaners or abrasive materials, as they may damage the surface or internal components.

- **Battery Replacement:** Replace batteries when the remote's response becomes sluggish or stops functioning. Always replace both batteries simultaneously with new AAA alkaline batteries.
- **Storage:** Store the remote in a dry place away from direct sunlight, extreme temperatures, and high humidity.
- **Avoid Drops:** Protect the remote from physical impact, as drops can damage internal circuitry.

TROUBLESHOOTING

If you experience issues with your XRT122 remote control, refer to the following common solutions:

- **Remote Not Responding:**
 - Check if the batteries are inserted correctly with the correct polarity.
 - Replace old batteries with new 1.5V AAA alkaline batteries.
 - Ensure there is a clear line of sight between the remote control and the TV's infrared sensor. Remove any obstructions.
 - Confirm the remote is pointed directly at the TV.
- **Intermittent Functionality:**
 - Weak batteries can cause intermittent operation. Replace them.
 - Ensure no strong light sources (like direct sunlight or bright fluorescent lights) are interfering with the remote's signal.

SPECIFICATIONS

Model Number	XRT122
Brand	ZdalaMit
Compatible Devices	Vizio Smart Televisions
Power Supply	2 x 1.5V AAA Alkaline Batteries (not included)
Special Feature	Pre-programmed (no setup required)
Color	Black
Product Dimensions	6 x 2 x 0.65 inches
Item Weight	0.01 ounces

Compatible Vizio TV Models:

D50-E1, D65-E0, D43-E2, D55-E0, D39H-D0, E43-C2, E55-C2, E65-C3, E70-C3, E40-C2, E65X-C2, E32-C1, E48-C2, E32H-C1, D58U-D3, and other similar Vizio Smart TV models.

SUPPORT

For any questions or assistance regarding your ZdalaMit XRT122 replacement remote control, please contact the seller or manufacturer directly. Refer to your purchase documentation for specific contact information.

