

## BOBLOV PD5064

# BOBLOV Body Mounted Camera Instruction Manual

Model: PD5064 | Brand: BOBLOV

## INTRODUCTION

This manual provides comprehensive instructions for the setup, operation, and maintenance of your BOBLOV Body Mounted Camera. Please read this manual thoroughly before using the device to ensure proper functionality and to maximize its performance and lifespan.

## PACKAGE CONTENTS

Verify that all items listed below are included in your package:



Figure 1: Included Accessories

- BOBLOV Body Mounted Camera (Main Unit)
- Shoulder Clip
- Belt Clip
- Charger
- Data Cable (USB)
- User Manual

## PRODUCT FEATURES

### High Definition Video Recording



Figure 2: 1296P HD Resolution

The camera records video at a maximum resolution of 1296P (1728x1296) at 30 frames per second, ensuring clear and detailed footage. Lower resolutions like 1080P, 720P, and 480P are also available to optimize storage space.

### Wide Angle Lens




Figure 3: 150 Degree Wide Angle Lens

Equipped with a 150-degree wide-angle lens (F1.8 aperture), the camera captures a broad field of view, minimizing blind spots and ensuring comprehensive coverage of your surroundings.

## Night Vision Capabilities



Figure 4: Night Vision IR LED Lights

Integrated IR LED lights enable clear recording in low-light or complete darkness. The night vision mode can be manually activated for optimal visibility.

## Compact and Lightweight Design




Figure 5: Compact Size & Lightweight

Weighing only 7 ounces (115g) and with compact dimensions, the camera is designed for comfortable and discreet body-worn use.

## Smart Fast Charging



Figure 6: Smart Fast Charging

The device supports smart fast charging, allowing for a full charge in approximately one hour, providing up to 7 hours of continuous recording time.

## Plug and Play Connectivity




Figure 7: Plug and Play with USB Cable

Easily transfer files to your computer (Windows 7/8/10/Mac compatible) using the included USB cable without

requiring additional software installation.

## Product Structure and Controls



Figure 8: Product Structure and Controls

Familiarize yourself with the camera's layout and button functions as detailed in the diagram above for efficient operation.

## SETUP

- Charging:** Before first use, fully charge the camera using the provided charger and USB cable. The charging indicator will show charging status.
- Memory Card:** The camera uses an SD card (not included) for storage. Insert a compatible SD card into the designated slot. Ensure it is properly formatted via the camera's menu for optimal performance.
- Mounting:** Attach the camera to your clothing or gear using the included shoulder clip or belt clip. Ensure the camera lens has an unobstructed view.

## OPERATING INSTRUCTIONS

- Power On/Off:** Press and hold the Power Switch button until the screen turns on/off.
- Video Recording:** Press the Video Recording button to start recording. Press it again to stop. A red indicator light typically signifies active recording.
- Photo Shooting:** Press the Photo Shooting button to capture still images.
- Audio Recording:** Press the Audio Recording button to start recording audio only. Press again to stop.
- Night Vision Activation:** In low light conditions, manually activate the IR LED lights using the dedicated button for night vision recording.
- Playback:** Use the navigation buttons and LCD screen to browse and play back recorded videos and photos.
- Menu Navigation:** Access settings and options via the Menu button. Use the Up/Down buttons to navigate and OK to confirm selections.

## MAINTENANCE

- Keep the camera clean by wiping it with a soft, dry cloth.
- Avoid exposing the camera to extreme temperatures or direct sunlight for prolonged periods.
- Ensure the USB port cover is securely closed to protect against dust and moisture.
- Store the camera in a cool, dry place when not in use.

## TROUBLESHOOTING

- **Camera not turning on:** Ensure the battery is charged. If fully charged, try resetting the device (refer to Product Structure diagram for reset button location).
- **Poor video quality:** Check the selected resolution in the settings. Ensure the lens is clean and free from smudges.
- **Night vision not working:** Confirm that the IR LED lights are manually activated in dark environments.
- **Files not transferring:** Ensure the USB cable is securely connected to both the camera and the computer. Try a different USB port or cable.

## SPECIFICATIONS

Feature	Specification
Brand	BOBLOV
Model Number	PD5064
Video Capture Resolution	1296p
Lens Type	Wide Angle (150 Degree)
Maximum Aperture	1.8 f
Flash Memory Type	SD
Screen Size	2 Inches
Special Features	Waterproof, Infrared, Night Vision, Low Light
Item Weight	7 ounces
Product Dimensions	3.94 x 0.79 x 2.36 inches

## WARRANTY & SUPPORT

Your BOBLOV Body Mounted Camera comes with a **One Year Warranty** from the date of purchase. Please retain your proof of purchase for warranty claims.

For technical support, troubleshooting assistance, or warranty inquiries, please visit the official BOBLOV store on Amazon or contact their customer service directly. Official product videos from the seller were not available in the provided data.

