

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [LP](#) /

> [LP LP-E8 Battery Charger Instruction Manual for Canon EOS Rebel Cameras](#)

LP LP-E8 Charger (Model 996790)

LP LP-E8 Battery Charger Instruction Manual

Model: 996790

Brand: LP

INTRODUCTION

This manual provides instructions for the safe and efficient use of your LP LP-E8 Battery Charger. This charger is designed to provide reliable power for your compatible camera batteries.

Compatibility

The LP LP-E8 Battery Charger is compatible with Canon EOS Rebel cameras that use LP-E8 batteries. This includes models such as:

- Canon EOS Rebel T2i
- Canon EOS Rebel T3i
- Canon EOS Rebel T4i
- Canon EOS Rebel T5i
- Canon EOS 550D
- Canon EOS 600D
- Canon EOS 650D
- Canon EOS 700D
- Canon EOS Kiss X4
- Canon EOS Kiss X5
- Canon EOS Kiss X6i
- Canon EOS Kiss X7i

Note: This charger is not compatible with Canon EOS Rebel T2, T3, T4, or T5 models.

COMPATIBILITY LIST

Works with these popular Canon camera models that use LP-E8 batteries



Canon EOS Rebel T2i, T3i, T4i, T5i, 550D, 600D, 650D, 700D, Kiss X4, X5, X6i, X7i DSLR Cameras and More

Image: LP LP-E8 Battery Charger showing compatibility with various Canon EOS Rebel camera models.

SAFETY INFORMATION

To ensure safe operation and prevent damage, please observe the following safety precautions:

- **Overcharge Protection:** The charger is equipped with circuitry to prevent overcharging of batteries.
- **Short Circuit Protection:** Built-in protection against short circuits ensures safe operation.
- **High Temperature Protection:** The charger includes features to prevent overheating during the charging process.
- **Surge Protection:** Designed to protect against power surges.
- Do not disassemble the charger. Refer to qualified service personnel for repairs.
- Use in dry locations only. Avoid exposure to moisture or water.
- Keep out of reach of children.

PRODUCT FEATURES

- **Standard Compatibility:** Meets or exceeds OEM Canon LP-E8 Battery Charger specifications.
- **Worldwide Use:** Supports AC100-240V input, allowing use in various countries.
- **Portable Design:** Constructed from durable ABS material, lightweight and compact for easy transport.

- **LED Indicator:** Provides clear charging status (Red for charging, Green for fully charged).

PRODUCT DETAILS



Image: Exploded view illustrating the internal components and design of the LP LP-E8 Battery Charger.



Image: The compact LP LP-E8 Battery Charger shown being held, emphasizing its portability.

SETUP AND OPERATING INSTRUCTIONS

Inserting the Battery

1. Ensure the charger is unplugged from the power outlet.
2. Align the LP-E8 battery with the charging slot on the charger. The "PUSH" indicator on the charger shows the direction for insertion.
3. Gently push the battery into the slot until it clicks securely into place.



Image: Demonstrating the correct way to insert an LP-E8 battery into the charger.

Charging Process

1. Once the battery is securely inserted, unfold the integrated plug on the charger.
2. Plug the charger directly into a standard AC wall outlet (AC100-240V).
3. The LED indicator on the charger will illuminate **Red** to indicate that the battery is currently charging.
4. When the battery is fully charged, the LED indicator will change to **Green**.
5. Once charging is complete, unplug the charger from the wall outlet and remove the battery by gently pressing

the "PUSH" tab and sliding the battery out.




Image: Step-by-step guide on inserting the battery and plugging in the charger.

LED DISPLAY

Check if the charger is working by whether the LED lights up red

- Red Light: Charging
- Green Light: Fully Charged



Image: LED indicator status: Red for charging, Green for fully charged.



Image: The LP LP-E8 Battery Charger in use, charging a battery while a Canon camera is nearby.

Your browser does not support the video tag.

Video: Official LP LED AC Charger demonstration, showing the charging process and LED indicators.

MAINTENANCE AND CARE

To ensure the longevity and optimal performance of your LP LP-E8 Battery Charger, follow these maintenance guidelines:

- Keep the charger clean and free from dust and debris. Use a soft, dry cloth for cleaning.
- Store the charger in a cool, dry place when not in use.
- Avoid dropping the charger or subjecting it to strong impacts.
- Do not expose the charger to extreme temperatures or direct sunlight for prolonged periods.

TROUBLESHOOTING

Charger Not Working / LED Not Lighting Up

- Ensure the charger is securely plugged into a functional wall outlet.
- Verify that the battery is correctly inserted into the charging slot.
- Check if the battery itself is damaged or incompatible.

Battery Not Charging Fully

- Confirm that the LED indicator turns green when charging is complete.
- If the battery consistently fails to charge fully, it may be nearing the end of its lifespan and require replacement.
- Ensure the charger is not exposed to extreme temperatures during charging, which can affect performance.

SPECIFICATIONS

| | |
|--------------------------|--------------------------------|
| Model | LP-E8 (Model 996790) |
| Input | AC100-240V, 50/60Hz, MAX 150mA |
| Output | DC8.4V 600mA |
| Product Dimensions | 1.87 x 1.35 x 3.34 inches |
| Item Weight | 2.39 ounces |
| Battery Cell Composition | Lithium Ion |
| Manufacturer | LP |



Image: Product dimensions of the LP LP-E8 Battery Charger.

WARRANTY AND SUPPORT

LP provides the following support for this product:

- **30-Day Refund:** Eligible for a refund within 30 days of purchase.

- **1-Year After-Sales Service:** Comprehensive support for one year after purchase.
- **Lifetime Service:** Ongoing support for the product's lifespan.
- **Customer Response:** Expect a quick and friendly response within 24 hours on working days for any inquiries or issues.