

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [CHAUVET DJ](#) /

› [CHAUVET DJ Intimidator Spot 110 Lighting Fixture User Manual](#)

CHAUVET DJ Intimidator Spot 110

CHAUVET DJ Intimidator Spot 110 Lighting Fixture User Manual

Model: Intimidator Spot 110 | Brand: CHAUVET DJ

1. INTRODUCTION

The CHAUVET DJ Intimidator Spot 110 is a compact and lightweight LED moving head designed for mobile applications. It features separate color and gobo wheels for versatile programming, sound-activated programs for dynamic light shows, and built-in automated programs for synchronized operation in Master/Slave mode.

2. WHAT'S IN THE BOX

- Intimidator Spot 110 Lighting Fixture
- Power Cord
- Mounting Bracket with Hardware
- Quick Reference Guide

3. SETUP

Before operating the Intimidator Spot 110, ensure it is securely mounted and all connections are properly made.

3.1 Mounting

The fixture can be mounted to a truss or placed on a flat surface. Use the included mounting bracket and hardware to secure the fixture. Ensure the mounting surface or truss can support the weight of the fixture.



Image: The Intimidator Spot 110 shown with its mounting bracket, illustrating how it can be attached for installation.

3.2 Power Connection

Connect the provided power cord to the power input on the rear of the fixture and then to a suitable power outlet (100-240VAC, 50/60Hz).



Image: Rear view of the Intimidator Spot 110, highlighting the power input and DMX In/Out ports for connection.

3.3 DMX Connection (Optional)

For advanced control, connect a DMX controller to the DMX IN port using a 3-pin DMX cable. For multiple fixtures, daisy-chain them by connecting the DMX OUT of one fixture to the DMX IN of the next.

4. OPERATING INSTRUCTIONS

The Intimidator Spot 110 offers various operating modes, including automated programs, sound-activated mode, and DMX control.

4.1 Control Panel

The control panel on the base of the fixture features a digital display and four buttons: **MENU**, **UP**, **DOWN**, and **ENTER**. These buttons are used to navigate through the menu options and select settings.



Image: Front view of the Intimidator Spot 110, highlighting the digital display and control buttons on its base.

4.2 Automated Programs

The fixture includes built-in automated programs that can be selected via the control panel. These programs offer various light sequences and movements without external control. To activate, navigate to the "Auto" mode using the MENU button and press ENTER.

4.3 Sound-Activated Mode

In sound-activated mode, the fixture's movements and light patterns respond to the beat of the music. To enable this mode, navigate to the "Sound" mode using the MENU button and press ENTER. The integrated microphone detects audio cues.

4.4 Master/Slave Mode

For a synchronized light show with multiple Intimidator Spot 110 fixtures, configure them in Master/Slave mode. One fixture acts as the master, controlling the others (slaves) via DMX cabling. Refer to the detailed manual for specific Master/Slave configuration steps.

4.5 Gobo and Color Wheels

The fixture features separate gobo and color wheels, allowing for creative lighting effects. Gobos project various shapes, while the color wheel provides a range of vibrant colors. These can be controlled via DMX or through some automated programs.



Image: The Intimidator Spot 110 projecting a blue light with a distinct gobo pattern onto a surface.




Image: Several Intimidator Spot 110 fixtures arranged in a circular truss, casting dynamic blue light beams and patterns.




Image: Several Intimidator Spot 110 fixtures arranged in a circular truss, casting dynamic red light beams and patterns.

5. MAINTENANCE

Regular maintenance ensures optimal performance and longevity of your Intimidator Spot 110.

5.1 Cleaning

Periodically clean the exterior of the fixture with a soft, dry cloth. Ensure the lens is free of dust and smudges to maintain light output clarity. Do not use harsh chemicals or abrasive materials.

5.2 Fan Vents

Keep the fan vents clear of obstructions to prevent overheating. Dust accumulation can impair cooling efficiency.

6. TROUBLESHOOTING

If you encounter issues with your Intimidator Spot 110, refer to the following common troubleshooting steps:

- **No Power:** Check the power cord connection and ensure the power outlet is functional.
- **No Light Output:** Verify the fixture is in an active mode (e.g., Auto, Sound, DMX). Check for any error messages on the display.
- **No Movement/Incorrect Movement:** Ensure the fixture is not in a static mode. If using DMX, verify DMX address and signal.
- **Overheating:** Check that fan vents are clear and the fixture has adequate ventilation.

7. SPECIFICATIONS

Feature	Detail
Model Number	Intimidator Spot 110
Dimensions	7.5"L x 5"W x 11"H
Item Weight	1 Pounds
Color	Black
Material	Plastic
Light Source Type	Light Emitting Diode
Brightness	1561 lux
Beam Angle	13 Degrees
Power Source	Corded Electric
Bulb Features	Sound-activated
Mounting Type	Table Mount
GTIN / UPC	781462218423

8. OFFICIAL PRODUCT VIDEOS

The following videos provide additional information and demonstrations of the CHAUVET DJ Intimidator Spot 110.

CHAUVET DJ Intimidator Spot 110 Professional LED Music Party

Your browser does not support the video tag.

Video: A demonstration of the CHAUVET DJ Intimidator Spot 110 in action, showcasing its various light patterns, colors, and movements in a professional setting.

9. WARRANTY AND SUPPORT

The CHAUVET DJ Intimidator Spot 110 is covered by the manufacturer's warranty. For detailed warranty information, technical support, or service inquiries, please visit the official CHAUVET DJ website or contact their customer service department. Keep your proof of purchase for warranty claims.

Visit the [CHAUVET DJ Store](#) for more products and information.

