Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Vitamix VM0195D

Vitamix VM0195D A2300i ASCENT Series Blender User Manual

Model: VM0195D | Brand: Vitamix

Introduction

This manual provides essential information for the safe and efficient operation of your Vitamix VM0195D A2300i ASCENT Series Blender. The A2300i model from the Vitamix® ASCENT range features an integrated digital timer, advanced SELF-DETECT technology, and is compatible with practical containers of various sizes, making it ideal for blending and on-the-go use. Please read all instructions carefully before using the appliance.





Figure 1: Front view of the Vitamix A2300i Ascent Series Blender, showcasing its sleek design and control panel.

Important Safeguards

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons.

- Read all instructions before operating the blender.
- Do not immerse the motor base in water or other liquids.
- Unplug from outlet when not in use, before assembling or disassembling parts, and before cleaning.
- Avoid contact with moving parts. Blades are sharp.
- Always operate the blender with the lid and lid plug securely in place.
- Do not use attachments not recommended or sold by Vitamix.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been dropped or damaged in any manner.

Setup

1. **Unpacking:** Carefully remove all components from the packaging. Retain packaging for future storage or shipping.

2. **Placement:** Place the motor base on a dry, level, and stable surface. Ensure adequate ventilation around the unit.
3. **Container Placement:** Place the container onto the motor base. The A2300i features SELF-DETECT technology, which automatically recognizes the container size and adjusts program settings accordingly. Ensure the container is seated firmly.
4. **Lid and Lid Plug:** Securely place the lid onto the container. Insert the lid plug into the opening in the lid. The system includes a lid interlock for safety.
5. **Power Connection:** Plug the power cord into a grounded electrical outlet.





Figure 2: Side view of the Vitamix A2300i, showing the container securely placed on the motor base.

Operating Instructions

Controls Overview:

- **Variable Speed Control:** Use the dial to select speeds from 1 to 10. Start at a lower speed and gradually increase for optimal blending.
- **Pulse Function:** The pulse switch provides short bursts of power for chopping ingredients or refining textures.
- **Digital Timer:** The integrated digital timer displays the blend time, allowing for precise control and consistent results.

Blending Process:

1. **Add Ingredients:** Place ingredients into the container. For best results, add liquids first, then soft ingredients, followed by hard ingredients, and finally ice or frozen items.
2. **Secure Lid:** Ensure the lid and lid plug are securely in place.
3. **Start Blending:** Turn the variable speed dial to the desired setting (start low, then increase). For tough ingredients, use the pulse function initially.
4. **Using the Tamper:** If ingredients get stuck or an air pocket forms, remove the lid plug and insert the tamper through the opening. Use the tamper to push ingredients towards the blades. **Never use utensils or your hands inside the container while the machine is running.**
5. **Finish Blending:** Once desired consistency is achieved, turn the speed dial to off and wait for the blades to stop before removing the lid.



Figure 3: The Vitamix A2300i blender in operation, preparing a beverage in a modern kitchen environment.

Cleaning and Maintenance

Self-Cleaning Method:

1. Fill the container halfway with warm water.
2. Add a few drops of dish soap.
3. Secure the lid and lid plug.
4. Start the machine on Variable Speed 1, then slowly increase to Variable Speed 10. Run for 30-60 seconds.
5. Rinse the container thoroughly with clean water.

Manual Cleaning:

- Unplug the blender before cleaning.
- Wash the container, lid, and lid plug with warm, soapy water. Use a soft brush for hard-to-reach areas.
- Wipe the motor base with a damp cloth. Do not immerse the motor base in water.
- Dry all parts thoroughly before reassembling or storing.



Figure 4: Close-up view of the Vitamix A2300i container, highlighting its robust design and clear measurement markings.

Troubleshooting

Problem	Possible Cause	Solution
Blender does not turn on.	Not plugged in; power switch off; container not seated correctly; lid not secured; motor overload.	Ensure plug is firmly in outlet. Turn power switch on. Re-seat container. Secure lid and lid plug. Allow motor to cool for 20-45 minutes if overloaded.

Problem	Possible Cause	Solution
Ingredients not blending smoothly.	Too little liquid; ingredients too large; air pocket around blades.	Add more liquid. Cut ingredients into smaller pieces. Use the tamper to push ingredients towards the blades. Increase speed.
Burning smell from motor.	Overloading the machine; prolonged blending of thick mixtures.	Reduce load. Add more liquid. Allow motor to cool down. This is normal for new blenders during initial use.

Specifications

Brand: Vitamix

Model Number: VM0195D

Color: Black

Dimensions (L x W x H): 27.94 x 20.32 x 43.18 cm (11 x 8 x 17 inches)

Weight: 8.06 Kilograms (17.77 lbs)

Power: 1200 Watts

Voltage: 220.00 Volts

Included Components: Blender base, 2-liter container with lid and lid plug, tamper.

Recommended Uses: Blending, mixing, chopping, pureeing.

Features: SELF-DETECT Technology, Variable Speed Control, Pulse Function, Digital Timer, Lid Interlock System.

Warranty and Support

The Vitamix VM0195D A2300i ASCENT Series Blender comes with a comprehensive**10-year warranty** covering parts, performance, and labor. This warranty ensures your peace of mind and reflects the high quality and durability of your Vitamix appliance.

For warranty claims, technical support, or any questions regarding your product, please visit the official Vitamix website or contact their customer service department. Keep your purchase receipt as proof of purchase.

Online Support: Visit Vitamix Support for FAQs, troubleshooting guides, and contact information.

© 2024 Vitamix. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for

conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07GDP13TR

More documents and user manuals: **https://manuals.plus/**