

## Morphy Richards 403010

# Morphy Richards 403010 Inspire Blender Instruction Manual

## 1. INTRODUCTION

Thank you for choosing the Morphy Richards 403010 Inspire Blender. This appliance is designed to assist you in preparing a variety of delicious and healthy recipes, from smoothies and milkshakes to soups and sauces. With its powerful motor, durable glass jug, and ice-crushing blades, this blender offers versatility and ease of use. Please read this manual thoroughly before first use to ensure safe and efficient operation.

## 2. IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons.

- Read all instructions before operating the blender.
- Ensure the voltage indicated on the appliance corresponds with your mains voltage before connecting.
- Always unplug the appliance from the power outlet before assembling, disassembling, or cleaning.
- Do not immerse the motor base, cord, or plug in water or any other liquid.
- Keep hands and utensils out of the jug while blending to prevent severe injury and damage to the blender. Use a scraper only when the blender is not running.
- Blades are sharp. Handle with extreme care when assembling, disassembling, or cleaning.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been dropped or damaged in any manner.
- Close supervision is necessary when any appliance is used by or near children.
- Do not use the blender for purposes other than its intended use.
- For each use, the consecutive operating time should not exceed 1 minute. A resting time of at least 10 minutes must be maintained between two consecutive cycles (2 x 1 minute) to cool down to room temperature before performing the next operating cycle.
- Do not blend hot liquids in the blender as this may cause pressure build-up and result in scalding.

### 3. PRODUCT OVERVIEW

---

The Morphy Richards 403010 Inspire Blender consists of a robust motor base, a durable 1.5-liter glass jug, a blade assembly, and a lid. The control dial on the front allows for easy selection of speed settings and the pulse function.



Image: Front view of the Morphy Richards 403010 Inspire Blender, showcasing the motor base, glass jug, and lid.



Image: The Morphy Richards 403010 Inspire Blender with icons highlighting its key features: 600W motor, 1.5L glass jug, safety lock system, ice crushing capability, 5 speed settings and pulse, removable stainless steel blades, and versatile use.

## 4. SETUP

1. **Unpack:** Carefully remove all packaging materials and dispose of them responsibly.
2. **Clean Before First Use:** Wash the glass jug, lid, and blade assembly in warm, soapy water. Rinse thoroughly and dry. The motor base should only be wiped with a damp cloth.
3. **Assemble the Jug:** Ensure the blade assembly is securely fitted into the bottom of the glass jug.
4. **Place on Motor Base:** Place the assembled glass jug onto the motor base. Ensure it is correctly seated and locked into position. The blender will not operate if the jug is not properly secured.
5. **Connect Power:** Plug the power cord into a suitable electrical outlet.

## 5. OPERATING INSTRUCTIONS

The Morphy Richards 403010 Inspire Blender features 5 speed settings and a pulse function for precise control over your blending tasks.

1. **Add Ingredients:** Place your desired ingredients into the glass jug. For best results, add liquids first, followed by soft ingredients, and then harder items or ice. Do not exceed the maximum fill line indicated on the jug.
2. **Secure Lid:** Place the lid firmly onto the glass jug. Ensure the filler cap is also in place.
3. **Select Speed:** Turn the control dial to your desired speed setting (1-5). Start with a lower speed and gradually increase if needed.
4. **Use Pulse Function:** For short bursts of power, such as crushing ice or chopping ingredients, turn the dial to the 'P' (Pulse) setting and hold it. Release to stop.
5. **Blending Time:** Do not operate the blender continuously for more than 1 minute. Allow a 10-minute rest period between consecutive 1-minute blending cycles to prevent overheating.
6. **Stop Blending:** Once blending is complete, turn the control dial to the '0' (Off) position and unplug the appliance.



Image: The Morphy Richards blender jug filled with fresh strawberries, blueberries, banana slices, and ice cubes, ready for blending.



1.5L Glass  
Jug



Image: A green smoothie being poured from the 1.5L glass jug of the Morphy Richards blender into a tall drinking glass.

## 6. CLEANING AND MAINTENANCE

Regular cleaning ensures the longevity and hygiene of your blender.

1. **Unplug:** Always unplug the blender from the power outlet before cleaning.
2. **Disassemble:** Remove the glass jug from the motor base. Carefully detach the blade assembly from the bottom of the jug. Remove the lid.
3. **Wash Components:** Wash the glass jug, lid, and blade assembly in warm, soapy water. The glass jug is easy to clean. Exercise extreme caution when handling the sharp blades. Rinse thoroughly and dry immediately.
4. **Clean Motor Base:** Wipe the motor base with a damp cloth. Do not immerse the motor base in water or any other liquid.
5. **Stubborn Stains:** For stubborn stains in the jug, fill it with warm water and a drop of dish soap, then run the blender on a low speed for a few seconds. Rinse thoroughly.
6. **Storage:** Store the clean and dry blender in a safe place, out of reach of children.

## 7. TROUBLESHOOTING

If you encounter issues with your blender, refer to the following common problems and solutions:

- **Blender does not turn on:**

- Ensure the power cord is securely plugged into a working outlet.
- Check that the glass jug is correctly seated and locked onto the motor base. The blender has a safety interlock system.

- **Ingredients are not blending smoothly:**

- Add more liquid to the mixture.
- Reduce the amount of ingredients in the jug to avoid overloading.
- Use the pulse function to break down larger pieces before continuous blending.

- **Motor stops during operation or smells burnt:**

- The blender may be overloaded or has been running for too long.
- Turn off the blender, unplug it, and allow it to cool down for at least 10-15 minutes before attempting to use it again.
- Reduce the load and ensure you adhere to the 1-minute continuous operation limit.

## 8. SPECIFICATIONS

Feature	Specification
Model Number	403010
Power	600 Watts
Capacity	1.5 Litres
Material	Glass (Jug)
Speed Settings	5 Speeds + Pulse
Special Features	Ice Crushing Blades
Dimensions (L x W x H)	16 x 16 x 39 cm
Weight	3.4 Kilograms
Voltage	240V

## 9. WARRANTY AND SUPPORT

Your Morphy Richards 403010 Inspire Blender comes with a **one-year manufacturer's warranty**. Additionally, you can receive an **extended 2-year warranty** upon product registration. Please refer to the warranty card included in your product packaging for details on how to register your appliance.

For technical support, spare parts, or warranty claims, please contact Morphy Richards customer service. Contact details can typically be found on the official Morphy Richards website or on your product packaging.

© 2024 Morphy Richards. All rights reserved.