

[Manuals.plus](#) /

> [PHILIPS](#) /

> Philips PowerPro Expert Bagless, Deep Black FC9732/61: 2100W, 420w suction power, PowerCyclone 8, 2l Dust capacity, Allergy Filter, TriActive+ nozzle, Crevice tool, Active Lock, 2 years warranty

## PHILIPS FC9732

# Philips PowerPro Expert Bagless Vacuum Cleaner Instruction Manual

Model: FC9732/61

## 1. SETUP AND ASSEMBLY

Before first use, ensure all components are correctly assembled. The Philips PowerPro Expert is designed for easy and secure setup.

### Unpacking and Initial Inspection

- Carefully remove all parts from the packaging.
- Check for any damage during transit. Do not use if any parts are damaged.
- Ensure all listed components are present.

### Assembling the Vacuum Cleaner

1. **Attach the Hose:** Insert the flexible hose into the air inlet opening on the main unit until it clicks securely into place.
2. **Connect the Tube:** Connect the telescopic tube to the hose handle. Ensure the Active Lock mechanism engages for a firm connection.
3. **Attach the Nozzle:** Connect the TriActive+ nozzle or other desired accessory to the telescopic tube.
4. **Accessory Storage:** The integrated brush and crevice tool can be conveniently stored onboard the vacuum cleaner for easy access during cleaning.



Figure 1: Fully assembled Philips PowerPro Expert vacuum cleaner. This image shows the main unit, flexible hose, telescopic tube, and TriActive+ nozzle, ready for operation.



Figure 2: Demonstrates the convenient onboard storage for accessories like the crevice tool. The image highlights how the tool fits neatly into a dedicated compartment on the vacuum's body.

## 2. OPERATING INSTRUCTIONS

The Philips PowerPro Expert is designed for efficient and powerful cleaning on various surfaces.

### Powering On and Suction Control

- Plug the power cord into a suitable electrical outlet (220 Volts).
- Press the On/Off button located on the main unit to start the vacuum cleaner.
- Adjust the suction power using the control dial or slider on the main unit or hose handle, as appropriate for the surface being cleaned. Lower settings are suitable for delicate surfaces or when less noise is desired.

### Using the TriActive+ Nozzle

The TriActive+ nozzle offers a 3-way cleaning action for optimal performance:

- It gently opens carpet pile to remove deeply embedded dust.
- Large front opening for picking up larger crumbs.
- Side brushes effectively clean along furniture and walls.

### PowerCyclone 8 Technology

This vacuum cleaner features PowerCyclone 8 technology, which rapidly accelerates air in the cyclonic chamber to separate dust from the air. This powerful swirling action maximizes airflow and maintains strong suction power for remarkable cleaning results.

### Allergy Lock System

The Allergy Lock system incorporates a sensor that ensures the dust container is fully sealed and leak-proof before

the appliance operates, preventing dust escape.



Figure 3: An alternative view of the Philips PowerPro Expert, showcasing the transparent dust container and the overall design. This angle emphasizes the compact and functional form of the vacuum.

### 3. MAINTENANCE

Regular maintenance ensures optimal performance and extends the lifespan of your Philips PowerPro Expert vacuum cleaner.

#### Emptying the Dust Container

- The dust container should be emptied when the dust level reaches the MAX indication.
- To empty, detach the dust container from the main unit by pressing the release button.
- Open the dust container lid and dispose of the collected dust into a waste bin. The unique shape and smooth surface of the container help control dust during emptying.
- Close the lid and reattach the dust container to the vacuum cleaner.

## Cleaning the Dust Container and Filters

- The dust container can be rinsed with water for thorough cleaning. Ensure it is completely dry before reassembling.
- The vacuum cleaner is equipped with an Allergy H13 filter system, which captures over 99.9% of fine dust particles.
- Regularly check and clean the filters according to the instructions in the full user manual. Filter replacement (e.g., FC6042/01) may be necessary periodically to maintain filtration efficiency.
- The fully-sealed filtration system ensures high hygiene levels, especially beneficial for allergy sufferers.

## 4. TROUBLESHOOTING

This section addresses common issues you might encounter with your vacuum cleaner.

### Reduced Suction Power

- **Check Dust Container:** Ensure the dust container is not full and is properly attached and sealed. Empty if necessary.
- **Inspect Filters:** Clogged filters can significantly reduce suction. Clean or replace the Allergy H13 filter as per maintenance instructions.
- **Clear Blockages:** Check the hose, telescopic tube, and nozzle for any blockages. Remove any debris obstructing the airflow.

### Unusual Noise

- **Check for Obstructions:** Ensure there are no foreign objects caught in the brush roll or air pathways.
- **Filter Check:** A dirty or improperly installed filter can cause unusual motor sounds.

### Vacuum Cleaner Not Starting

- **Power Connection:** Verify that the power cord is securely plugged into a working electrical outlet.
- **Power Outlet:** Test the outlet with another appliance to ensure it is functional.
- **Allergy Lock System:** Ensure the dust container is correctly installed and the Allergy Lock system has engaged, as the vacuum will not operate if it detects an improper seal.

## 5. SPECIFICATIONS

Detailed technical specifications for the Philips PowerPro Expert Bagless Vacuum Cleaner FC9732/61.

Feature	Specification
Brand	PHILIPS
Model Number	FC9732
Color	Deep Black

Feature	Specification
Power	2100W
Suction Power	420W
Dust Capacity	2 Liters
Filter Type	Allergy H13 (HEPA equivalent)
Noise Level	84 dB
Product Dimensions	50.5 x 29.2 x 29.2 cm
Item Weight	7.7 Kilograms
Voltage	220 Volts
Material	Metal
Special Features	Bagless, cyclonic, pet_hair
Included Components	Crevice Tool, Integrated brush, Small nozzle, TriActive+ nozzle

## 6. WARRANTY AND SUPPORT

Your Philips PowerPro Expert vacuum cleaner comes with comprehensive warranty coverage and dedicated support.

### Warranty Information

This product is covered by a **2-year brand warranty** from the date of purchase. This warranty covers manufacturing defects and ensures reliable operation under normal household use. Please retain your proof of purchase for warranty claims.

### Customer Support

For technical assistance, troubleshooting beyond this manual, or warranty service, please contact Philips customer support. You can find contact details on the official Philips website or through the retailer where the product was purchased.

When contacting support, please have your product model number (FC9732) and serial number (if applicable) ready.