

Furinno 18041GYW

Furinno Beginning TV Stand Instruction Manual

MODEL: 18041GYW

Brand: Furinno

1. PRODUCT OVERVIEW

The Furinno Beginning TV Stand is designed for simplicity and functionality, suitable for various home styles. This stand accommodates TVs up to 37 inches and features a bottom shelf for media accessories or storage. Constructed from engineered wood, it offers durability and strength for your entertainment setup.

Key Features:

- Ample storage space with a bottom shelf.
- Designed for easy assembly.
- Weight capacity: 30 lbs (top shelf), 20 lbs (bottom shelf).
- Product Dimensions: 35.43" (W) x 21.69" (H) x 15.67" (D).



Image 1.1: The Furinno Beginning TV Stand in French Oak Grey, showcasing its design with a television placed on the top surface and two storage baskets on the lower shelf.

2. SAFETY INFORMATION

- Keep the product away from naked flames or direct heat sources.
- Ensure all screws and fasteners are securely tightened before use.
- Do not exceed the stated weight capacities for the top (30 lbs) and bottom (20 lbs) shelves.
- Place the TV stand on a flat, stable surface to prevent tipping.
- Supervise children around the furniture to prevent climbing or misuse.

3. PACKAGE CONTENTS

Before beginning assembly, verify that all components listed below are present and undamaged. If any parts are missing or damaged, please contact customer support.

Components List:

- Top Panel (1)
- Bottom Shelf (1)
- Side Panels (2)
- Plastic Poles (4)
- Hardware Pack (screws, dowels, etc.)
- Assembly Instruction Manual (1)




Image 3.1: A detailed line drawing illustrating the dimensions of the Furinno Beginning TV Stand, useful for identifying parts and understanding the structure.

4. ASSEMBLY INSTRUCTIONS

Assembly is straightforward and can typically be completed by one person. It is recommended to have a soft, clean surface to work on to prevent scratching the furniture components. Please refer to the included hardware pack and assembly instruction sheet for detailed diagrams.

Step 1: Prepare the Area and Identify Parts

Clear a spacious area for assembly. Unpack all components and lay them out. Compare each part with the component list and diagrams in the separate instruction sheet to ensure everything is present and correctly identified.

Step 2: Attach Plastic Poles to the Bottom Shelf

Take the bottom shelf and insert the plastic poles into the designated holes. Ensure they are firmly seated. If applicable, use the provided screws to secure the poles to the bottom shelf as indicated in the assembly diagrams.

Step 3: Attach Side Panels

Connect the side panels to the plastic poles. Align the holes in the side panels with the top of the plastic poles and gently push down. Secure with screws if specified in the instructions.

Step 4: Attach the Top Panel

Carefully place the top panel onto the assembled structure, aligning the holes with the top of the side panels. Secure the top panel using the remaining screws. Ensure all connections are tight for stability.

Step 5: Final Checks

Once assembled, gently shake the TV stand to check for stability. Tighten any loose screws. Place the stand in its desired location, ensuring it is level.



Image 4.1: The assembled Furinno Beginning TV Stand positioned in a living room, demonstrating its integration with other furniture and a television.

5. USAGE GUIDELINES

- This TV stand is designed to hold televisions up to 37 inches.
- Ensure the weight of your television does not exceed 30 lbs.
- The bottom shelf has a weight capacity of 20 lbs for media devices or decorative items.
- Distribute weight evenly across the surfaces to maintain stability.
- Avoid placing hot items directly on the surface; use coasters or protective pads.

6. CARE AND MAINTENANCE

- Wipe clean with a clean, damp cloth.
- Avoid using harsh chemicals, abrasive cleaners, or polishes that may damage the finish.
- Periodically check and tighten all screws and fasteners to ensure the stand remains stable.
- Protect the furniture from direct sunlight and extreme temperature changes.

7. SPECIFICATIONS







Attribute	Detail
Brand	Furinno
Model Number	18041GYW
Material	Engineered Wood
Color	French Oak
Product Dimensions (L x W x H)	15.59 x 35.04 x 21.65 inches
Assembled Length	15.67 inches
Assembled Width	35.43 inches
Assembled Height	21.69 inches
Item Weight	19.8 pounds
Number of Shelves	1
Top Shelf Weight Capacity	30 lbs
Bottom Shelf Weight Capacity	20 lbs
Assembly Instructions	Included
Product Care Instructions	Avoid using harsh chemicals, Wipe with Dry Cloth

8. TROUBLESHOOTING

- **Stand is wobbly:** Ensure all screws are fully tightened. Check that the stand is placed on a level surface.
- **Parts do not fit:** Double-check the assembly diagrams to ensure parts are oriented correctly. Some parts may appear similar but have subtle differences.
- **Missing hardware:** Refer to the package contents list. If hardware is missing, contact Furinno customer support for assistance.
- **Scratches or damage during assembly:** Use a soft cloth or blanket during assembly to protect surfaces. Minor scratches can sometimes be touched up with furniture repair markers.

9. WARRANTY AND SUPPORT

Furinno products are manufactured with quality and care. For specific warranty information or to request replacement parts, please refer to the warranty card included in your package or visit the official Furinno website. For further assistance, contact Furinno customer service.

	<p>Furinno TV Stand & End Table Assembly Manual - JAYA & Andrey Models</p> <p>Comprehensive assembly instructions for Furinno JAYA Large TV Stand (Model 15119) and Furinno Andrey Set of 2 End Tables (Model 11157). Includes parts lists, step-by-step guides, and important warnings.</p>
	<p>Furinno Pasir 4 Tier Open Shelf & Andrey End Table Assembly Instructions</p> <p>Comprehensive assembly instructions for the Furinno Pasir 4 Tier Open Shelf (Model 11209) and the Furinno Andrey Set of 2 End Tables/Night Stands (Model 11157), including hardware lists, parts lists, and step-by-step guidance.</p>
	<p>Furinno Grand Entertainment Center Model 14146 Assembly Instructions</p> <p>Step-by-step assembly guide for the Furinno Grand Entertainment Center (Model 14146), including parts list, hardware, warnings, and customer support information. Designed for easy setup with no tools required.</p>
	<p>Furinno FR21028B Floating Storage Hutch Media Console Assembly Instructions</p> <p>Step-by-step assembly guide and parts list for the Furinno FR21028B Floating Storage Hutch Media Console. Includes all necessary hardware and assembly tips for building your media console.</p>
	<p>Furinno Furniture Assembly Instructions: Jaya Coffee Table & Turn-N-Tube TV Stand</p> <p>Comprehensive assembly instructions and product details for the Furinno Jaya Simple Design Oval Coffee Table (Model 15079) and Furinno Turn-N-Tube 3-Tier Entertainment TV Stand (Model 12250R1). Includes parts lists, step-by-step guides, and important warnings.</p>
	<p>Furinno FG21748 Sun Lounger with Tray Assembly Instructions and Care Guide</p> <p>Assemble your Furinno FG21748 Sun Lounger with Tray using this comprehensive guide. Includes parts list, hardware details, step-by-step assembly instructions, and care tips for outdoor furniture.</p>