



Manuals.plus /

› AOC /

› AOC 22V2H 22-inch Full HD Ultra-Slim Monitor Instruction Manual

AOC 22V2H

AOC 22V2H 22-inch Full HD Ultra-Slim Monitor Instruction Manual

1. SETUP AND ASSEMBLY

This section provides instructions for the initial setup and assembly of your AOC 22V2H monitor.

1.1 Unpacking the Monitor

Carefully remove all components from the packaging. Ensure all items listed in the 'What's in the Box' section are present. Retain the packaging for future transport or service needs.

1.2 Attaching the Stand

1. Place the monitor face down on a soft, clean surface to prevent scratches.
2. Align the stand base with the stand neck and secure it, typically with a screw or by snapping it into place.
3. Attach the assembled stand to the back of the monitor. Ensure it clicks securely or is fastened with the provided screws.

Note: The AOC 22V2H monitor's input ports are integrated into the stand. This design means the stand must be connected for functionality.



Image: Rear view of the AOC 22V2H monitor, highlighting the stand and its integrated connectivity ports.

1.3 Connecting Cables

1. **Power Connection:** Connect the power adapter to the monitor's power input on the stand, then plug the power cord into a power outlet.
2. **Video Connection:** Connect one end of the HDMI cable (included) to the HDMI port on the monitor stand and the other end to the HDMI output port on your computer or device. Alternatively, use a VGA cable for VGA connections.
3. **Audio Output:** If desired, connect external speakers or headphones to the 3.5mm audio line-out port on the monitor stand.



Image: Angled rear view of the monitor, illustrating the HDMI and power input locations on the stand.

2. OPERATING THE MONITOR

This section details how to power on your monitor and navigate its On-Screen Display (OSD) menu for various adjustments.

2.1 Powering On/Off

Press the power button, usually located on the bottom right bezel or rear of the monitor, to turn the monitor on or off. The power indicator light will illuminate when the monitor is active.



Image: Front view of the AOC 22V2H monitor displaying an active screen.

2.2 On-Screen Display (OSD) Menu Navigation

The OSD menu allows you to adjust various monitor settings. Buttons for OSD navigation are typically located on the bottom bezel or rear of the monitor.

- Press any OSD button to activate the menu.
- Use the navigation buttons (often directional arrows) to move through menu options.
- Press the 'Menu' or 'OK' button to select an option or confirm a setting.
- Use the 'Exit' or 'Back' button to return to the previous menu or exit the OSD.

2.3 Adjusting Display Settings

Within the OSD menu, you can customize your viewing experience:

- **Brightness/Contrast:** Adjust these settings to suit your environment and preference.
- **Color Settings:** Modify color temperature, gamma, and individual RGB levels.

- **Input Select:** Manually switch between HDMI and VGA input sources if auto-detection does not work.
- **Picture Enhancement:** Utilize features like *AOC Flicker-Free* technology to reduce eye strain during prolonged use and *AOC Low Blue Mode* to minimize harmful blue light emissions.
- **Refresh Rate:** Ensure your system is configured to output at the monitor's optimal 75Hz refresh rate for smoother visuals, especially during gaming. The monitor also supports AMD FreeSync for adaptive synchronization with compatible graphics cards.



Image: Front view of the AOC 22V2H monitor showcasing a vibrant display, demonstrating its picture quality.

3. MAINTENANCE

Proper maintenance ensures the longevity and optimal performance of your monitor.

3.1 Cleaning the Monitor

- Always power off the monitor and unplug the power cord before cleaning.
- Use a soft, lint-free cloth lightly dampened with water or a specialized screen cleaner to wipe the screen. Avoid harsh chemicals, abrasives, or alcohol-based cleaners.
- For the monitor casing, use a soft, dry cloth.
- Do not spray liquid directly onto the screen or casing.

3.2 Safety Precautions

- Do not block ventilation openings on the monitor.
- Avoid placing the monitor in direct sunlight or near heat sources.
- Keep the monitor away from moisture and dust.
- Do not attempt to service the monitor yourself. Refer all servicing to qualified personnel.

4. TROUBLESHOOTING

This section addresses common issues you might encounter with your AOC 22V2H monitor.

4.1 No Power

- Ensure the power cord is securely connected to both the monitor and the power outlet.
- Verify that the power outlet is functioning correctly by plugging in another device.
- Check the power adapter for any visible damage.

4.2 No Signal

- Confirm that the video cable (HDMI or VGA) is firmly connected to both the monitor and your computer/device.
- Ensure the correct input source is selected in the monitor's OSD menu.
- Test with a different video cable or another device to rule out cable or source issues.

4.3 Distorted or Unclear Image

- Adjust the monitor's resolution to its native 1920x1080 resolution through your computer's display settings.
- Check the refresh rate setting on your computer and ensure it is set to 75Hz.
- Reset the monitor to factory default settings via the OSD menu.
- If using an analog (VGA) connection, perform an auto-adjustment from the OSD menu.

5. SPECIFICATIONS

Key technical specifications for the AOC 22V2H monitor:

Feature	Specification
Brand	AOC
Model Number	22V2H
Screen Size	22 Inches (21.5" Viewable)
Resolution	FHD 1080p (1920 x 1080 Pixels)
Aspect Ratio	16:9
Display Type	LED IPS
Refresh Rate	75 Hz
Response Time	5 Milliseconds
Contrast Ratio	20,000,000:1 (Smart Contrast)
Connectivity Technology	HDMI 1.4, VGA
Hardware Connectivity	3.5mm Audio Line-out
Adaptive Sync	FreeSync
Additional Features	Anti Glare Screen, Blue Light Filter, Flicker-Free, Frameless, Tilt Adjustment
Item Weight	6.03 Pounds
Color	Black
Mounting Type	VESA Mountable (Note: Requires adapter due to integrated stand design)

6. WARRANTY INFORMATION

The AOC 22V2H monitor comes with a comprehensive warranty to protect your investment.

- **Manufacturer's Warranty:** Three-year manufacturer's warranty.
- **Coverage:** This warranty covers parts and labor for a period of three years from the date of purchase.

For detailed terms and conditions, please refer to the warranty card included with your product or visit the official AOC support website.

7. CUSTOMER SUPPORT

If you require further assistance or encounter issues not covered in this manual, please contact AOC customer support.

- **Online Support:** Visit the official AOC website for FAQs, driver downloads, and support resources.
- **Contact Information:** Refer to your product's quick start guide or the AOC website for regional customer service contact details (phone numbers, email).

When contacting support, please have your monitor's model number (22V2H) and serial number ready.