

Melitta 1023-01

Melitta Easy II 1023-01 Filter Coffee Maker User Manual

Model: 1023-01 | Brand: Melitta

1. INTRODUCTION

Thank you for choosing the Melitta Easy II 1023-01 Filter Coffee Maker. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your new appliance. Please read these instructions carefully before first use and retain them for future reference.

The Melitta Easy II is designed to brew aromatic filter coffee, featuring a transparent water tank, a borosilicate glass jug, and an automatic shut-off function for convenience and safety.

2. SAFETY INSTRUCTIONS

- Always connect the appliance to a properly grounded power outlet.
- Do not immerse the appliance, power cord, or plug in water or other liquids.
- Ensure the voltage indicated on the appliance matches your local mains voltage before connecting.
- Keep the appliance out of reach of children. This appliance is not intended for use by persons with reduced physical, sensory, or mental capabilities unless supervised.
- Do not operate the appliance if the power cord or plug is damaged, or if the appliance malfunctions or has been damaged in any way. Contact authorized service personnel for repair.
- Avoid contact with hot surfaces. The heating plate and glass jug become hot during and after operation. Use handles and knobs.
- Always unplug the coffee maker from the power outlet before cleaning and when not in use. Allow it to cool down completely before handling or storing.
- Use only cold, fresh water in the water tank.
- Do not place the appliance on or near hot gas or electric burners, or in a heated oven.
- Do not use the appliance for purposes other than its intended use.

3. PRODUCT OVERVIEW

Familiarize yourself with the components of your Melitta Easy II coffee maker:



Image 1: Angled view of the Melitta Easy II 1023-01 Filter Coffee Maker, showing the water tank, filter holder, and glass jug.

1. **Water Tank:** Transparent tank with clear markings for water level.
2. **Water Level Indicator:** Easy-to-read scale on the front for 10 large (125 ml) or 15 small (85 ml) cups.
3. **Swivel Filter Holder:** Holds the coffee filter and ground coffee. It can be swiveled out for easy access.
4. **Drip-Stop System:** Prevents dripping when the jug is removed.
5. **Borosilicate Glass Jug:** Durable glass jug for collecting and serving brewed coffee.
6. **Heating Plate:** Keeps the coffee warm after brewing.
7. **Power Switch with Indicator Light:** To turn the appliance on/off.
8. **Cable Storage:** Integrated compartment in the base for tidy cable management.





Image 2: Front view of the Melitta Easy II 1023-01 Filter Coffee Maker, highlighting the water level indicator and power switch.

4. SETUP

4.1 Unpacking and First Use

1. Remove all packaging materials and promotional labels from the coffee maker.
2. Clean the glass jug and the swivel filter holder with warm soapy water. Rinse thoroughly and dry. The swivel filter holder is dishwasher-safe.
3. Wipe the exterior of the appliance with a damp cloth.
4. Before brewing coffee for the first time, operate the coffee maker with only water (without coffee) for two full cycles to clean the internal components.

4.2 Placement

Place the coffee maker on a stable, flat, heat-resistant surface, away from the edge of the countertop and out of reach of children. Ensure there is adequate ventilation around the appliance.

4.3 Power Connection

Unwind the power cord from the integrated cable storage compartment in the base. Plug the power cord into a grounded 230V AC power outlet.

5. OPERATING INSTRUCTIONS

5.1 Brewing Coffee

1. **Fill Water Tank:** Open the lid of the water tank. Fill the transparent water tank with fresh, cold water up to the desired level using the water level indicator. The tank has a capacity of 1.25 liters, suitable for 10 large cups (125 ml each) or 15 small cups (85 ml each). Close the lid.

2. **Insert Filter:** Swivel the filter holder to the side. Insert a Melitta 1x4 paper filter into the filter holder.
3. **Add Ground Coffee:** Add the desired amount of ground coffee into the paper filter. A general guideline is one level tablespoon of ground coffee per cup, but adjust to your personal taste.
4. **Position Filter Holder:** Swivel the filter holder back into its closed position, ensuring it is securely seated.
5. **Place Glass Jug:** Place the empty borosilicate glass jug with its lid on the heating plate, ensuring it is correctly positioned to activate the drip-stop mechanism.
6. **Start Brewing:** Press the power switch. The indicator light will illuminate, and the brewing process will begin. The appliance operates at 1050 W for optimal brewing temperature.
7. **Drip-Stop System:** The integrated drip-stop system prevents coffee from dripping onto the heating plate when the jug is temporarily removed during brewing.
8. **Keep Warm Function:** After brewing, the coffee maker will automatically keep the coffee warm for approximately 40 minutes.
9. **Automatic Shut-off:** For safety and energy saving, the appliance will automatically switch off after 40 minutes.

6. CLEANING AND MAINTENANCE

6.1 Daily Cleaning

1. Always unplug the coffee maker and allow it to cool completely before cleaning.
2. Remove the used paper filter and discard the coffee grounds.
3. Wash the glass jug and its lid, and the swivel filter holder in warm soapy water. These parts are also dishwasher-safe.
4. Wipe the exterior surfaces of the coffee maker with a soft, damp cloth. Do not use abrasive cleaners or scouring pads.
5. Never immerse the main unit of the coffee maker in water or any other liquid.

6.2 Descaling

Over time, mineral deposits (limescale) can build up in your coffee maker, affecting its performance and the taste of your coffee. The frequency of descaling depends on the hardness of your water and how often you use the appliance.

To descale, use a commercially available descaling solution suitable for coffee makers, following the manufacturer's instructions. Alternatively, a solution of white vinegar and water (1:2 ratio) can be used. Run the descaling solution through the coffee maker as if brewing coffee, then rinse by running several cycles with fresh water only.

7. TROUBLESHOOTING

If you encounter issues with your Melitta Easy II coffee maker, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Coffee maker does not turn on.	Not plugged in; power outage; faulty power switch.	Ensure the power cord is securely plugged into a working outlet. Check your circuit breaker. If the switch is faulty, contact customer support.
Coffee is not brewing.	No water in the tank; filter holder not correctly seated; jug not on heating plate.	Fill the water tank. Ensure the filter holder is fully closed. Verify the glass jug is correctly placed on the heating plate.
Coffee tastes weak or too strong.	Incorrect coffee-to-water ratio; coffee grind too coarse/fine; appliance needs descaling.	Adjust the amount of coffee. Use a medium grind for filter coffee. Descale the appliance if necessary.
Water leaks from the filter holder.	Filter holder not properly closed; filter paper collapsed; too much coffee.	Ensure the filter holder is fully closed. Make sure the filter paper is correctly inserted and not overflowing. Reduce the amount of coffee.
Drip-stop not working.	Jug not correctly positioned; drip-stop mechanism clogged.	Ensure the jug is fully pushed onto the heating plate. Clean the drip-stop mechanism if it appears clogged.

If the problem persists after attempting these solutions, please contact Melitta customer support.

8. SPECIFICATIONS




Image 3: Technical drawing illustrating the dimensions of the Melitta Easy II 1023-01 coffee maker.

- **Model:** Melitta Easy II 1023-01
- **Brand:** Melitta
- **Capacity:** 1.25 Liters (approx. 10 large cups / 15 small cups)
- **Power:** 1050 Watts
- **Voltage:** 230 Volts
- **Material:** Plastic (housing), Borosilicate Glass (jug)
- **Dimensions (H x W x D):** 295 x 170 x 224 mm
- **Weight:** 1.32 kg
- **Cable Length:** 70 cm
- **Filter Size:** 1x4
- **Features:** Drip-stop system, Automatic shut-off (after 40 minutes), Dishwasher-safe swivel filter holder, Integrated cable storage.

9. WARRANTY AND SUPPORT

Melitta products are manufactured to high-quality standards. For information regarding the warranty period and conditions applicable to your region, please refer to the warranty card included with your purchase or visit the official Melitta website.






For technical support, spare parts, or service inquiries, please contact Melitta customer service. Contact details can typically be found on the Melitta website or on your product packaging.

10. OFFICIAL PRODUCT VIDEOS

No official product videos from the seller are available for embedding at this time.

© 2025 Melitta. All rights reserved.

Related Documents - 1023-01

	<p>Melitta Easy Timer & EasyTop® Timer Coffee Maker User Manual</p> <p>Comprehensive user manual for the Melitta Easy Timer and EasyTop® Timer filter coffee maker, covering safety instructions, operation, cleaning, and maintenance.</p>
	<p>Melitta Easy Filter Coffee Maker - User Manual and Operating Guide</p> <p>Comprehensive user manual and operating guide for the Melitta Easy and EasyTop filter coffee makers, covering setup, brewing, cleaning, maintenance, safety instructions, and disposal information.</p>
	<p>Melitta Easy Timer & EasyTop Timer Filter Coffee Maker - Operating Instructions</p> <p>Comprehensive operating instructions and safety guide for the Melitta Easy Timer and EasyTop Timer filter coffee makers, covering setup, brewing, timer function, cleaning, and maintenance.</p>
	<p>Melitta epour® Bedienungsanleitung</p> <p>Umfassende Bedienungsanleitung für die Melitta® epour® Filterkaffeemaschine. Entdecken Sie die Zubereitung, Funktionen und Pflege für perfekten Kaffeegenuss.</p>
	<p>Melitta LOOK® THERM Timer Coffee Maker User Manual</p> <p>Comprehensive user manual for the Melitta LOOK® THERM Timer filter coffee maker, detailing features, operation, safety instructions, and maintenance. Includes multilingual support.</p>



Comprehensive user manual for the Melitta Easy Timer and EasyTop Timer filter coffee makers, covering safety, operation, maintenance, and disposal information. Includes instructions for brewing coffee, setting the timer, and cleaning the appliance.