

[manuals.plus](#) /› [NEDIS](#) /› [Nedis Mechanical Gaming Wired Keyboard \(Model GKBD200BKUS\) User Manual](#)**NEDIS GKBD200BKUS**

Nedis Mechanical Gaming Wired Keyboard (Model GKBD200BKUS) User Manual

Comprehensive instructions for setup, operation, and maintenance.

1. INTRODUCTION

This manual provides essential information for the proper use and maintenance of your Nedis Mechanical Gaming Wired Keyboard, model GKBD200BKUS. Please read these instructions carefully before using the product to ensure optimal performance and longevity.

2. SAFETY INFORMATION

- Keep the keyboard away from liquids and excessive moisture.
- Avoid exposing the keyboard to extreme temperatures.
- Do not attempt to disassemble or repair the keyboard yourself. Refer to qualified service personnel.
- Use only with compatible devices and power sources as specified.

3. PACKAGE CONTENTS

Verify that all items are present in the package:

- Nedis Mechanical Gaming Wired Keyboard (Model GKBD200BKUS)
- USB Cable (integrated)
- User Manual (this document)



Image: The retail packaging for the Nedis Mechanical Gaming Wired Keyboard, showing the product name and features.

4. PRODUCT OVERVIEW

The Nedis Mechanical Gaming Wired Keyboard (GKBD200BKUS) is designed for gaming and general use, featuring a durable metal body, multi-color RGB backlighting, and a US International layout. It includes a convenient phone holder for mobile gaming or media consumption.



Image: A top-down view of the Nedis Mechanical Gaming Wired Keyboard, showcasing its full US International layout.



Image: A close-up view highlighting the solid metal frame construction and ABS keycap material of the keyboard.

5. SETUP INSTRUCTIONS

- 1. Connect the Keyboard:** Plug the integrated USB cable from the keyboard into an available USB port on your computer (PC).
- 2. Driver Installation:** The keyboard is plug-and-play. Your operating system (Windows 10, etc.) should automatically detect and install the necessary drivers. No additional software installation is typically required.
- 3. Initial Test:** Open a text editor or browser and type to ensure the keyboard is functioning correctly.



Image: The Nedis Mechanical Gaming Wired Keyboard with its braided USB cable, ready for connection.

ON THE GO

on the go unrestricted gaming



Image: An illustration showing the keyboard's wide compatibility with various Windows and Mac operating systems, highlighting its 1.5-meter USB 2.0 cable.

6. OPERATING INSTRUCTIONS

6.1. RGB Backlighting

The keyboard features multi-color RGB backlighting. Specific controls for changing modes or brightness are typically accessed via function key combinations (Fn + [key]). Refer to the keyboard's key legends for specific RGB control functions, often indicated by light bulb icons or similar symbols.



Image: The Nedis Mechanical Gaming Wired Keyboard illuminated with vibrant multi-color RGB backlighting, showcasing dynamic lighting effects.



Image: A detailed view of the keyboard's keys, highlighting the extra-bright RGB illumination and dynamic lighting capabilities.

6.2. Multimedia Keys

The keyboard includes dedicated multimedia function keys (F1-F12, often combined with the Fn key) to control audio, video playback, and other system functions. These keys are designed to facilitate operation and improve efficiency.



Image: The keyboard layout emphasizing the multimedia function keys and indicating a durability rating of at least 10 million keystrokes.

6.3. Phone Holder

The keyboard features an integrated phone holder. To use, simply place your smartphone into the designated slot on the top of the keyboard. For mobile gaming, connect your phone to the keyboard via a compatible USB adapter (not included) for unrestricted control.



Image: The Nedis Mechanical Gaming Wired Keyboard featuring an integrated phone holder, with a smartphone positioned for use.

7. MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to wipe the surface of the keyboard. For stubborn dirt, a slightly damp cloth can be used, ensuring no liquid enters the keyboard. Do not use harsh chemicals or abrasive cleaners.
- **Keycap Cleaning:** Keycaps can be carefully removed for deeper cleaning if necessary. Use a keycap puller (not included) to avoid damage.
- **Storage:** When not in use, store the keyboard in a clean, dry environment away from direct sunlight.

8. TROUBLESHOOTING

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Keyboard not responding	Loose USB connection, faulty USB port, driver issue.	<ul style="list-style-type: none"> Ensure the USB cable is securely plugged into the computer. Try a different USB port. Restart your computer. Check Device Manager for driver issues (Windows).
RGB lighting not working	Lighting disabled, software conflict.	<ul style="list-style-type: none"> Press the designated RGB control keys (e.g., Fn + Scroll Lock or similar, refer to key legends) to cycle through modes or enable lighting. Ensure no conflicting software is running.
Certain keys not working	Debris under keycap, physical damage.	<ul style="list-style-type: none"> Gently remove the keycap and clean any debris. If physical damage is suspected, contact customer support.

9. SPECIFICATIONS

Feature	Detail
Brand	NEDIS
Model	GKBD200BKUS
Connectivity Technology	Wired (USB)
Keyboard Description	Multimedia, Mechanical
Recommended Uses	Gaming
Compatible Devices	PC
Operating System	Windows 10 (and earlier versions), Mac OS
Special Features	Backlit (RGB), Integrated Phone Holder
Material	Metal (frame)
Product Dimensions (LxWxH)	21 x 4 x 46 cm
Item Weight	970 g
Cable Length	1.5 meters (approx.)
Keystroke Life	At least 10 million keystrokes

10. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the official Nedis website or contact your local retailer. Keep your proof of purchase for warranty claims.

Nedis Customer Service: For further assistance, visit www.nedis.com.

© 2023 NEDIS. All rights reserved. Information in this manual is subject to change without notice.