

Oxelo B100

Oxelo B100 Helmet User Manual

Model: B100 | Brand: Oxelo



1. PRODUCT OVERVIEW

The Oxelo B100 Helmet is designed for children participating in skating, skateboarding, and scootering activities. This helmet provides essential head protection, featuring a stable design with an adjustment dial and ample ventilation for comfort.

Key Features:

- Designed for children's skating, skateboarding, and scootering.
- Stable fit ensured by the helmet's shape and adjustment dial.
- Adjustable buckle and strap dividers for a secure fit.
- 11 large vents for effective ventilation.
- Constructed with 100% Acrylonitrile Butadiene Styrene outer fabric.



Image 1.1: Front-side view of the Oxelo B100 Helmet in blue, showcasing its overall design and ventilation openings.

2. SETUP INSTRUCTIONS

2.1. Adjusting the Fit

Proper helmet fit is crucial for safety. The Oxelo B100 helmet features an adjustment dial and adjustable straps to ensure a snug and stable fit.

- 1. Positioning the Helmet:** Place the helmet squarely on the head, ensuring it covers the forehead without tilting back. The front edge should be approximately two finger-widths above the eyebrows.
- 2. Using the Adjustment Dial:** Locate the adjustment dial at the back of the helmet. Turn the dial clockwise to tighten the fit or counter-clockwise to loosen it. Adjust until the helmet feels snug but comfortable, without excessive movement when shaking your head.
- 3. Adjusting the Side Straps:** The side straps should form a 'V' shape just below the ears. Use the strap dividers to slide them up or down until they are positioned correctly.
- 4. Securing the Chin Strap:** Fasten the buckle under the chin. Tighten the chin strap until it is snug, allowing only one or two fingers to fit between the strap and the chin. Ensure the strap does not pinch the skin.



Image 2.1: Side view of the Oxelo B100 Helmet, highlighting the rear adjustment dial for a secure fit.



Image 2.2: Front view of the Oxelo B100 Helmet, illustrating the chin strap and buckle system.

3. OPERATING THE HELMET

3.1. Wearing the Helmet Correctly

Always wear the helmet correctly to ensure maximum protection. The helmet should be worn for all activities involving inline skates, skateboards, or scooters.

- Ensure the helmet is level on your head, not tilted back or forward.
- The chin strap must always be buckled and tightened securely.
- Check the fit before each use to ensure it remains snug and stable.

3.2. Intended Use

This helmet is specifically designed for children engaging in recreational skating, skateboarding, and scootering. It is not intended for motor sports or other high-speed activities.

4. CARE AND MAINTENANCE

4.1. Cleaning

To clean your Oxelo B100 helmet, use a soft cloth dampened with mild soap and water. Avoid using harsh chemicals, abrasive cleaners, or solvents, as these can damage the helmet's materials and compromise its protective properties.

4.2. Storage

Store the helmet in a dry place, away from direct sunlight and extreme temperatures. Prolonged exposure to heat or UV light can degrade the helmet's materials. It is recommended to store the helmet in its original packaging or a protective bag when not in use.

5. TROUBLESHOOTING

5.1. Common Issues

- **Helmet feels loose:** Re-adjust the fit dial and ensure the chin strap is tightened appropriately. Check that the side straps form a 'V' shape below the ears.
- **Helmet is uncomfortable:** Loosen the adjustment dial slightly. Ensure no hair or clothing is caught under the straps or padding. If discomfort persists, the helmet size may be incorrect.
- **Visible damage:** If the helmet shows any signs of damage (cracks, dents, or deep scratches), it should be replaced immediately, even if it appears minor. A damaged helmet may not provide adequate protection in an impact.

6. PRODUCT SPECIFICATIONS

Specification	Detail
Brand	Oxelo

Model Name	Oxelo B100
Colour	Blue
Age Range (Description)	Kid
Size	52-54 CM
Special Feature	Ventilation
Outer Material	Acrylonitrile Butadiene Styrene (ABS)
Inner Material	Foam
Item Weight	400 Grams
Item Dimensions L x W x H	12 x 54 x 12 Centimeters
Recommended Uses For Product	Skateboarding, Skating, Scootering
Manufacturer	Decathlon

7. WARRANTY INFORMATION

The Oxelo B100 Helmet comes with a **2-year warranty** from the date of purchase. This warranty covers manufacturing defects. Please retain your proof of purchase for any warranty claims. The warranty does not cover damage resulting from misuse, accidents, or normal wear and tear.

8. CUSTOMER SUPPORT

For further assistance, questions, or concerns regarding your Oxelo B100 Helmet, please refer to the retailer where the product was purchased or visit the official Oxelo website for contact information. Always ensure to provide your product model (B100) and any relevant purchase details when seeking support.

© 2023 Oxelo. All rights reserved.

This manual is for informational purposes only.

