Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

meidong 3119

Meidong COWIN 3119 Portable Smart Speaker

User Manual

1. Product Overview

The Meidong COWIN 3119 is a versatile portable speaker designed for high-quality audio playback and smart home integration. It supports both WiFi and Bluetooth connectivity, allowing for seamless music streaming from various sources. With built-in Amazon Alexa, you can control your music, get information, and manage smart home devices using voice commands. Its multi-room audio feature enables synchronized playback across multiple speakers for an immersive listening experience throughout your home.



Image 1.1: Front view of the Meidong COWIN 3119 Portable Smart Speaker, showcasing its sleek black design and top panel controls.

2. Safety Information

Please read all safety instructions carefully before using the device. Keep this manual for future reference.

- Do not expose the speaker to water, moisture, or extreme temperatures.
- Avoid dropping or subjecting the speaker to strong impacts.
- Do not attempt to disassemble, repair, or modify the speaker. This will void the warranty.
- Use only the provided charging cable and adapter.
- Keep the speaker away from heat sources such as radiators, stoves, or other heat-producing appliances.
- Clean the speaker only with a dry, soft cloth.

3. Package Contents

Ensure all items are present in the package:

- Meidong COWIN 3119 Portable Smart Speaker
- USB Charging Cable
- User Manual (this document)

4. Product Features

- **Dual Wireless Modes:** Offers 9 hours of playback in WiFi mode and 12 hours in Bluetooth mode for extended use.
- **Powerful 20W Audio:** Equipped with dual 10W drivers and advanced DSP chips for automatic EQ adjustment, delivering rich, distortion-free stereo sound.
- **Multi-Room Play:** Connect up to 16 COWIN 3119 series speakers to create a synchronized multi-room audio system.
- **Amazon Alexa Built-in:** Access voice commands for music, news, smart home control, and more.
- **Versatile Connectivity:** Supports WiFi, Bluetooth, and USB connections.
- **Enhanced Bass:** Features a 1.5L high-capacity chamber and passive bass radiator for deep, resonant bass.
- **App Control:** Manage settings and features via a dedicated mobile application.




Image 4.1: Diagram illustrating the internal components of the speaker, including the 20W stereo output, 1.5L high-capacity chamber, passive bass radiator, and 2.75-inch full-screen loudspeaker.



Image 4.2: The speaker shown with a smartphone displaying icons for WiFi support, App Control, Voice Control, and Bluetooth connectivity, highlighting its versatile control options.

5. Controls and Indicators

The top panel of the speaker features several control buttons and indicators:

- **Power Button:** Press and hold to turn the speaker on or off.
- **Volume Down (-):** Decreases the volume.
- **Volume Up (+):** Increases the volume.
- **Play/Pause Button:** Plays or pauses audio playback.
- **Mode Button:** Switches between WiFi and Bluetooth modes.
- **Microphone Button:** Activates or deactivates the microphone for Alexa commands.
- **LED Indicator:** Displays current status (e.g., charging, connected, mode).

6. Setup

6.1 Initial Charging

Before first use, fully charge the speaker. Connect the USB charging cable to the speaker's charging port and the other end to a compatible USB power adapter (not included) or a computer's USB port. The LED indicator will show charging status and turn off when fully charged.

6.2 Powering On/Off

- **To Power On:** Press and hold the Power button until the LED indicator lights up.
- **To Power Off:** Press and hold the Power button until the LED indicator turns off.

6.3 Connecting to Wi-Fi

For full functionality, including Amazon Alexa and multi-room audio, connect the speaker to your home Wi-Fi network. Download the official Meidong COWIN app from your smartphone's app store (iOS/Android). Follow the in-app instructions to connect your speaker to Wi-Fi and set up your Alexa account.

6.4 Connecting via Bluetooth

1. Turn on the speaker.
2. Press the Mode button to switch to Bluetooth mode. The LED indicator will flash, indicating it's in pairing mode.
3. On your smartphone or Bluetooth-enabled device, go to Bluetooth settings and search for available devices.
4. Select "COWIN 3119" from the list.
5. Once connected, the LED indicator will stop flashing and remain solid.

7. Operating

7.1 WiFi Mode Operation (Alexa, Streaming Services)

Once connected to Wi-Fi and linked to your Alexa account via the app, you can use voice commands to control the speaker. Say "Alexa" followed by your command. The speaker supports various streaming services like Spotify, Airplay, and iHeart Radio through the Alexa app or direct integration.



Image 7.1: The speaker positioned in front of various app icons, illustrating its compatibility with Amazon Alexa and popular music and smart home services.

7.2 Bluetooth Mode Operation

In Bluetooth mode, the speaker acts as a standard Bluetooth audio device. Play music from your paired smartphone or tablet, and control playback (play/pause, volume) using the speaker's buttons or your device.

7.3 Multi-Room Audio Setup

To set up a multi-room audio system with multiple COWIN 3119 speakers:

1. Ensure all speakers are connected to the same Wi-Fi network via the Meidong COWIN app.
2. Open the app and navigate to the multi-room audio settings.
3. Group speakers together to play the same music synchronously, or assign different music to individual speakers/groups.



Image 7.2: An overhead diagram of a house layout showing multiple COWIN 3119 speakers in different rooms (bedroom, kitchen, living room) connected wirelessly to form a multi-room audio system, with a phone displaying the network settings.

8. Charging

The speaker features a built-in rechargeable battery. A full charge provides approximately 9 hours of playback in WiFi mode and 12 hours in Bluetooth mode. When the battery is low, the LED indicator may change color or flash. Connect the speaker to a power source using the provided USB cable to recharge.



Image 8.1: The speaker with a graphic overlay indicating a 2000 mAh battery capacity and 12 hours of play time, emphasizing its long battery life.

9. Maintenance

- **Cleaning:** Use a soft, dry, lint-free cloth to clean the speaker's surface. Do not use abrasive cleaners, alcohol, or other chemical solvents.
- **Storage:** When not in use for extended periods, store the speaker in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Charge the speaker regularly, even if not in use.

10. Troubleshooting

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Speaker does not turn on	Low battery; Power button not held long enough	Charge the speaker; Press and hold the Power button for 3-5 seconds
No sound	Volume too low; Incorrect mode; Device not connected	Increase volume; Switch to correct mode (WiFi/Bluetooth); Reconnect device
Bluetooth pairing fails	Speaker not in pairing mode; Device too far; Interference	Ensure speaker is in pairing mode; Move device closer; Turn off other Bluetooth devices
WiFi connection issues	Incorrect Wi-Fi password; Router issues; Speaker too far from router	Verify password; Restart router; Move speaker closer to router; Use the app for troubleshooting
Alexa not responding	No internet connection; Microphone off; Alexa account not linked	Check Wi-Fi connection; Ensure microphone is active; Link Alexa account via app

11. Specifications

Feature	Specification
Model Number	COWIN 3119
Brand	Meidong
Connectivity Technology	Bluetooth, USB, WiFi
Speaker Output Power	20 Watts (Dual 10W drivers)
Battery Life (Bluetooth)	Up to 12 Hours
Battery Life (WiFi)	Up to 9 Hours
Controller Type	Amazon Alexa
Speaker Type	Multiroom
Dimensions (L x W x H)	28.8 x 14.2 x 11.4 cm (approx. 11.3 x 5.6 x 4.5 inches)
Weight	1.34 kg (approx. 2.95 lbs)



Image 11.1: The speaker shown with its approximate dimensions: 10.1 inches in length, 3.2 inches in width, and 3.6 inches in height.

12. Warranty and Support

For warranty information and technical support, please refer to the contact details provided on the product packaging or the official Meidong website. Keep your purchase receipt as proof of purchase for any warranty claims.

© 2024 Meidong. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07GP36QM3

More documents and user manuals: **https://manuals.plus/**