B Bubos BU-F0701

Bubos BU-F0701 Baby Food Maker Instruction Manual

Model: BU-F0701 | Brand: B Bubos

Introduction

The Bubos Baby Food Maker is a versatile 5-in-1 appliance designed to simplify the preparation of healthy homemade baby food. It combines steaming, blending, cooking, mashing, and pureeing functions into one compact device. This manual provides essential information for safe and efficient operation, maintenance, and troubleshooting.



Image: The Bubos Baby Food Maker, a compact white and green appliance, shown on a kitchen counter.

Important Safety Information

Always prioritize safety when operating the Bubos Baby Food Maker. This appliance is designed with safety features to protect you and your baby.

- **BPA and Lead-Free:** All food-contacting parts are made from BPA and lead-free materials, ensuring your baby's food is safe.
- **Automatic Shut-off:** The device features an automatic shut-off mechanism that activates when the water tank is empty during steaming, preventing overheating and potential damage.
- **Double Switch Safety Clasp:** Designed to prevent accidental operation.
- **Heat Insulation Design:** Protects hands from heat during operation.
- **Removable Knife Set:** For easy and thorough cleaning, preventing residue buildup.



Image: A detailed diagram highlighting the double switch safety clasp, heat insulation design, and removable knife set for enhanced safety and ease of cleaning.

Product Components

The Bubos Baby Food Maker includes the following parts:

- Main Unit with Control Panel
- Blender Jar with Lid
- Steaming Basket
- Mixing Lid
- Spatula
- Measuring Cup
- Instruction Manual



Image: The Bubos Baby Food Maker displaying its 4-in-1 powerful functions: Steam, Auto Blending, Reheat, and Defrost.

Setup and First Use

1. **Unpack:** Carefully remove all components from the packaging.
2. **Clean:** Before first use, wash all parts that will come into contact with food (blender jar, lid, steaming basket, blade, spatula, measuring cup) with warm soapy water. Rinse thoroughly and dry. The bowl and blade are dishwasher-safe.
3. **Assemble:** Place the main unit on a stable, flat surface. Ensure the blender jar is correctly seated on the base.
4. **Water Tank:** Open the water tank lid on the main unit. Fill the water tank with distilled or purified water up to the MAX line. Close the lid securely.

Your browser does not support the video tag.

Video: This video demonstrates the unboxing and initial setup of a baby food maker, including placing ingredients and adding water for steaming. It provides a visual guide for preparing the appliance for use.

Operating Instructions

Steaming Food

1. **Prepare Ingredients:** Wash, peel, and chop fruits, vegetables, or meat into small, uniform pieces (approximately 1/4 to 1/2 inch cubes).
2. **Load Steaming Basket:** Place the prepared ingredients into the steaming basket.
3. **Place Basket:** Insert the steaming basket into the blender jar. Secure the blender jar lid.
4. **Add Water:** Ensure the water tank on the main unit is filled with distilled or purified water to the appropriate level (refer to the MAX line).
5. **Select Steam Function:** On the control panel, select the 'Steam' function.
6. **Set Time:** Adjust the steaming time according to the type and quantity of food. For apples, 15 minutes is typically sufficient.
7. **Start:** Press the start button. The appliance will begin steaming and automatically shut off when the cycle is complete.

Blending/Pureeing Food

1. **After Steaming:** Once steaming is complete, carefully remove the blender jar. Use the spatula to transfer the steamed ingredients from the steaming basket directly into the blender jar.
2. **Add Liquid (Optional):** For desired consistency, add a small amount of breast milk, formula, or purified water.
3. **Secure Lid:** Ensure the blender jar lid is securely fastened.
4. **Select Blend Function:** On the control panel, select the 'Blend' function.
5. **Pulse/Blend:** Use short pulses or continuous blending until the desired puree consistency is achieved.

Your browser does not support the video tag.

Video: This video demonstrates the process of making a banana puree using a baby food maker, from preparing the fruit to blending it into a smooth consistency.

Auto Cook Function (Steam & Blend)

The auto cook function allows for steaming and blending in one continuous cycle, saving time and effort.

1. Follow steps 1-4 for Steaming Food.
2. Select the 'Auto Blend' function on the control panel.
3. The appliance will automatically steam the ingredients and then blend them to a smooth puree.

Reheat and Defrost

The Bubos Baby Food Maker can also reheat and defrost baby food. Place the food in the blender jar (without the steaming basket), select the appropriate function, and set the desired time.

Sterilize Function

Use the sterilize function to sanitize bottles, pacifiers, or other small baby items. Place items in the steaming basket, add water to the tank, and select 'Sterilize'.

Maintenance and Cleaning

Regular cleaning ensures hygiene and extends the life of your appliance.

- **Daily Cleaning:** After each use, disassemble the blender jar, lid, steaming basket, and blade. Wash these parts with

warm soapy water. The bowl and blade are dishwasher-safe.

- **Water Tank:** The steam tank can be opened completely for easy cleaning, preventing rust, mold, and bacteria buildup. Regularly clean the water tank to prevent mineral deposits.
- **Main Unit:** Wipe the main unit with a damp cloth. Do not immerse the main unit in water.
- **Storage:** Ensure all parts are completely dry before reassembling and storing the appliance in a cool, dry place.

Troubleshooting

Common Issues and Solutions

Problem	Possible Cause	Solution
Appliance does not turn on.	Not plugged in, blender jar not correctly seated, water tank lid not closed.	Check power connection. Ensure blender jar is locked in place. Close water tank lid securely.
Steaming cycle stops prematurely.	Water tank is empty.	Refill the water tank with distilled or purified water. The appliance has an automatic shut-off for safety.
Food not blending smoothly.	Ingredients too large, insufficient liquid, overfilling.	Chop ingredients into smaller pieces. Add more liquid (breast milk, formula, or water). Do not overfill the blender jar.
"E3" error code on screen.	Indicates dry burning (water tank empty).	Add water to the steam tank. The heater will automatically shut off to prevent damage.

Product Specifications

- **Brand:** B Bubos
- **Model Number:** BU-F0701
- **Color:** Clear
- **Product Dimensions:** 22.86 x 25.4 x 22.86 cm
- **Item Weight:** 210 g
- **Power/Wattage:** 300.0 Watts
- **Voltage:** 220 Volts
- **Material:** Plastic
- **Number of Speeds:** 1
- **Special Features:** Built-in Grinder
- **Care Instructions:** Bowl and blade are dishwasher-safe.

Warranty and Support

For warranty information or product support, please contact the seller directly. Refer to your purchase documentation for specific warranty terms and contact details.
Typically, manufacturers offer a limited warranty against defects in materials and workmanship. Keep your proof of purchase for any warranty claims.

© 2026 B Bubos. All rights reserved.
For further assistance, please contact customer support.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question