

VTech VT1301-2

VTech VT1301-2 Twin Cordless Phone User Manual

Model: VT1301-2

INTRODUCTION

This manual provides comprehensive instructions for setting up, operating, and maintaining your VTech VT1301-2 Twin Cordless Phone system. Please read this manual thoroughly before using your new phone to ensure proper functionality and to take full advantage of its features.

The VTech VT1301-2 is a DECT-compliant twin cordless phone system designed for clear communication and ease of use. It features internal calls between handsets, 3-way conference calling, a 20-name and number phonebook, caller ID display, and multiple ringer melodies.

PACKAGE CONTENTS

Ensure all items are present in your package:

- Two (2) Cordless Handsets
- Two (2) Handset Chargers (Bases)
- Two (2) Power Adapters
- One (1) Telephone Line Cord
- Rechargeable Batteries (pre-installed or separate)
- This User Manual



Image: Two VTech VT1301-2 cordless handsets, red and white, resting on their charging bases. This shows the complete twin phone system.



Image: Power adapter and telephone line cord for the VTech VT1301-2 phone system. These are essential accessories for connecting and powering the device.

SETUP

1. Battery Installation and Charging

1. Open the battery compartment cover on the back of each handset.

2. Insert the supplied rechargeable batteries, observing the polarity markings (+ and -).
3. Close the battery compartment cover.
4. Place each handset onto its respective charging base. Ensure the "CHARGE" indicator (if present) illuminates, indicating proper charging.
5. Allow the handsets to charge for at least 12-16 hours before initial use to ensure optimal battery performance.



Image: Rear view of two VTech VT1301-2 cordless handsets on their charging bases, showing power and phone line connections. This illustrates where the power adapter and telephone line cord connect to the base unit.

2. Connecting the Base Unit

1. Connect one end of the telephone line cord to the TEL LINE jack on the main charging base.
2. Connect the other end of the telephone line cord to a telephone wall jack.
3. Connect the small end of the power adapter to the POWER jack on the main charging base.
4. Plug the large end of the power adapter into a standard electrical outlet.
5. For the second charging base, connect its power adapter to the POWER jack and plug it into an electrical outlet. This base does not require a telephone line connection.

Important:

- Use only the supplied power adapters and telephone line cord.
- Do not connect the telephone line cord to the second charging base.
- Position the base unit away from other electrical appliances for optimal performance.

OPERATING INSTRUCTIONS

Handset Layout and Keys





Image: Close-up view of a VTech VT1301-2 cordless handset, showing the display and keypad. This highlights the various buttons and screen for user interaction.

- **MENU/OK:** Accesses the menu, confirms selections.
- **TALK:** Makes or answers a call, retrieves a call waiting call.
- **OFF:** Ends a call, returns to idle mode.
- **MUTE/DELETE:** Mutes the microphone during a call, deletes characters or entries.
- **REDIAL/CID:** Displays the Caller ID list, redials the last number.
- **▲/▼ (Navigation Keys):** Scrolls through menus, adjusts volume.
- **Speakerphone Key:** Toggles speakerphone on/off.
- **Numeric Keypad (0-9, *, #):** Enters numbers and characters.
- **FLASH:** Used for network services like call waiting.

Making and Answering Calls

- **To Make a Call:**
 1. Press **TALK** or the **Speakerphone Key**.
 2. Dial the phone number.
 3. Press **OFF** to end the call.
- **To Answer a Call:**
 1. When the phone rings, press **TALK** or the **Speakerphone Key**.
 2. Press **OFF** to end the call.

Internal Calls (Intercom)

You can make internal calls between the two handsets.

1. From an idle handset, press the **Intercom Key** (often represented by a phone icon or specific menu option).
2. The other handset will ring.
3. To answer, the other handset user presses **TALK**.
4. To end the intercom call, either handset user presses **OFF**.

Phonebook

The phonebook stores up to 20 names and numbers.

- **To Add an Entry:**
 1. Press **MENU/OK**.
 2. Scroll to "PHONEBOOK" and press **MENU/OK**.
 3. Select "ADD NEW" and press **MENU/OK**.
 4. Enter the name using the keypad. Press **MENU/OK**.

5. Enter the number. Press **MENU/OK** to save.

- **To Dial from Phonebook:**

1. Press **MENU/OK**.
2. Scroll to "PHONEBOOK" and press **MENU/OK**.
3. Scroll to the desired entry.
4. Press **TALK** to dial.

MAINTENANCE

Cleaning

- Clean the phone and base unit with a soft, damp cloth.
- Do not use cleaning sprays or liquid cleaners.
- Ensure the phone is unplugged from the wall outlet before cleaning.

Battery Care

- Use only the supplied rechargeable batteries.
- If the phone will not be used for an extended period, remove the batteries to prevent leakage.
- Dispose of old batteries responsibly according to local regulations.

TROUBLESHOOTING

Problem	Solution
No dial tone.	<ul style="list-style-type: none">• Ensure the telephone line cord is securely connected to the base unit and the wall jack.• Check if the power adapter is properly connected to the base unit and a working electrical outlet.• Test with another phone to confirm the telephone line is active.
Handset does not charge.	<ul style="list-style-type: none">• Ensure the handset is correctly placed on the charging base.• Verify the charging base's power adapter is plugged in.• Clean the charging contacts on both the handset and base with a dry cloth.• Check if the batteries are inserted correctly.
Poor sound quality or static.	<ul style="list-style-type: none">• Move the handset closer to the base unit.• Relocate the base unit away from other electronic devices (e.g., microwaves, Wi-Fi routers).• Check for any physical obstructions between the handset and base.

Problem	Solution
Cannot make or receive calls.	<ul style="list-style-type: none"> • Ensure the handset is registered to the base unit (refer to the full manual for registration steps if needed). • Check the telephone line connection. • Verify the phone line is active.

SPECIFICATIONS

- **Model:** VT1301-2
- **Brand:** VTech
- **Type:** Cordless DECT Phone System
- **Handsets:** Twin (2)
- **Phonebook Capacity:** 20 names and numbers
- **Caller ID:** 10 caller number display
- **Redial Memory:** 5 last numbers
- **Ringer Melodies:** 10 (5 polyphonic, 5 standard)
- **Intercom:** Yes, between handsets
- **Conference Call:** 3-way
- **Range:** Up to 300m outdoor (line of sight)
- **Radiation Mode:** Ultra-low Radiation Mode
- **Display:** Large character and backlit LCD
- **Power Source:** Corded Electric (for base units)
- **Material:** Plastic



Image: VTech VT1301-2 cordless handset on its charging base, with a ruler indicating a height of 7.5 inches (19 cm). This provides a visual reference for the product's dimensions.

WARRANTY AND SUPPORT






For warranty information and technical support, please refer to the warranty card included in your product packaging


or visit the official VTech website. Keep your purchase receipt as proof of purchase.

VTech Official Website: www.vtechphones.com

© 2023 VTech. All rights reserved. Information in this manual is subject to change without notice.

Related Documents - VT1301-2

	<p>VTech CS5119 Series DECT 6.0 Cordless Telephone Abridged User's Manual</p> <p>This abridged user's manual provides essential installation, operation, and safety instructions for the VTech CS5119, CS5119-2, and CS5119-3 DECT 6.0 cordless telephones. Learn how to set up your phone, use features like Caller ID, Call Block, Phonebook, and troubleshoot common issues.</p>
	<p>VTech CS2050/CS2051/CS2052/CS2053 Quick Start Guide</p> <p>Comprehensive guide to setting up and using your VTech CS2050, CS2051, CS2052, or CS2053 cordless phone system, including safety instructions, product registration, warranty information, and feature setup.</p>
	<p>VTech DS6101 Accessory Handset User Manual</p> <p>This user manual provides instructions for setting up, registering, and using the VTech DS6101 accessory handset with the DS6151/DS6151-11 telephone base. It covers battery installation and charging, belt clip and headset usage, handset registration and replacement, and important safety information.</p>
	<p>VTech CS6114 DECT 6.0 Cordless Telephone User Manual</p> <p>Comprehensive user manual for the VTech CS6114 DECT 6.0 cordless telephone, covering setup, features, operations, troubleshooting, and safety instructions.</p>
	<p>VTech CS6120-2/CS6124 DECT 6.0 Cordless Phone User Manual</p> <p>User manual for VTech CS6120-2 and CS6124 cordless phones. Covers setup, operation, features, answering system, and troubleshooting. Includes ENERGY STAR® information.</p>




vttech®
User's manual
CS1100-O
www.hkphones.vtech.com

[VTech CS1100-O Cordless Phone User Manual](#)

Comprehensive user manual for the VTech CS1100-O cordless phone, covering setup, operation, features, settings, troubleshooting, and warranty information.

Documents - VTech – VT1301-2




vttech®
User's manual
Models: VT1301/
VT1301-2
http://hkphones.vtech.com

[\[pdf\] User Manual Installation Guide Instructions Guide Warranty](#)

User s manual Alco S Pte Ltd VTech Phones Use yoUr pHONE 14 4 Switch ON OFF the Handset 2 IM por
T an safe y l ns r U c TI ons 3 The correct disposal of your old appliance battery will help prevent potential
negative consequences for environment and human health Jul 16 2013 · Models VT1301 h t p k o n e v m
Table contents 1 Important safety instructions SET UP THE Power adaptor base Charger Telephone cord
AAA NiMH rechargeable batteries Warranty card X HK ENG 20130716 Final hkphones vtech assets data
english products 42687F75 1929 45F4 8170 70CBC1657D6B guide A3DF242E FFEB 4E95 AEA3
C684EC6AEDF5 B5A3E7F6 5B31 4DEE 88F7 21A46028B88F 80 5010F9E2 0120 4940 A53D
0ACADC34BD5C DCFE8615 D11F 4E20 AA3B F95CB19A1503
User s manual Models: VT1301/ **VT1301-2** h t t p : // h k p h o n e s . v t e c h . c o m
Table of contents 1. Important safety instructions..... 1 2.
SET UP THE TELEPHONE..... 3 2.1
Package C...

lang:en **score:34** filesize: 8.93 M page_count: 41 document date: 2013-07-16



vttech®
用戶手冊
型號: VT1301/
VT1301-2
http://hkphones.vtech.com

[\[pdf\] User Manual Guide](#)

hkphones vtech VTech 2 5 1 aaa 3 hs 13 4
VT1301 X HK CN manual 20130716 Final assets data chinese products A3DF242E FFEB 4E95 AEA3
C684EC6AEDF5 guide B5A3E7F6 5B31 4DEE 88F7 21A46028B88F
VT1301/ **VT1301-2** h t t p : // h k p h o n e s . v t e c h . c o m 1.
.....1 2.
.....2 2.1
.....
lang:i-klingon **score:25** filesize: 9.72 M page_count: 36 document date: 2013-07-16