

[Manuals.plus](#) /

> [ATIMO](#) /

> ATIMO LED Multi-Function Waterproof Watch User Manual

ATIMO 8011448824679

ATIMO LED Multi-Function Waterproof Watch User Manual

Model: 8011448824679

1. PRODUCT OVERVIEW

The ATIMO LED Multi-Function Waterproof Watch is designed for children, offering a durable and feature-rich timepiece suitable for various activities. It features a precise Japanese movement, comfortable PU resin strap, and a highly transparent, pressure-tolerant resin glass. This watch is built to withstand daily use and is water-resistant up to 50 meters.





Figure 1.1: Front view of the ATIMO LED Multi-Function Waterproof Watch, showcasing its red and black design with digital and analog displays.

1.1 Key Features

- Japanese Movement for precise timekeeping.
- Durable PC Material Shell.
- Highly Transparent Resin Glass, pressure-tolerant.
- 50M Water Resistance.
- Stainless Steel Buckle.
- Imported EL Lighting Chip for backlight.
- Dual Time Display.
- Alarm Clock function.
- Stop Watch function.
- Calendar Date Window.

1.2 Watch Components

FUNCTION INTRODUCTION



Figure 1.2: Diagram illustrating the various buttons and components of the watch, including the Backlight, Mode, Start/Stop, Reset buttons, and the Crown.

1.3 Multi-Function Overview

MULTI-FUNCTION



Figure 1.3: Overview of the watch's multi-functions, including LED backlight, alarm, stopwatch, date display, 12/24 hour format, and waterproof capabilities.

2. SETUP

2.1 Initial Power On

The watch comes with a pre-installed Lithium Metal battery. It should be ready for use upon unboxing. If the display is blank, ensure the battery insulation tab (if present) has been removed. If the issue persists, the battery may need replacement (refer to Section 4.2).

2.2 Setting Time and Date

1. In normal time display mode, press the **MODE** button repeatedly until the time setting mode is activated (usually indicated by flashing digits).
2. Use the **RESET** button to cycle through the settings (seconds, minutes, hours, month, date, day of week).

3. Use the **START/STOP** button to adjust the flashing value upwards.
4. Once all settings are correct, press the **MODE** button again to exit the setting mode and return to normal time display.

2.3 Setting 12/24 Hour Format

While in time setting mode (as described in 2.2), when the hour digits are flashing, press the **START/STOP** button to toggle between 12-hour (with AM/PM indicator) and 24-hour formats.

3. OPERATING INSTRUCTIONS

3.1 Using the Backlight

The watch features an imported EL Lamp for clear visibility in low-light conditions.

1. Press the **LIGHT** button (typically on the top-left side of the watch).
2. The display will illuminate for a few seconds, allowing you to read the time clearly at night.

BACKLIGHT SETTING

Use imported EL Lamp. Press the 'LIGHT' button to tell time clearly at night.



NORMAL DISPLAY MODE



LED LIGHT DISPLAY MODE

Figure 3.1: Comparison showing the watch display in normal mode versus with the LED backlight activated.

3.2 Using the Alarm Function

1. Press the **MODE** button until you reach the alarm setting mode (often indicated by 'AL' or an alarm icon).
2. Use the **RESET** button to select the hour or minute to set.
3. Use the **START/STOP** button to adjust the value.
4. Press **MODE** to confirm and exit.
5. To activate/deactivate the alarm, in alarm mode, press **START/STOP** to toggle the alarm on/off. An alarm icon will appear when active.

3.3 Using the Stopwatch

1. Press the **MODE** button until you reach the stopwatch mode (often indicated by 'ST' or 'CHRONO').
2. Press the **START/STOP** button to start the stopwatch.
3. Press **START/STOP** again to pause/resume.

4. Press the **RESET** button to reset the stopwatch to zero.

4. MAINTENANCE

4.1 Water Resistance Guidelines

The ATIMO watch is rated 50M water resistant, meaning it can withstand splashes, rain, showering, swimming, and white water rafting. However, it is important to follow these guidelines:

- **DO NOT PULL OUT THE BUTTON UNDERWATER.** Operating buttons underwater can compromise the water seal and lead to water ingress.
- Avoid long-time underwater activities, as this is not recommended despite the 50M rating.
- Avoid using the watch in extreme hot or cold temperatures, as this can shorten the watch's life.
- Too much water contact, especially hot water or steam, will shorten watch life.



Figure 4.1: The watch is suitable for activities like swimming and showering, but avoid operating buttons underwater.

4.2 Cleaning and Care

- Clean the strap regularly with a soft, damp cloth to remove dirt and sweat.
- Avoid using harsh chemicals or abrasive cleaners on the watch.
- Store the watch in a dry place when not in use.

4.3 Battery Replacement

The watch uses 1 Lithium Metal battery (included). When the display becomes dim or stops functioning, the battery may need replacement. It is recommended to have battery replacement performed by a qualified watch technician to ensure the water resistance seal is maintained.

5. TROUBLESHOOTING

Problem	Possible Cause	Solution
Display is blank or dim.	Low or dead battery.	Replace the battery.
Buttons are unresponsive.	Watch may be in a locked mode or internal issue.	Try pressing all buttons firmly. If unresponsive, the battery may be too low. If issue persists, contact support.
Water inside the watch.	Buttons operated underwater, seal compromised, or extreme temperature exposure.	Immediately stop using the watch. Seek professional repair to prevent further damage. Do not attempt to dry with heat.
Time is inaccurate.	Time not set correctly or low battery.	Re-set the time (refer to Section 2.2). If problem persists, replace battery.

6. SPECIFICATIONS

- **Model Number:** 8011448824679
- **Watch Case Diameter:** 44mm (1.58inch)
- **Watch Case Thickness:** 17mm (0.67inch)
- **Watch Case Material:** ABS Plastic
- **Watch Band Width:** 20mm (0.79inch)
- **Watch Band Material:** PU Rubber
- **Fit for Wrist Circumference:** 160mm-230mm (6.3-9.1inch)
- **Water Resistance:** 50M
- **Movement:** Japanese Quartz
- **Battery:** 1 Lithium Metal battery (included)
- **First Available Date:** August 21, 2018

7. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation provided at the time of purchase or contact the seller directly. ATIMO strives to provide quality products and support for its customers.

When contacting support, please have your watch model number (8011448824679) and purchase details readily available.

