Signature Design by Ashley U5240247

Signature Design by Ashley Hallstrung U5240247 Power Reclining Sofa User Manual

Model: U5240247

Product Overview

The Signature Design by Ashley Hallstrung Power Reclining Sofa is designed for comfort and convenience. This 2-seat power reclining sofa features adjustable headrests and integrated USB charging ports. It is upholstered with top-grain leather on seating areas and armrests, with faux leather on the back and sides. The sofa provides an extended ottoman for lounging and a high-back design for support.



Figure 1: Front view of the Hallstrung Power Reclining Sofa, showcasing its dark brown leather upholstery and two reclining seats.

Setup Instructions

Assembly is required for this power reclining sofa. Please follow these steps carefully to ensure proper setup and functionality.

1. **Unpacking:** Carefully remove all components from the packaging. Inspect all parts for any damage. Retain packaging materials until you are satisfied with the product.
2. **Attach Backs:** Align the metal brackets on the sofa backrests with the corresponding receivers on the base of the sofa. Push down firmly until the backrests lock into place.
3. **Connect Power:** Locate the power cords extending from the sofa base. Connect these cords to the power supply unit, and then plug the power supply into a standard electrical outlet. Ensure all connections are secure.
4. **Test Functionality:** Once assembled and powered, test the reclining and headrest functions using the control buttons.



Figure 2: Rear view of the sofa, illustrating the power cords that need to be connected during setup.

Operating Instructions

The Hallstrung Power Reclining Sofa offers easy-to-use power controls for personalized comfort.

- **Power Recline:** Use the one-touch power control buttons located on the side of each seat to recline the sofa. Press the forward button to extend the footrest and recline the backrest. Press the backward button to return to the upright position.
- **Adjustable Headrests:** The Easy View power adjustable headrests allow you to customize your head and neck support. While reclining, use the dedicated headrest control buttons to adjust the angle of the headrest for optimal viewing or relaxation.
- **USB Charging Ports:** Each power control panel includes a USB charging port. Connect your compatible devices (e.g., cell phones, tablets) to these ports for convenient charging while you relax.



Figure 3: Detail of the power control panel, showing the buttons for reclining and the integrated USB charging port.

Your browser does not support the video tag.

Video 1: An official product video from Ashley Furniture demonstrating the features and overall appearance of the Hallstrung Living Room collection, including the power reclining sofa.

Maintenance

Proper care and maintenance will extend the life and appearance of your Hallstrung Power Reclining Sofa.

- **Regular Cleaning:** Dust the leather upholstery regularly with a soft, dry cloth. For light spills, wipe immediately with a clean, damp cloth. Avoid harsh chemicals or abrasive cleaners.
- **Leather Care:** For deeper cleaning or conditioning, use a leather cleaner and conditioner specifically designed for top-grain leather. Follow the product instructions carefully. Test any cleaning product on an inconspicuous area first.
- **Avoid Direct Sunlight:** Prolonged exposure to direct sunlight can cause leather to fade or dry out. Position your sofa away from direct sunlight or use curtains/blinds to protect it.

- **Power Mechanism:** Periodically check all power connections to ensure they are secure. Avoid placing heavy objects on the footrest when it is extended.

Troubleshooting

If you encounter issues with your sofa, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Sofa does not recline or headrest does not adjust.	No power, loose connection, or power supply issue.	Ensure the power cord is securely plugged into the wall outlet and the sofa's power supply. Check if the wall outlet is functional. Verify all internal connections are firm.
Grinding noise during operation.	Obstruction in mechanism or component wear.	Inspect the reclining mechanism for any foreign objects. If the noise persists, contact customer support.
USB port not charging devices.	Device incompatibility or power issue.	Ensure the sofa is powered on. Try a different USB cable or device to rule out device-specific issues.

Specifications

Detailed specifications for the Hallstrung Power Reclining Sofa:

Feature	Detail
Brand	Signature Design by Ashley
Model Number	U5240247
Product Dimensions (D x W x H)	40"D x 86"W x 44"H
Item Weight	256 pounds
Seating Capacity	2
Weight Limit	250 pounds per seat
Upholstery Fabric Type	Leather (Top-grain on seating, faux leather on back/sides)
Frame Material Type	Engineered Wood
Seat Fill Material	Foam
Back Cushion Removability	Attached
Additional Features	Power Recline, Adjustable Headrests, USB Charging Ports
Color	Chocolate
UPC	024052498172



Figure 4: Dimensional drawing of the sofa, indicating its width (86 inches), depth (40 inches), and height (44 inches).

Warranty Information

This product is covered by a one-year limited manufacturer's warranty. This warranty typically covers defects in materials and workmanship under normal household use. For specific details regarding coverage, limitations, and how to make a claim, please refer to the warranty documentation included with your purchase or contact Signature Design by Ashley customer support.

Customer Support

For further assistance, technical support, or warranty claims, please contact Signature Design by Ashley customer service. You can find contact information on the official Signature Design by Ashley website or through your retailer.

Online Resources: For additional information and support, visit the Signature Design by Ashley Store.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question