

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Orno](#) /

› [Orno AE-13114 Plug-in Dimmer Switch User Manual](#)

## Orno AE-13114

# Orno AE-13114 Plug-in Dimmer Switch User Manual

Model: AE-13114

## INTRODUCTION

This manual provides essential instructions for the safe and effective use of your Orno AE-13114 Plug-in Dimmer Switch. Please read it thoroughly before operating the device and retain it for future reference.

## SAFETY INFORMATION

Always observe the following safety precautions:

- Ensure the dimmer is used with compatible dimmable light sources only.
- Do not exceed the maximum load of 280W.
- This device is designed for indoor use only.
- Keep out of reach of children.
- Do not disassemble or modify the device.
- The protective clip provides contact protection, ensuring safe use.

## PRODUCT OVERVIEW

The Orno AE-13114 is a compact plug-in dimmer switch designed for easy control of dimmable lighting. It features a rotary control for stepless adjustment of light intensity.



**Figure 1:** Front view of the Orno AE-13114 Plug-in Dimmer Switch, showing the rotary control knob and the integrated power plug.



**Figure 2:** Back view of the Orno AE-13114 Plug-in Dimmer Switch, displaying the product label with model number and electrical specifications, along with the socket for connecting a lamp.

## SETUP

- 1. Unpack:** Carefully remove the dimmer switch from its packaging.
- 2. Connect Lamp:** Ensure your lamp is unplugged. Plug the lamp's power cord into the socket on the front of the Orno AE-13114 dimmer switch.
- 3. Plug into Wall Outlet:** Insert the Orno AE-13114 dimmer switch into a standard 230V wall outlet. No complex installation is required.
- 4. Verify Compatibility:** Confirm that the light source in your lamp is dimmable and does not exceed the dimmer's maximum load of 280W.

## OPERATING INSTRUCTIONS

The Orno AE-13114 features a simple rotary control for adjusting light intensity.

- Turn On/Off:** Rotate the knob clockwise from the 'OFF' position until you hear a click and the light turns on. To turn off, rotate the knob counter-clockwise until it clicks into the 'OFF' position.
- Adjust Brightness:** Once the light is on, continue rotating the knob clockwise to increase brightness or counter-clockwise to decrease brightness. The dimmer provides stepless adjustment from full light output to complete extinction.
- Compatible Devices:** This dimmer is suitable for controlling floor lamps, table lamps, bedside lamps, and other devices equipped with dimmable light sources.

## MAINTENANCE

To ensure the longevity and proper functioning of your dimmer switch:

- Cleaning:** Disconnect the dimmer from the power outlet before cleaning. Wipe the surface with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- Storage:** If storing the device for an extended period, keep it in a cool, dry place away from direct sunlight.
- Inspection:** Periodically check the device and its connections for any signs of damage. If damage is observed, discontinue use immediately.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
Light does not turn on.	Dimmer not plugged in correctly. Lamp not plugged into dimmer. Light bulb is faulty or not dimmable. Dimmer knob is in 'OFF' position.	Ensure dimmer is securely plugged into the wall outlet. Ensure lamp is securely plugged into the dimmer. Replace the light bulb or ensure it is a dimmable type. Rotate the knob clockwise past the 'OFF' click.
Light flickers or hums.	Incompatible light bulb (not dimmable or incorrect type). Load exceeds maximum wattage.	Use only dimmable light bulbs compatible with phase-cut dimmers. Ensure total wattage of connected lamps does not exceed 280W.
Dimmer feels warm.	Normal operation, or excessive load.	A slight warmth is normal. If it feels excessively hot, disconnect immediately and check total wattage of connected lamps. Ensure it does not exceed 280W.

## SPECIFICATIONS

Model	AE-13114
Brand	Orno
Operating Voltage	230 Volts

<b>Maximum Load</b>	280W
<b>Minimum Load</b>	40W
<b>Dimensions (L x W x H)</b>	5.6 x 9.6 x 7.9 cm
<b>Weight</b>	130 grams
<b>Material</b>	Polycarbonate
<b>Country of Origin</b>	China

*Note: Specifications are subject to change without prior notice.*


## WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the documentation provided with your purchase or contact your retailer. Keep your proof of purchase for any warranty claims.

Manufacturer: ORNO-LOGISTIC Sp. z o.o., ul. Rolników 437, 44-141 Gliwice, POLAND

© 2025 Orno. All rights reserved.

## Related Documents - AE-13114

	<p><a href="#"><u>ORNO OR-AE-13110 Desktop Extension Socket with Electrical Opening - User Manual</u></a></p> <p>Comprehensive user manual for the ORNO OR-AE-13110 desktop extension socket. This retractable, motorized socket integrates seamlessly into desks, offering 3 Schuko power outlets, 1 HDMI port, and 2 RJ45 ports. The manual provides detailed safety instructions, installation guidance, technical specifications, and environmental information for responsible use.</p>
	<p><a href="#"><u>Ръководство за потребителя и инструкции за безопасност за мини детектор за дим ORNO OR-DC-628</u></a></p> <p>Подробно ръководство за потребителя и инструкции за безопасност за мини детектор за дим ORNO OR-DC-628 с вградена батерия, обхващащо инсталация, експлоатация, отстраняване на неизправности и изхвърляне.</p>
	<p><a href="#"><u>ORNO CALYPSO II OR-DB-QS-159 Wireless Doorbell User Manual</u></a></p> <p>User manual for the ORNO CALYPSO II OR-DB-QS-159 wireless doorbell, providing safety information, specifications, and usage details for home and commercial applications.</p>

