



Manuals.plus /

› **Manfrotto** /

› Manfrotto Pro Light LW-99 V2 Professional Photography Roller Bag User Manual

Manfrotto LW-99 V2

Manfrotto Pro Light LW-99 V2 Professional Photography Roller Bag User Manual

Model: LW-99 V2

INTRODUCTION

This manual provides detailed instructions for the Manfrotto Pro Light LW-99 V2 Professional Photography Roller Bag. This rolling organizer is designed for secure and convenient transport of lighting equipment, offering protection against impacts, dust, and rain. It features a lightweight design and a modular interior for versatile storage.



Image 1: Front view of the Manfrotto Pro Light LW-99 V2 Professional Photography Roller Bag, showcasing its robust exterior and main compartment zipper.

KEY FEATURES

- **Camera Protection System:** Designed to absorb shocks and protect contents from impacts.
- **Lightweight Construction:** Utilizes materials that reduce overall weight for easier transport.
- **Weather Resistance:** Can be sealed to protect against dust and rain.
- **Modular Interior:** Includes 6 interchangeable dividers for customizable organization of gear.
- **Reinforced Handles:** For secure lifting and carrying.
- **Sliding Rails:** Bumpers on the back function as sliding rails for added protection and stability.

SETUP AND INITIAL CONFIGURATION

1. **Unpacking:** Carefully remove the roller bag from its packaging. Inspect for any shipping damage.
2. **Divider Adjustment:** The bag comes with 6 interchangeable dividers. Open the main compartment and arrange the dividers to create custom compartments for your specific lighting equipment, cameras, and

accessories. The dividers attach securely with hook-and-loop fasteners.

3. **Handle Extension:** To extend the retractable handle, locate the release button on the handle grip and pull upwards until it locks into position. Ensure it is fully extended before rolling the bag.
4. **Side Straps:** The side straps connected to the top flap are designed to secure additional items or compress the bag. Adjust their length as needed.



Image 2: Side view of the Manfrotto Pro Light LW-99 V2 Roller Bag, showing the retractable handle and side profile.

OPERATING INSTRUCTIONS

Packing Your Gear

- Place heavier items at the bottom and center of the bag for better balance.
- Utilize the adjustable dividers to snugly fit each piece of equipment, preventing movement during transit.
- Ensure all zippers are fully closed before moving the bag to protect contents from dust and moisture.

Transporting the Bag

- **Rolling:** Extend the retractable handle and tilt the bag to engage the wheels. Roll the bag on smooth surfaces.
- **Carrying:** For stairs or uneven terrain, retract the handle and use the reinforced top or side handles to lift and carry the bag.
- **Protection:** The sliding rails on the back provide protection when the bag is laid flat or dragged over small obstacles.

CARE AND MAINTENANCE

- **Cleaning:** Wipe the exterior fabric with a damp cloth and mild soap. Do not use harsh chemicals or abrasive cleaners. Allow to air dry completely.
- **Zippers:** Periodically clean zippers with a small brush to remove dust and debris. Lubricate with a silicone-based spray if they become stiff.
- **Wheels:** Check wheels regularly for debris accumulation. Clean as needed to ensure smooth rolling.
- **Storage:** Store the bag in a cool, dry place away from direct sunlight when not in use.
- **Dividers:** The internal dividers can be removed and spot cleaned if necessary.

TROUBLESHOOTING

Problem: Retractable handle is stuck or difficult to extend/retract.

Solution: Ensure the release button is fully depressed. Check for any obstructions in the handle mechanism. Avoid forcing the handle; apply gentle, even pressure.

Problem: Zippers are stiff or difficult to operate.

Solution: Clean the zipper teeth with a small brush to remove any dirt or grit. Apply a small amount of zipper lubricant (e.g., silicone spray or wax) to the teeth.

Problem: Bag does not roll smoothly.

Solution: Inspect the wheels for tangled hair, string, or other debris. Remove any obstructions. Ensure the bag is not overloaded beyond its capacity, which can strain the wheels.

Problem: Internal dividers do not stay in place.

Solution: Ensure the hook-and-loop fasteners on the dividers and interior lining are clean and free of lint. Press firmly to secure them. If the fasteners are worn, contact support for replacement options.

SPECIFICATIONS

Feature	Detail
Model	LW-99 V2
Brand	Manfrotto
Closure Type	Zipper
Strap Type	Shoulder (for additional carrying options)
Wheel Type	In-line skate
Handle Type	Retractable
Number of Compartments	4 (main, plus additional pockets)
Color	Black
Material Type	Polyester
Included Components	Manfrotto Pro Light Rolling Lighting Gear Organizer V2, 6 x Dividers
UPC	719821414049

WARRANTY INFORMATION

The Manfrotto Pro Light LW-99 V2 Professional Photography Roller Bag comes with a **Limited 2-Year Warranty**. This warranty can be extended by an additional 3 years upon product registration. Please refer to the official Manfrotto website for detailed warranty terms, conditions, and registration procedures. Keep your proof of purchase for warranty claims.

CUSTOMER SUPPORT

For further assistance, technical support, or inquiries regarding your Manfrotto Pro Light LW-99 V2 Roller Bag, please visit the official Manfrotto website or contact their customer service department.

- **Online Support:** Manfrotto Support Website
- **Product Registration:** Register your product to extend your warranty and receive updates.

