



Manuals.plus /

› Flash Furniture /

› Flash Furniture Sorrento Home and Office Task Chair DS-512C-BRN-GG User Manual

## Flash Furniture DS-512C-BRN-GG

# Flash Furniture Sorrento Home and Office Task Chair User Manual

Model: DS-512C-BRN-GG

## PRODUCT OVERVIEW

The Flash Furniture Sorrento Home and Office Task Chair is designed for comfort and functionality in both home and office environments. It features a brown LeatherSoft upholstery with tufted padding on the seat and back. LeatherSoft is a blend of leather and polyurethane, offering softness and durability. The chair includes a 360-degree swivel function and pneumatic seat height adjustment for personalized comfort and ease of use.

Key features include:

- Soft and durable LeatherSoft upholstered back and seat with biscuit tufting.
- Full swivel seat for easy access to work surfaces.
- Pneumatic seat height adjustment for optimal positioning.
- Low back design to support the lower back.
- 5-star black metal base with dual-wheel casters for mobility.



Image: The Flash Furniture Sorrento Home and Office Task Chair in brown LeatherSoft, showcasing its design and features.

## SETUP AND ASSEMBLY

This product requires assembly. Please refer to the assembly instructions included in the product packaging for detailed steps. Ensure all components are present before beginning assembly. It is recommended to assemble the chair on a soft, clean surface to prevent damage.

# 32"- 36.5" H



24" D

24" W

Image: Diagram illustrating the dimensions of the Flash Furniture Sorrento Task Chair: 24"D x 24"W x 32-36.5"H.

## OPERATING INSTRUCTIONS

### Seat Height Adjustment

To adjust the seat height, locate the pneumatic adjustment lever typically found under the right side of the seat. While seated, pull the lever upwards to lower the seat. To raise the seat, lift your weight off the seat and pull the lever upwards. Release the lever at the desired height to lock the position.

### Swivel Function

The chair is equipped with a 360-degree swivel mechanism, allowing for full rotation. This feature provides easy access to various areas of your workspace without needing to reposition the entire chair.

## Mobility

The 5-star black metal base with dual-wheel casters allows for smooth movement across hard floor surfaces. Ensure the casters are clean and free of debris for optimal performance.



Image: Detailed view highlighting the quilted LeatherSoft upholstery, pneumatic seat height adjustment lever, and dual-wheel casters on the 5-star metal base.

## MAINTENANCE AND CARE

Proper care will extend the life and appearance of your chair.

- **Cleaning LeatherSoft Upholstery:** The LeatherSoft upholstery can be cleaned quickly with water and a neutral detergent. Apply a small amount to a clean cloth and gently wipe the soiled area. Avoid abrasive cleaners or harsh chemicals.
- **Caster Maintenance:** Periodically check the dual-wheel casters for hair, dust, or other debris that may impede smooth movement. Clean as necessary.

- **General Inspection:** Regularly inspect all screws and bolts to ensure they are tight. Retighten if necessary.



Image: A close-up view of the quilted brown LeatherSoft upholstery, showing the texture and stitching.

## TROUBLESHOOTING

If you encounter any issues with your chair, please review the following common solutions:

- **Chair not adjusting height:** Ensure the pneumatic lever is fully engaged. If the issue persists, the gas lift may need replacement.
- **Casters not rolling smoothly:** Check for obstructions (hair, dirt) in the caster wheels and remove them. Ensure the casters are securely attached to the base.
- **Chair feels unstable:** Verify that all assembly screws and bolts are tightened securely.

For further assistance, please contact Flash Furniture customer support.

## SPECIFICATIONS

<b>Brand:</b>	Flash Furniture
<b>Model Number:</b>	DS-512C-BRN-GG
<b>Color:</b>	Brown Leathersoft
<b>Material:</b>	Leather/Faux Leather, Plastic, Foam, Metal
<b>Product Dimensions (D x W x H):</b>	24"D x 24"W x 36.5"H
<b>Seat Height:</b>	Adjustable, 20-22.5"
<b>Seat Depth:</b>	17"
<b>Back Size (W x H):</b>	17.5"W x 14.5"H
<b>Item Weight:</b>	17 Pounds
<b>Maximum Weight Recommendation:</b>	250 Pounds
<b>Assembly Required:</b>	Yes
<b>Recommended Uses:</b>	Office, Home Office/Study
<b>Certifications:</b>	Conforms to ANSI/BIFMA standard X5.1-17

## WARRANTY AND SUPPORT

This Flash Furniture product comes with a **1-year limited manufacturer's warranty**. For warranty claims, technical support, or any inquiries regarding your Sorrento Home and Office Task Chair, please contact Flash Furniture customer service directly. Refer to your product packaging for specific contact information or visit the official Flash Furniture website.

## PRODUCT VIDEO

Your browser does not support the video tag.

Video: An official Flash Furniture video showcasing the features and design of the Sorrento Home and Office Task Chair. This video demonstrates the chair's swivel, height adjustment, and overall aesthetic.