

Mattel FYX43

Mattel Disney Pixar Cars Turbo Racers Assortment Instruction Manual

Model: FYX43

1. INTRODUCTION

Thank you for choosing the Mattel Disney Pixar Cars Turbo Racers Assortment. This manual provides essential information for the safe and enjoyable operation of your new toy vehicles. The assortment features popular characters from Disney Pixar's Cars 3, including Lightning McQueen, Dinoco Cruz Ramirez, Jackson Storm, and Danny Swervez. These vehicles are designed for pump-and-race action without the need for batteries.

Please read these instructions carefully before use and retain them for future reference.

2. SETUP

2.1 Unboxing

- Carefully remove the vehicle from its packaging.
- Dispose of all packaging materials responsibly.

2.2 Initial Inspection

- Inspect the vehicle for any visible damage or missing parts. If any issues are found, please contact customer support.
- No assembly is required for these vehicles.
- No batteries are required for operation.



Figure 2.1: Danny Swervez Turbo Racer vehicle, ready for play.

3. OPERATING INSTRUCTIONS

The Disney Pixar Cars Turbo Racers are designed for simple, kid-activated racing action. Follow these steps to operate your vehicle:

1. **Prepare the Vehicle:** Place the vehicle on a flat, smooth surface.
2. **Charge the Turbo Feature:** Firmly press down on the vehicle's spoiler multiple times. You will feel a resistance as the internal mechanism charges. Continue pressing until the spoiler is fully depressed and the vehicle is charged.
3. **Launch the Vehicle:** Release the vehicle on the flat surface. The stored energy will propel the car forward.

The vehicle is designed to speed off up to 10 feet when properly charged and released.



Figure 3.1: Pressing down on the spoiler to charge the vehicle.



Figure 3.2: Vehicle with spoiler extended, ready for launch.



Figure 3.3: Vehicle racing forward after release.

3.1 Official Product Video

Your browser does not support the video tag.

Video 3.1: Demonstration of the Disney Pixar Cars Turbo Racers, showing how to pump the spoiler and launch the vehicles for racing

action. This video features various characters from the assortment.

4. MAINTENANCE

4.1 Cleaning

- To clean the vehicle, wipe it with a soft, damp cloth.
- Do not use harsh chemicals, abrasive cleaners, or immerse the vehicle in water, as this may damage the product.

4.2 Storage

- Store the vehicle in a cool, dry place away from direct sunlight.
- Avoid storing in extreme temperatures.

5. TROUBLESHOOTING

5.1 Vehicle Not Moving or Moving Short Distances

- **Ensure Full Charge:** Verify that the spoiler has been fully depressed multiple times to adequately charge the internal mechanism.
- **Check for Obstructions:** Inspect the wheels and underside of the vehicle for any debris or obstructions that might hinder movement.
- **Surface Conditions:** Ensure the vehicle is being used on a flat, smooth, and clean surface. Uneven or carpeted surfaces can reduce performance.

6. SPECIFICATIONS

Feature	Detail
Product Dimensions	6.5 x 3.25 x 7.5 inches
Item Weight	5.6 ounces
Item Model Number	FYX43
Manufacturer Recommended Age	36 months - 7 years
Manufacturer	Mattel
ASIN	B07GSL13T5
Release Date	December 1, 2018

7. WARRANTY INFORMATION

Mattel products are manufactured to high-quality standards. For specific warranty details regarding your Disney Pixar Cars Turbo Racers Assortment, please refer to the warranty information provided with your product packaging or visit the official Mattel website. Warranty terms and conditions may vary by region.

8. CUSTOMER SUPPORT

If you have any questions, concerns, or require assistance with your Disney Pixar Cars Turbo Racers Assortment, please contact Mattel Customer Service. You can typically find contact information on the product packaging or by visiting the official Mattel website:

- **Mattel Official Website:** www.mattel.com

Please have your product model number (FYX43) and purchase details available when contacting support.

