

## WMF 0416510011

# WMF Kult Pro Blender 1400W Instruction Manual

Model: 0416510011

## 1. IMPORTANT SAFETY INSTRUCTIONS

---

Please read these instructions carefully before using your WMF Kult Pro Blender. Keep this manual for future reference.

- Always ensure the blender is placed on a stable, flat surface.
- The blender will only operate when the glass jug is correctly in place and the lid is securely closed. This is a built-in safety feature.
- Do not immerse the motor base in water or other liquids.
- Unplug the appliance from the power outlet before cleaning or when not in use.
- Keep hands and utensils out of the container while blending to reduce the risk of severe personal injury and/or damage to the blender.
- Blades are sharp. Handle with extreme care when cleaning.
- Do not blend hot liquids that exceed the maximum fill line to prevent overflow and scalding.

## 2. PRODUCT OVERVIEW AND COMPONENTS

---

The WMF Kult Pro Blender is designed for powerful and efficient blending. Familiarize yourself with its components:

- **Motor Base:** Made of Cromargan stainless steel, housing the 1400-watt motor.
- **Glass Jug:** 1.8-liter capacity with measurement markings.
- **Lid with Filling Opening:** Securely fits onto the glass jug, featuring a small opening for adding ingredients during operation.
- **Dosing Cup:** Fits into the lid's filling opening for precise ingredient measurement.
- **4-Wing Stainless Steel Blade:** High-quality, removable blade assembly for optimal blending results.
- **Control Panel:** Features an LED-lit dial for variable speed settings, pulse function, and three pre-set programs.



Figure 2.1: Exploded view showing the motor base, glass jug, lid, and dosing cup.



Figure 2.2: The WMF Kult Pro Blender fully assembled.

### 3. SETUP

---

Follow these steps to set up your blender for first use:

1. **Unpack:** Carefully remove all components from the packaging.
2. **Clean:** Before first use, wash the glass jug, lid, dosing cup, and blade assembly in warm, soapy water. Rinse thoroughly and dry. The motor base should only be wiped with a damp cloth.
3. **Assemble Blade:** Ensure the 4-wing stainless steel blade assembly is securely attached to the bottom

of the glass jug.

4. **Place Jug:** Position the glass jug onto the motor base. The WMF Sapy handling safety slider ensures the blender will only operate when the jug is correctly placed.
5. **Secure Lid:** Place the lid onto the glass jug and ensure it is securely fastened. The safety mechanism requires the lid to be closed for operation.
6. **Connect Power:** Plug the power cord into a suitable electrical outlet.



Figure 3.1: Ensure the lid is securely placed on the glass jug before operation.

## 4. OPERATING INSTRUCTIONS

---

The WMF Kult Pro Blender offers versatile blending options with its powerful motor and intuitive controls.

### 4.1 Adding Ingredients

- Add ingredients to the glass jug. Do not exceed the 'MAX' fill line (1800 ml).
- For adding ingredients during blending, remove the dosing cup from the lid's filling opening and carefully pour in liquids or drop in small items.



Figure 4.1: Glass jug with clear measurement markings up to 1800 ml.



Figure 4.2: The lid features a removable dosing cup for adding ingredients during operation.

## 4.2 Using the Control Panel

The control panel features a central dial and illuminated buttons for various functions.



Figure 4.3: The illuminated control panel with dial and program buttons.

- **ON/OFF:** Turn the dial to 'ON' to power on the blender. Turn to 'OFF' to power off.
- **Variable Speed:** Rotate the dial to adjust the blending speed. Start with lower speeds for softer ingredients and gradually increase for harder items.
- **Pulse Function (P):** Press and hold the 'P' button for short bursts of high-speed blending. Release to stop. Useful for chopping or controlled blending.
- **Pre-set Programs:** The blender includes three automatic programs:
  - **Smoothie:** Optimized for creating smooth, consistent smoothies.
  - **Ice Crush:** Designed for efficiently crushing ice cubes.
  - **Interval:** A program with alternating blending and pause cycles, ideal for thicker mixtures or achieving specific textures.

Simply press the corresponding button to activate a program. The blender will run for a pre-programmed

duration and stop automatically.

The 1400-watt motor and 25,000 rpm speed ensure powerful mixing for various ingredients, from soft fruits to hard ice.

## 5. MAINTENANCE AND CLEANING

---

Regular cleaning ensures the longevity and optimal performance of your WMF Kult Pro Blender.

1. **Unplug:** Always unplug the blender from the power outlet before cleaning.
2. **Disassemble:** Carefully remove the glass jug from the motor base. The 4-wing stainless steel blade assembly is removable for thorough cleaning.
3. **Wash Components:** Wash the glass jug, lid, dosing cup, and blade assembly in warm, soapy water. A brush may be used for the blades. Rinse thoroughly and dry immediately. These parts are generally dishwasher safe, but hand washing is recommended for blade longevity.
4. **Clean Motor Base:** Wipe the motor base with a damp cloth. Do not immerse it in water. Ensure no liquid enters the motor housing.
5. **Storage:** Store the blender in a clean, dry place.



Figure 5.1: The removable 4-wing stainless steel blade for easy cleaning.

## 6. TROUBLESHOOTING

---

If you encounter issues with your blender, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Blender does not turn on.	Not plugged in; jug or lid not correctly placed; power outage.	Check power connection; ensure jug and lid are securely locked in place; check household circuit breaker.

Problem	Possible Cause	Solution
Motor stops during operation.	Overload; motor overheating.	Unplug and let cool for 15-20 minutes; reduce ingredient quantity; add more liquid.
Ingredients not blending smoothly.	Too little liquid; ingredients too large; dull blades.	Add more liquid; cut ingredients into smaller pieces; ensure blades are clean and sharp (if applicable, contact support for blade replacement).
Leakage from the bottom of the jug.	Blade assembly not tightened; seal damaged.	Ensure blade assembly is securely tightened; inspect seal for damage and replace if necessary.

If the problem persists after attempting these solutions, please contact WMF customer support.

## 7. SPECIFICATIONS

---

- **Brand:** WMF
- **Model Number:** 0416510011
- **Color:** Cromargan mat.
- **Power:** 1400 Watts
- **RPM:** 25,000 rpm
- **Jug Capacity:** 1.8 Liters (1800 Milliliters)
- **Product Dimensions:** 8.46"D x 8.46"W x 17.72"H
- **Item Weight:** 10.27 pounds
- **Voltage:** 240V
- **Blade Material:** Stainless Steel
- **Container Material:** Glass
- **Control Type:** Button, Dial
- **Special Feature:** Multiple Speeds, Pulse Function, 3 Auto Programs (Smoothie, Ice Crush, Interval)
- **Recommended Uses:** Smoothies, Ice Crushing, General Blending

## 8. WARRANTY AND SUPPORT

---

WMF products are manufactured with high-quality materials and undergo strict quality control. For warranty information, please refer to the warranty card included with your purchase or visit the official WMF website.

For technical support, spare parts, or service inquiries, please contact WMF customer service:

- **Website:** [www.wmf.com](http://www.wmf.com)
- **Customer Service:** Refer to your regional WMF contact information.