Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

RovyVon A5-G4-X

RovyVon Aurora A5 USB-C Keychain Flashlight Instruction Manual

Model: A5-G4-X | Brand: RovyVon

Introduction

This manual provides detailed instructions for the safe and effective operation and maintenance of your RovyVon Aurora A5 USB-C Keychain Flashlight. Please read thoroughly before first use to ensure optimal performance and longevity of your device.

What's in the Box

Please verify that all components are present in your package:

- RovyVon Aurora A5 Flashlight (with integrated battery)
- 1 Key Ring
- 1 Magnetic Base
- 1 Magnetic Clip
- 1 RovyVon Card
- 1 USB-C Cover (replacement)

Setup

Initial Unlock

For first-time use, the flashlight is in a locked state to prevent accidental activation during shipping. To unlock the device, rapidly press the main button **five (5) times**.

Charging the Flashlight

The RovyVon Aurora A5 features a built-in rechargeable lithium polymer battery. To charge the device:

1. Locate the USB-C charging port at the tail end of the flashlight.
2. Gently pull up the protective USB-C cover.
3. Connect a standard USB-C cable (not included) to the flashlight's port and a compatible power source.
4. The charging indicator light will show the charging status. A full charge typically takes approximately 90 minutes.

5. Once charging is complete, securely close the USB-C cover to maintain water resistance.




Figure 1: USB-C Charging Port. Ensure the cover is sealed after charging.

Operating Instructions

Main Light Operation (Front LED)

- **Momentary On:** Press and hold the main button. Release to turn off.

- **Constant On:** Double-click the main button. The light will turn on and stay on.
- **Cycle Modes (Moonlight/Low/Medium/High):** While the main light is constantly on, single-click the main button to cycle through the brightness levels.
- **Turn Off:** While the main light is constantly on, press and hold the main button.
- **Lock Mode:** To prevent accidental activation, rapidly press the main button**five (5) times** to lock the flashlight. Repeat the action to unlock.



Figure 2: RovyVon Aurora A5 Flashlight showing its compact design and light output.

Side Light Operation (Side LEDs)

The Aurora A5 features versatile side lights for various applications:

- **Activate Side Lights:** Triple-click the main button. The side light will activate in its last used mode.
- **Cycle Side Light Modes:** While the side light is on, single-click the main button to cycle through the modes: *Warm White Low > Warm White High > Red > Red Flash*

- **Turn Off:** While the side light is on, press and hold the main button.



Figure 3: Side lights in warm white mode, ideal for reading or ambient lighting.




Figure 4: Side lights in red mode, useful for preserving night vision or as a warning light.

Glow-in-the-Dark Feature

The translucent body of the Aurora A5 is made from a polycarbonate mixed fluorescent powder material. When exposed to bright light (especially the flashlight's own bright white light), the body absorbs energy and will glow in the dark, making it easy to locate in low-light conditions.

Maintenance

Battery Care

To prolong battery life, charge the flashlight regularly, especially if it has not been used for an extended period. Avoid fully depleting the battery before recharging.

Cleaning

Wipe the flashlight with a soft, damp cloth to remove dirt or debris. Do not use harsh chemicals or abrasive materials, as these may damage the finish or internal components.

Troubleshooting

If you encounter any issues with your RovyVon Aurora A5 Flashlight, please refer to the following common solutions:

- **Flashlight does not turn on:** Ensure the device is unlocked by rapidly pressing the main button five times. Check if the battery needs charging.
- **Flashlight does not charge:** Verify that the USB-C cable is securely connected to both the flashlight and the power source. Ensure the power source is active.
- **Intermittent operation:** Ensure the USB-C cover is fully closed and the flashlight is free from debris that might interfere with the button.

If the problem persists after attempting these solutions, please contact RovyVon customer support for further assistance.

Specifications

Feature	Specification
Model Number	A5-G4-X
Special Feature	Rechargeable
Color	Red
Power Source	Battery Powered
Light Source Type	LED
Material	Polycarbonate mixed fluorescent powder
Product Dimensions (L x W x H)	2.38"D x 0.62"W x 0.62"H
Voltage	3.7 Volts
Light Path Distance	15 Meters
Battery Cell Composition	Lithium Polymer
Item Weight	0.4 Ounces
Number of Batteries	1 (included)
Water Resistance Level	Water Resistant (IPX6)
Brightness	650 Lumens

Feature	Specification
Runtime (Low Mode)	8 hours (up to 480 minutes)




Figure 5: The compact size of the Aurora A5, comparable to a standard AA battery.

Warranty and Support

All RovyVon products come with a **2-Year Warranty**. If you have any questions or encounter issues with your RovyVon

Aurora A5 Flashlight, please contact RovyVon customer support. We are committed to resolving any concerns within 24 hours, and in many cases, a return may not be necessary.
For support, please visit the official RovyVon website or refer to the contact information provided on your RovyVon Card included in the package.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07GTJRMJ4

More documents and user manuals: **https://manuals.plus/**