

[Manuals.plus](#) /

› [TONOR](#) /

› TONOR Conference USB Microphone G11 User Manual

TONOR G11

TONOR G11 Conference USB Microphone User Manual

Model: G11

1. INTRODUCTION

The TONOR G11 is an omnidirectional condenser USB microphone designed for clear audio capture in various settings, particularly suited for conference calls, online classes, and recording. Its 360° pickup pattern ensures that subtle sounds are captured effectively, allowing participants to communicate clearly without raising their voices.

2. PRODUCT FEATURES

- **Omnidirectional Microphone:** Captures sound from 360° directions with a pickup distance of 11.5 ft (3.5m), ensuring loud and clear audio transmission.
- **Made for Conferences:** Ideal for small to medium meetings using platforms like Skype, GoToMeeting, WebEx, Hangouts, Fuze, VoIP, and Zoom. Also suitable for court reports, seminars, remote training, business negotiations, and video chats.
- **Plug & Play, No Drivers Required:** Compatible with Windows and macOS operating systems. Simply plug in the microphone to begin recording.
- **Convenient Mute Button:** Features a touch-sensitive mute/unmute button with a built-in blue indicator light to show the microphone's working status.
- **Durable Design:** Constructed from sturdy metal material with an anti-slip mat on the base for desktop stability. Includes a 1.8m (5.9ft) nylon shielded cable to effectively eliminate signal interferences.

3. PACKAGE CONTENTS

- 1x TONOR G11 USB Microphone with 1.8m cable
- 1x User Manual

4. SETUP

The TONOR G11 microphone is designed for easy setup with its plug-and-play functionality. No additional drivers are required for most operating systems.

1. Connect the USB-A connector of the microphone cable into an available USB port on your computer (PC or Mac).
2. The operating system will automatically detect and install the necessary components.
3. If the microphone does not respond after plugging it in, navigate to your computer's sound or microphone settings and manually select the TONOR G11 USB Microphone as the input device.



PLUG & PLAY
NO DRIVERS REQUIRED

Figure 4.1: Connecting the TONOR G11 USB Microphone to a laptop. The microphone is plug-and-play, requiring no additional drivers for most systems.


5. OPERATING INSTRUCTIONS

Once connected, the TONOR G11 is ready for use. Its omnidirectional pickup ensures clear audio from all directions, making it ideal for group settings.


- **Mute Function:** The microphone features a touch-sensitive mute button located on its top surface. Tap the button to mute or unmute the microphone.
- **Status Indicator:** A blue LED light on the microphone indicates its status. When the light is blue, the microphone is active and recording. When muted, the light will change (e.g., turn off or change color, depending on the specific model's indicator).

MUTE BUTTON

Just one touch to mute!



Recording



Mute

Figure 5.1: The touch-sensitive mute button on the TONOR G11 microphone. A blue light indicates active recording, while a different state (e.g., off) indicates mute.

OMNIDIRECTIONAL MINI MICROPHONE

Microphone has an ultra-long distance pickup, with a radius of around 11.5ft that enables easy sound pickup from all directions.




Figure 5.2: Illustration of the TONOR G11's omnidirectional pickup pattern, showing its ability to capture sound from all directions within a 11.5ft radius.

Official Product Video: TONOR Conference USB Microphone Overview

Your browser does not support the video tag.

This video provides a general overview of the TONOR Conference USB Microphone, demonstrating its features and typical usage scenarios.

6. MAINTENANCE

To ensure the longevity and optimal performance of your TONOR G11 microphone, follow these simple maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to wipe the microphone's surface. Avoid using liquid cleaners or abrasive materials, as they may damage the finish or internal components.
- **Cable Care:** The 1.8m nylon shielded cable is designed for durability. Avoid sharp bends, kinks, or excessive pulling on the cable,

especially near the connectors, to prevent internal wire damage.

- **Storage:** When not in use, store the microphone in a clean, dry place away from extreme temperatures and humidity.



Figure 6.1: The TONOR G11 microphone features a durable metal construction and an anti-slip base for stable desktop placement.



Figure 6.2: The microphone's 1.8m high-quality nylon shielded cable is designed for durability and effective signal interference elimination.

7. TROUBLESHOOTING

If you encounter issues with your TONOR G11 microphone, please refer to the following common troubleshooting steps:

Problem	Possible Cause	Solution
Microphone not detected or no sound input.	Incorrect input device selected; Loose connection; USB port issue.	Ensure the USB cable is securely plugged into your computer. Go to your computer's sound settings and select "TONOR G11 USB Microphone" as the input device. Try a different USB port. Restart your computer.
Sound is too low or distorted.	Input volume too low; Background noise; Microphone too far from sound source.	Adjust the input volume level in your computer's sound settings. Ensure the microphone is placed within its optimal pickup range (approx. 11.5 ft). Minimize background noise in your environment.
Mute button not responding.	Temporary software glitch.	Unplug and re-plug the microphone. Restart the application using the microphone or your computer.

8. SPECIFICATIONS

Specification	Value
Brand	TONOR
Model Name	G11
Polar Pattern	Omnidirectional
Connectivity Technology	USB
Connector Type	USB
Microphone Form Factor	Mini
Item Dimensions (LxWxH)	7.87 x 11.81 x 1.97 inches
Item Weight	4.8 ounces (135 Grams)
Material	Nylon, Metal
Signal-to-Noise Ratio	78 dB
Impedance	2200 Ohm
Hardware Platform	Laptop, PC
Compatible Devices	Laptop, Personal Computer, Speaker
Special Feature	Mute Function, Voice Activated Recording
Power Source	Corded Electric
Number of Batteries	1 Lithium Ion batteries required.

9. WARRANTY AND SUPPORT

The TONOR G11 USB Microphone comes with a **2-year warranty** from the date of purchase.
For technical support, warranty claims, or any inquiries, please contact TONOR customer service:

- **Email:** support@tonormic.com
- **Website:** www.tonormic.com

Please retain your proof of purchase for warranty validation.



Figure 9.1: Front view of the TONOR G11 product packaging, indicating a 2-year warranty.



Figure 9.2: Side view of the TONOR G11 product packaging, showing contact information for support.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

How do I know if the TONOR G11 conference microphone is recording?

You can determine the recording status of the TONOR G11 by observing the built-in LED indicator light located on the top surface of the microphone:Active/Recording: The LED light will be blue. This indicates the...

[Read full answer](#)

Open the live page

<https://manuals.plus/asin/B07GVGMW59>

More documents and user manuals: <https://manuals.plus/>