

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [BRIO](#) /

› [BRIO 33983 Train Eight Tunnel Set with Battery Locomotive User Manual](#)

## BRIO 33983

# BRIO 33983 Train Eight Tunnel Set with Battery Locomotive User Manual

Model: 33983

## INTRODUCTION

This manual provides essential instructions for the assembly, operation, and maintenance of your BRIO 33983 Train Eight Tunnel Set with Battery Locomotive. Please read this manual thoroughly before use to ensure safe and optimal enjoyment of the product.

The BRIO 33983 set is designed to facilitate imaginative play, allowing for cargo transport on a figure-eight track layout. It includes a battery-powered locomotive, a mountain tunnel, a loading crane, a truck, and wagons, all contained within a sturdy storage box.

## PRODUCT COMPONENTS

The BRIO 33983 Train Eight Tunnel Set includes 26 pieces, designed for children aged 3 years and up. Key components are:

- Battery-powered locomotive
- Mountain tunnel
- Small magnetic loading crane
- Truck
- Two wagons with cargo
- Wooden track pieces to form a figure-eight layout
- Sturdy storage box



Image 1: The BRIO 33983 Train Eight Tunnel Set, packaged in its green storage box. The box features an illustration of the assembled track layout with the train, tunnel, and crane.

## SETUP INSTRUCTIONS

- 1. Unpack Components:** Carefully remove all 26 pieces from the sturdy storage box. Ensure all components listed in the "Product Components" section are present.
- 2. Battery Installation (Locomotive):**
  - Locate the battery compartment on the underside of the battery-powered locomotive.
  - Using a small screwdriver, open the battery compartment cover.
  - Insert the required batteries (not included), ensuring correct polarity (+/-).
  - Securely close the battery compartment cover with the screwdriver.
- 3. Track Assembly:**
  - Arrange the wooden track pieces on a flat, stable surface to form a figure-eight layout. The approximate dimensions for the assembled track are 105 cm x 45 cm.
  - Connect the track pieces firmly using the interlocking connectors.
  - Position the mountain tunnel over the appropriate track section as indicated in the product illustration.
- 4. Placement of Accessories:** Place the small magnetic loading crane, truck, and wagons around the track layout as desired for play.



Image 2: An overhead view of the assembled BRIO 33983 track layout, showing the figure-eight design with the mountain tunnel, train, and other accessories in place. The green storage box is visible in the background.

## OPERATING INSTRUCTIONS

---

- Starting the Locomotive:** Once batteries are installed, place the locomotive on the track. Locate the power switch on the locomotive (if present, otherwise it may start automatically upon battery insertion). Turn the switch to the "ON" position to start the locomotive moving along the track.
- Connecting Wagons:** Use the magnetic connectors to attach the wagons to the locomotive. Ensure the magnets align for a secure connection.
- Cargo Play:** Use the small magnetic loading crane to load and unload cargo from the wagons and the truck.
- Stopping the Locomotive:** To stop the locomotive, turn the power switch to the "OFF" position.

## MAINTENANCE

---

- Cleaning:** Wipe all components with a dry or slightly damp cloth. Do not immerse electronic components (locomotive) in water.
- Storage:** When not in use, store all pieces in the provided sturdy storage box to prevent loss and damage.
- Battery Care:** Remove batteries from the locomotive if the toy will not be used for an extended period to prevent leakage. Replace old batteries with new ones when performance diminishes.
- Inspection:** Regularly inspect track pieces and other components for any signs of wear or damage. Discontinue use if any part is broken or damaged.

## TROUBLESHOOTING

---

- Locomotive not moving:**
  - Check if the power switch is in the "ON" position.
  - Ensure batteries are correctly installed with the correct polarity.
  - Replace old batteries with new ones.
  - Verify that the locomotive wheels are clean and free from obstructions.
- Train derails frequently:**
  - Ensure all track pieces are firmly connected and laid on a flat surface.
  - Check for any debris on the track.
  - Ensure wagons are correctly attached to the locomotive.

## SAFETY INFORMATION

---

This product complies with standard toy safety regulations. No specific warnings beyond general toy safety are required. Please observe the following general safety guidelines:

- Suitable for children aged 3 years and up.
- Adult supervision is recommended during play.
- Keep small parts away from younger children to prevent choking hazards.

- Do not mix old and new batteries, or different types of batteries.
- Dispose of used batteries responsibly.

## SPECIFICATIONS

<b>Brand</b>	BRIO
<b>Model Number</b>	33983
<b>Product Dimensions (L x W x H)</b>	38.4 x 28.9 x 16.5 cm
<b>Product Weight</b>	2.05 kg
<b>Recommended Age</b>	36 months - 5 years
<b>Educational Goals</b>	Creative thinking, Social skills
<b>Number of Players</b>	1
<b>Assembly Required</b>	No (for the main product, track assembly is required)
<b>Batteries Required</b>	Yes
<b>Batteries Included</b>	No
<b>Power Source</b>	Battery
<b>Material Type(s)</b>	Plastic (and wood for tracks, implied by BRIO)
<b>Color</b>	Green
<b>Track Layout Dimensions</b>	Approx. 105 x 45 cm

## WARRANTY INFORMATION

Specific warranty details for the BRIO 33983 Train Eight Tunnel Set are typically provided at the point of purchase or within the product packaging. Please refer to your purchase receipt or contact BRIO customer service for detailed warranty terms and conditions.

## SUPPORT

For further assistance, spare parts, or inquiries regarding your BRIO 33983 Train Eight Tunnel Set, please visit the official BRIO website or contact their customer support. Contact information can usually be found on the product packaging or their official website.