

LEGO 60215

LEGO City Fire Station 60215 Instruction Manual

MODEL: 60215

Introduction

This manual provides comprehensive instructions for the assembly, operation, and care of your LEGO City Fire Station 60215 set. This set allows for the construction of a multi-level fire station, complete with various emergency vehicles and minifigures, designed for creative play scenarios.



Image: The complete LEGO City Fire Station 60215 set, showcasing the fire station building, fire truck, drone, water scooter, and several firefighter minifigures.

Components Overview

The LEGO City Fire Station 60215 set includes 509 pieces, allowing for the construction of the following main components:

- **3-Level Fire Station:** Features an office, relaxation room, and a Scout tower.
- **Garage:** Equipped with a large opening front door for vehicle access.
- **Fire Off-Road Vehicle:** Includes a stud-shooting fire hose and working light and sound bricks.
- **Scouting Drone:** Detachable with spinning rotors and a camera.
- **Water Scooter:** Designed for water rescue operations.
- **Minifigures:** Includes a fire chief, firefighters, and a fire dog figure.
- **Accessories:** Various small elements such as fire pieces, tools, and office equipment.



Image: A comprehensive view of the LEGO City Fire Station, highlighting the detailed interior of the station, the fire truck, water scooter, drone, and the included minifigures.

Setup and Assembly

Assembly of the LEGO City Fire Station 60215 is guided by the included instruction booklets. For an enhanced building experience, digital instructions are available through the LEGO Life app.

Digital Building Instructions

The LEGO Life app offers interactive 3D building instructions, allowing you to zoom, rotate, and visualize each step of the construction process. This can be particularly helpful for complex sections or for builders who prefer digital guidance.

Your browser does not support the video tag.

Video: This video demonstrates how to use the LEGO Life app for digital building instructions, including scanning a set, viewing 3D models, and tracking your collection.

To access digital instructions:

1. Download the LEGO Life app from your device's app store.
2. Scan the QR code found on the physical instruction booklet or product box.
3. Follow the on-screen 3D instructions to build your set.

Operating Features

The LEGO City Fire Station 60215 set offers several interactive features for dynamic play:

Fire Truck

The fire off-road vehicle features a working light and sound brick, which can be activated to enhance emergency role-play. It also includes a stud-shooting fire hose for imaginative fire extinguishing. The vehicle is designed to fit inside the station's garage.



Image: A detailed view of the red fire off-road vehicle, highlighting its blue light bar and the stud-shooting fire hose mechanism.

Scouting Drone

The detachable drone can be launched from the fire station's roof. Its spinning rotors and camera allow for simulated aerial reconnaissance during rescue missions.



Image: A close-up of the red and black scouting drone with its four spinning rotors, positioned on the fire station's roof.

Water Scooter

The water scooter is designed for quick water rescues and can be docked at the station's waterside dock. It accommodates one minifigure.



Image: The red water scooter with a firefighter minifigure, shown in a water rescue scenario with fire elements.

Fire Station Garage Door

The fire station features a large, functional garage door that can be opened and closed to allow the fire truck to enter and exit the station.

Your browser does not support the video tag.

Video: A brief overview of the LEGO City Fire Station, demonstrating the opening and closing garage door and the fire truck's lights and sounds.

Maintenance

To ensure the longevity and cleanliness of your LEGO City Fire Station 60215 set, follow these maintenance guidelines:

- **Cleaning:** Use a soft brush or a damp cloth with mild soap to gently clean LEGO bricks. Avoid harsh chemicals or abrasive materials.
- **Storage:** Store the set in a cool, dry place away from direct sunlight to prevent discoloration and warping of plastic elements.
- **Handling:** Handle the set with care to prevent pieces from detaching or breaking.

Troubleshooting

If you encounter any issues with your LEGO City Fire Station 60215 set, consider the following:

- **Missing Pieces:** If a piece is missing, contact LEGO Customer Service for assistance. Ensure all bags have been thoroughly checked.
- **Difficulty Connecting Bricks:** Ensure bricks are aligned correctly and apply firm, even pressure. Some new bricks may require slightly more force.
- **Light and Sound Brick Malfunction:** Check if the included battery is correctly installed and has sufficient charge. Replace the battery if necessary.
- **Lost Instructions:** Digital instructions are available via the LEGO Life app or on the official LEGO website.

Specifications

Product Dimensions	13.94 x 14.88 x 2.78 inches
Item Weight	2.2 pounds
Item Model Number	6251400
Recommended Age	5 years and up
Batteries Required	1 Product Specific battery (included)
Number of Pieces	509

Safety Information

WARNING: CHOKING HAZARD - Small parts. Not for children under 3 years.

Always supervise young children during play to prevent accidental ingestion of small parts. Ensure all components are securely connected during assembly and play.

Warranty and Support

For warranty information, replacement parts, or further assistance, please visit the official LEGO website or contact LEGO Customer Service directly. Keep your proof of purchase for any warranty claims.

Official LEGO Website: www.lego.com