

## Kappesberg G746

# Kappesberg Maxxi 120cm 4-Drawer Countertop Cabinet G746 Instruction Manual

## INTRODUCTION

---

Welcome to your Kappesberg Maxxi 120cm 4-Drawer Countertop Cabinet, model G746. This manual provides essential information for the safe and efficient assembly, installation, and use of your new kitchen cabinet. Please read these instructions carefully before beginning assembly or operation to ensure proper functionality and longevity of your product.

## SAFETY INFORMATION

---

Adhering to these safety guidelines is crucial for preventing injury and damage to the product.

- Handle the product with care during installation, as it weighs approximately 49.88 kg. It is recommended to have two people for lifting and positioning.
- The cabinet must be firmly fixed to the wall or floor to prevent tipping, especially if it will be installed above ground level or used to store heavy items.
- Ensure drawers and doors are closed correctly to prevent fingers or other body parts from being pinched.
- Do not overload the cabinet with objects beyond its specified load capacity. Distribute weight evenly across shelves and drawers.
- Use safety gloves and other appropriate protective equipment during installation and maintenance.
- Always follow the manufacturer's specific instructions for installation, use, and maintenance provided with the product packaging.

## PRODUCT OVERVIEW

---

The Kappesberg Maxxi G746 is a modular kitchen countertop cabinet designed for optimized storage. It features durable MDP (Medium Density Particleboard) construction with a Nogal (Walnut) finish, offering both functionality and modern aesthetics.

### Key Features:

- 1 Tilt-out door for convenient access.

- 4 Spacious drawers for organized storage.
- Telescopic slides ensuring smooth and quiet drawer operation.
- Stylish aluminum handles.
- Durable touch paint finish.



**Figure 1:** Kappesberg Maxxi G746 Countertop Cabinet with approximate dimensions (Width: 120cm, Depth: 52cm, Height: 88cm).



**Figure 2:** Interior view of the G746 cabinet, illustrating the four drawers and internal storage shelf, suitable for various kitchen items.

## SETUP AND ASSEMBLY

---

This product requires assembly. Detailed assembly instructions are included with the product packaging. It is highly recommended to have two people for assembly due to the product's weight and size.

### Before You Begin:

- Verify that all components and hardware are present according to the packing list provided by the manufacturer.
- Ensure you have the necessary tools for assembly, such as screwdrivers, a hammer, and a measuring tape.
- Choose a clear, spacious, and level area for assembly to prevent damage to the product or flooring.

### Installation Type:

The Kappesberg Maxxi G746 cabinet is designed for under-counter installation, featuring a floor-mounted type with a toe kick base. Ensure the cabinet is securely fastened to the wall or floor using appropriate anchors (not always included) to prevent tipping, especially if it will hold heavy items or if there are children in the household.

## OPERATING INSTRUCTIONS

---

The Kappesberg Maxxi G746 cabinet is designed for organized storage of various kitchen items, including dishes, utensils, and food.

### Using Drawers:

Gently pull the aluminum handles to open the drawers. The telescopic slides are designed for smooth and

quiet operation. Push firmly to close the drawers completely. Avoid slamming drawers to prolong the life of the slides and prevent damage to the cabinet structure.

### **Using the Tilt-Out Door:**

The cabinet features one tilt-out door. Use the designated handle to open and close it. Ensure the door is fully closed after use to maintain a tidy appearance and protect contents.

### **Weight Capacity:**

Do not overload the drawers or shelves beyond their intended weight capacity. Overloading can lead to structural damage, instability, and potential safety hazards. Distribute weight evenly within each compartment.

## **MAINTENANCE**

---

Regular maintenance will help preserve the appearance and functionality of your cabinet.

### **Cleaning:**

- Wipe all surfaces with a soft, damp cloth.
- For stubborn marks, use a mild, non-abrasive soap solution, then wipe dry immediately with a clean cloth.
- Avoid using abrasive cleaners, solvents, ammonia-based products, or harsh chemicals, as these can damage the finish and material.

### **Hardware Care:**

- Periodically check and tighten any loose screws on handles, hinges, and drawer slides. Do not overtighten.
- If drawer slides become stiff or noisy, apply a small amount of silicone-based lubricant to the tracks.

### **General Care:**

- Protect the cabinet from excessive moisture, humidity, and direct sunlight, which can cause warping or fading.
- Avoid placing hot items directly on the cabinet surface without adequate protection (e.g., trivets).

## **TROUBLESHOOTING**

---

This section addresses common issues you might encounter with your cabinet.

### **Drawers are stiff or not closing smoothly:**

- Check for any obstructions (e.g., items, debris) in the drawer slides or tracks.
- Ensure the drawer is properly aligned on its tracks. Gently remove and reinsert if necessary.
- Apply a silicone lubricant to the slides if they appear dry or resistant.

### **Cabinet feels unstable or wobbly:**

- Verify that the cabinet is securely fastened to the wall or floor as per the assembly instructions.
- Ensure the floor surface where the cabinet is placed is level. Use shims if necessary to stabilize.
- Check that all assembly screws are tightened. Do not overtighten.

### **Door not closing properly:**

- Inspect the hinges for proper alignment. Adjust if they appear loose or misaligned.
- Ensure no items inside the cabinet are obstructing the door's closing path.

## SPECIFICATIONS

<b>Brand</b>	Kappesberg
<b>Model Number</b>	G746
<b>Color</b>	Nogal (Walnut)
<b>Material</b>	MDP (Medium Density Particleboard)
<b>Product Dimensions (W x D x H)</b>	120 cm x 52 cm x 88 cm (Approximate, based on product image)
<b>Item Weight</b>	49.88 kg
<b>Number of Doors</b>	1 (Tilt-out)
<b>Number of Drawers</b>	4
<b>Number of Shelves</b>	1
<b>Assembly Required</b>	Yes
<b>Installation Type</b>	Under-counter, Floor-mounted
<b>Base Type</b>	Toe kick base
<b>Hardware Color</b>	Silver
<b>Style</b>	Modern

## WARRANTY AND SUPPORT

For detailed warranty information, technical support, or to inquire about replacement parts, please contact Kappesberg customer service directly. Refer to your purchase documentation or the manufacturer's official website for specific warranty terms, conditions, and contact details.

You can typically find more information and support on the official Kappesberg website:

[Visit Kappesberg Official Website](#)