

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [LEGO](#) /

› [LEGO Classic Basic Brick Set 11002 Instruction Manual](#)

## LEGO 6250766

# LEGO Classic Basic Brick Set 11002 Instruction Manual

Model: 6250766

[Setup](#) [Operating Instructions](#) [Maintenance](#) [Troubleshooting](#) [Specifications](#) [Warranty & Support](#)

## INTRODUCTION

The LEGO Classic Basic Brick Set 11002 provides a foundation for creative building. This set includes 300 colorful LEGO bricks, along with specialized elements like wheels and eyes, to inspire the construction of various models. It is designed to encourage open-ended play and develop building skills across different complexity levels.

This manual offers guidance for getting started, maintaining your bricks, and understanding the product's features.

## IMPORTANT SAFETY INFORMATION

**WARNING:** This toy contains small parts. It is not suitable for children under 3 years of age due to choking hazards. Adult supervision is recommended during play.

## SETUP

- Unboxing:** Carefully open the product packaging. Remove all LEGO bricks and any included instruction booklets.
- Sorting (Optional):** For easier building, you may sort the bricks by color or type into separate containers. This can help in quickly locating specific pieces during construction.
- Review Instructions:** Familiarize yourself with the included building ideas and instructions. Additional inspiration can be found online at [LEGO.com/classic](#).



Image: Front view of the LEGO Classic Basic Brick Set 11002 packaging, showing various colorful bricks and example models.



Image: Back view of the LEGO Classic Basic Brick Set 11002 packaging, illustrating different building complexity levels (Easy, Medium, Advanced) with example models like a monster truck, airplane, and knight.

## OPERATING INSTRUCTIONS (BUILDING)

The LEGO Classic Basic Brick Set is designed for open-ended creative play. Follow these general guidelines for building:

- 1. Choose a Model:** Decide whether to follow one of the included building ideas or create your own unique design. The set offers suggestions for a dinosaur, knight on horseback, monster truck, bird in a birdhouse, a dog, and an airplane.
- 2. Select Bricks:** Gather the necessary bricks for your chosen model. The set includes a variety of colors and shapes to facilitate diverse creations.
- 3. Assemble:** Connect the LEGO bricks firmly. LEGO bricks are designed to fit together securely but can be easily separated for rebuilding.
- 4. Experiment:** Do not hesitate to modify existing designs or invent entirely new structures. The core principle of LEGO Classic sets is to foster imagination.



Image: A collection of models built using the LEGO Classic Basic Brick Set, including a dinosaur, a knight on horseback, a monster truck, a birdhouse, a dog, and an airplane, demonstrating the set's versatility.



Image: A child lying on a wooden floor, actively engaged in building with LEGO bricks from the Classic Basic Brick Set, surrounded by various colorful pieces and partially built models.

Your browser does not support the video tag.

Video: An official product video showcasing the LEGO Classic Basic Brick Set, demonstrating a child building various creations and highlighting the set's features for open-ended creative play.

## MAINTENANCE

- **Cleaning:** LEGO bricks can be cleaned with mild soap and water. Avoid using hot water (above 104°F or 40°C) or harsh chemicals, as this can damage the plastic. Rinse thoroughly and air dry.
- **Storage:** Store LEGO bricks in a clean, dry place away from direct sunlight and extreme temperatures to prevent

discoloration or warping. Using storage containers can help keep sets organized and prevent loss of pieces.

- **Handling:** While LEGO bricks are durable, avoid excessive force when connecting or disconnecting them to prevent wear and tear.

## TROUBLESHOOTING

Problem	Solution
Bricks not connecting securely.	Ensure the studs and tubes are clean and free from debris. Apply firm, even pressure when connecting.
Missing a specific brick.	Carefully check all packaging materials and the play area. If a piece is genuinely missing from a new set, contact LEGO Customer Service.
Difficulty separating bricks.	Use a brick separator tool (not included in this set, but available separately) or gently twist and pull the bricks apart. Avoid using teeth or sharp objects.

## SPECIFICATIONS

**Model Number:** 6250766

**Set Number:** 11002

**Number of Pieces:** 300

**Recommended Age:** 4 years and up

**Product Dimensions:** 10.32 x 7.52 x 2.84 inches

**Item Weight:** 0.015 ounces

**Material:** ABS Plastic

## WARRANTY & SUPPORT

LEGO products are manufactured to high-quality standards. For information regarding warranty, missing parts, or product support, please visit the official LEGO Customer Service website or contact them directly.

**Online Support:** [www.lego.com/service](http://www.lego.com/service)

**Contact Information:** Refer to the LEGO website for regional contact details.