Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- · IRIS /
- > IRIS USA WOOZOO Air Circulator Fan Instruction Manual

IRIS 586800

IRIS USA WOOZOO Air Circulator Fan

Model: 586800 | Brand: IRIS USA

INTRODUCTION

The IRIS USA WOOZOO Air Circulator Fan is designed to enhance airflow in various indoor environments such as homes, offices, and dormitories. This compact yet powerful unit features remote control operation, allowing for convenient adjustment of settings from a distance. It offers five distinct speed settings, an optional natural breeze mode, and comprehensive oscillation capabilities (left/right, up/down, or all directions) to ensure widespread air circulation. The fan operates quietly, particularly on its lowest setting, and includes auto-off timer options for 1, 2, or 4 hours. With a 70-inch power cord, it provides flexibility in placement to maximize air coverage up to 353 sq ft.

KEY FEATURES

- Compact Design: Dimensions of 8.27"L x 8.27"W x 11.42"H make it suitable for various spaces.
- Multi-Directional Oscillation: Oscillates left, right, up, and down to direct airflow precisely where needed, or in all directions for whole-room circulation.
- Five Speed Settings: Adjustable airflow strength to meet diverse cooling requirements.
- Natural Breeze Mode: Simulates the feeling of an outdoor breeze for enhanced comfort.
- Auto-Off Timer: Conveniently set the fan to shut off automatically after 1, 2, or 4 hours.
- Quiet Operation: Features a virtually silent 'low' setting for undisturbed use, especially in bedrooms.
- Remote Control: Full control over all fan settings from a distance.
- Extended Air Distance: Capable of providing airflow up to 82 feet, covering areas up to 353 sq ft.

INCLUDED COMPONENTS

- WOOZOO Air Circulator Fan Unit
- Remote Control
- Power Cord (70 inches)

SETUP

- 1. Unboxing: Carefully remove the fan and all included components from the packaging.
- 2. Placement: Place the fan on a stable, flat surface in the desired location. Ensure there is adequate space around the fan

for optimal air circulation and oscillation.

- 3. Power Connection: Plug the 70-inch power cord into a standard 120V electrical outlet.
- 4. **Remote Control Battery:** Insert the required battery (CR2025 lithium cell, 3V) into the remote control if not already installed.

No assembly is required for this product.

OPERATING INSTRUCTIONS

The fan can be operated using the control panel on its base or the included remote control.

Control Panel / Remote Functions:

- Power Button (): Press to turn the fan ON or OFF.
- Speed Adjustment (< >): Use the left and right arrow buttons to cycle through 5 fan speeds. The current speed level is indicated by LED lights.
- Natural Breeze Mode (with waves): Press this button to activate the natural breeze setting, which varies the fan speed
 to simulate natural wind.
- Timer Setting ((©): Press to set the auto-off timer for 1, 2, or 4 hours. Corresponding LED lights will illuminate.
- Horizontal Oscillation (♥): Press to activate left-to-right oscillation. Press again to stop.
- Vertical Oscillation (©): Press to activate up-and-down oscillation. Press again to stop.
- Combined Oscillation: Activate both horizontal and vertical oscillation for full 3D air circulation.
- LED Light Control (Remote Only): The remote control may include a button to turn off the LED indicator lights on the fan's base for undisturbed use in dark environments.



Figure 1: Fan Control Panel. Displays power, speed, timer, and oscillation controls.



Figure 2: Remote Control. Provides convenient access to all fan functions.

MAINTENANCE

Regular cleaning ensures optimal performance and longevity of your fan.

- Exterior Cleaning: Wipe the exterior surfaces of the fan with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- **Grille Cleaning:** Periodically use a soft brush or a vacuum cleaner with a brush attachment to remove dust and debris from the front and rear grilles.
- **Blade Cleaning:** For deeper cleaning, if the grilles are removable, carefully remove them and wipe the fan blades with a damp cloth. Ensure the fan is unplugged before attempting to clean the blades. Allow all parts to dry completely before reassembling and operating.
- Storage: When not in use for extended periods, store the fan in a cool, dry place, preferably in its original packaging to protect it from dust.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Fan does not turn on.	No power supply.	Ensure the power cord is securely plugged into a working electrical outlet. Check the circuit breaker.
Weak or no airflow.	Fan speed is too low; Grilles are obstructed by dust.	Increase the fan speed setting. Clean the fan grilles and blades as per maintenance instructions.
Fan makes unusual noise.	Obstruction in fan blades; Fan not on a stable surface.	Unplug the fan and check for any foreign objects obstructing the blades. Ensure the fan is placed on a stable, level surface.
Remote control not working.	Battery is dead or incorrectly inserted.	Replace the CR2025 lithium cell battery in the remote control. Ensure it is inserted with correct polarity.

SPECIFICATIONS

Attribute	Detail
Brand	IRIS
Model Name	PCF-SC15T (Internal Model: 586800)
Product Dimensions	8.27"D x 8.27"W x 11.42"H
Item Weight	3.97 pounds
Color	White
Power Source	Corded Electric
Voltage	120V
Wattage	60 watts
Number of Power Levels	5
Control Method	Remote
Special Features	Remote Controlled, Oscillating (Horizontal & Vertical)
Max Air Distance	82 ft
Cable Length	70 Inches

WARRANTY AND SUPPORT

For warranty information or product support, please refer to the documentation included with your purchase or visit the official IRIS USA website. Contact customer service for any inquiries regarding product operation, maintenance, or troubleshooting beyond the scope of this manual.

© 2025 IRIS USA. All rights reserved.

Related Documents - 586800



WOOZOO® Globe Fan PCF-SC15T User Manual | IRIS USA, Inc.

Comprehensive user manual for the WOOZOO® Globe Fan, Series PCF-SC15T by IRIS USA, Inc. Includes safety precautions, operating instructions, cleaning, maintenance, troubleshooting, specifications, and warranty information.



Iris Product Setup, Features, and Cleaning Guide

Comprehensive guide to setting up, understanding the features, and cleaning the Iris product. Includes setup steps, outlet information, and maintenance instructions.



IRIS Easy Flip User Manual: Comprehensive Guide to Setup and Operation

Get started with your IRIS Easy Flip phone. This user manual covers setup, basic operations, connectivity, communication, camera, settings, safety, and troubleshooting for your IRIS Easy Flip device.



IRIS Easy Flip Quick Start Guide

A concise guide to setting up and using your IRIS Easy Flip phone, covering basic features, SIM card setup, battery charging, security, and emergency calls.



IRISPen Air 7 Quick Start Guide: Scan, Translate, Read Aloud

Comprehensive quick start guide for the IRISPen Air 7 smart scanner pen. Learn how to install, set up, scan text, translate, and use text-to-speech features on Windows and Mac OS.



IRIS Easy Flip Quick Start Guide

A quick start guide for the IRIS Easy Flip phone, covering setup, at-a-glance features, and basic configuration.