

[Manuals.plus](#) /

> [Bell+Howell](#) /

> Bell + Howell Magnetic Tac Light Lantern User Manual

Bell+Howell Magnetic Tac Light Lantern

Bell + Howell Magnetic Tac Light Lantern User Manual

Model: Magnetic Tac Light Lantern

1. INTRODUCTION

Thank you for choosing the Bell + Howell Magnetic Tac Light Lantern. This high-performance, super bright LED lantern is designed for durability and versatility, featuring a magnetic base for hands-free operation. It is built to withstand various environmental conditions, making it suitable for automotive use, camping, emergencies, and general illumination.

Please read this manual thoroughly before using your lantern to ensure proper operation and to maximize its lifespan.



Image 1.1: The Bell + Howell Magnetic Tac Light Lantern, showcasing its compact and extended forms.

2. SAFETY INFORMATION

Observe the following safety precautions to prevent injury or damage to the lantern:

- Do not look directly into the LED light when it is on, as it can cause temporary vision impairment.
- Keep out of reach of children.

- Do not attempt to disassemble or modify the lantern. This will void the warranty and may cause damage or injury.
- Ensure batteries are inserted with correct polarity. Incorrect insertion can cause battery leakage or explosion.
- Remove batteries if the lantern will not be used for an extended period to prevent leakage.
- Dispose of used batteries according to local regulations.

3. PACKAGE CONTENTS

Your package should contain the following items:

- Bell + Howell Magnetic Tac Light Lantern (2 units)
- User Manual (this document)

4. SETUP

4.1 Battery Installation

The Bell + Howell Magnetic Tac Light Lantern is battery-powered. Batteries are typically not included and must be purchased separately.

1. Locate the battery compartment cover at the bottom of the lantern.
2. Twist the cover counter-clockwise to open and remove it.
3. Insert the required number of batteries (typically 3x AA or AAA, refer to the compartment markings) ensuring correct polarity (+/-).
4. Replace the battery compartment cover and twist clockwise until securely fastened.

5. OPERATING INSTRUCTIONS

5.1 Turning On/Off and Adjusting Brightness

The lantern operates by extending and collapsing its body:

- To turn on: Gently pull the top section of the lantern upwards to extend it. The LED lights will illuminate.
- To adjust brightness: Continue to extend or collapse the lantern body. The further it is extended, the brighter the light will be.
- To turn off: Fully collapse the top section of the lantern back into its base. The LED lights will turn off.

5.2 Using the Magnetic Base

The lantern features a strong magnetic base for hands-free illumination:

- Attach the magnetic base to any ferrous metal surface, such as a car hood, fuse box, metal shelf, or workbench.
- Ensure the surface is clean and stable to prevent the lantern from falling.

6. MAINTENANCE

6.1 Cleaning

- Wipe the exterior of the lantern with a soft, damp cloth.
- Do not use abrasive cleaners or solvents, as they may damage the finish.

- Ensure the lantern is completely dry before storing or using.

6.2 Storage

- Store the lantern in a cool, dry place when not in use.
- Remove batteries if storing for extended periods to prevent corrosion.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Lantern does not turn on.	Batteries are dead or incorrectly inserted.	Replace batteries with new ones, ensuring correct polarity.
Light is dim.	Batteries are low. Lantern is not fully extended.	Replace batteries. Fully extend the lantern body.
Lantern flickers.	Loose battery connection or low batteries.	Check battery compartment for secure connection. Replace batteries.

8. SPECIFICATIONS

Feature	Detail
Brand	Bell+Howell
Model	Magnetic Tac Light Lantern
Light Source Type	Light Emitting Diode (LED)
Number of Light Sources	3
Color	Silver
Power Source	Battery Powered
Product Dimensions (L x W x H)	3.07"L x 3.35"W x 7.16"H
Item Weight	1.22 kg
Mounting Type	Surface (with magnetic base)
Water Resistance Level	Waterproof
Shade Material	Metal
UPC	080313021305
ASIN	B07GZJ78CG

9. WARRANTY AND SUPPORT

For warranty information or customer support, please refer to the official Bell+Howell website or contact their customer service directly. Specific warranty terms may vary by region and retailer.

You can visit the Bell+Howell Store for more information:[Bell+Howell Store on Amazon](#)

© 2023 Bell+Howell. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B07GZJ78CG>

More documents and user manuals: <https://manuals.plus/>