

- Manuals.plus /
- › [REVLON](#) /
 - › REVLON Infrared Hair Dryer with Diffuser - User Manual

REVLON RVDR5264

REVLON Infrared Hair Dryer with Diffuser - User Manual

Model: RVDR5264

PRODUCT OVERVIEW

The REVLON Infrared Hair Dryer with Diffuser is designed to provide salon-quality blowouts at home, focusing on maintaining hair's natural moisture and preventing over-drying. It incorporates Infrared Heat Technology, Ceramic Coating, and Tourmaline Ionic Technology to deliver shiny, soft, and frizz-free results.



Figure 1: REVLON Infrared Hair Dryer with included attachments.

KEY FEATURES

- **Infrared Heat Technology:** Designed to penetrate the hair cuticle, drying hair from the inside out to help maintain natural moisture and prevent over-drying.
- **3X Ceramic Coating:** Ensures even heat distribution, reducing heat damage and promoting healthier-looking hair.
- **Tourmaline Ionic Technology:** Helps to reduce frizz and static, leaving hair smooth and shiny.
- **Powerful 1875 Watts:** Provides strong airflow for fast drying and efficient styling.
- **Multiple Heat/Speed Settings:** Features 3 heat settings (Hot, Warm, Cool Shot) and 2 speed settings (High, Low) for versatile styling options suitable for all hair types.
- **Attachments:** Includes a Volumizing Finger Diffuser for enhancing natural curls and waves, and a Concentrator Nozzle for precise styling.
- **Lightweight Design:** Ergonomically designed for comfortable handling during use.

Enhanced Technology for Healthier Looking Hair



3X CERAMIC COATING

Ensures even heat distribution
and minimizes damage



TOURMALINE TECHNOLOGY

Reduces frizz and static for sleek
and shiny hair



UP TO 1875 WATTS

For maximum drying power

Figure 2: Advanced technologies for healthier hair.

SAFETY INFORMATION

Please read all instructions before using this appliance. Keep away from water. Do not use while bathing. Do not place or store appliance where it can fall or be pulled into a tub or sink. Do not place in or drop into water or other liquid. If an appliance falls into water, unplug it immediately. Do not reach into the water. Always unplug this appliance immediately after using.

- Ensure your hands are dry before plugging in or unplugging the appliance.
- Do not use this appliance near bathtubs, showers, basins or other vessels containing water.
- Always inspect the appliance for damage before use. Do not use if the cord or plug is damaged.
- Keep the air intake filter clear of dust and lint to prevent overheating.
- Unplug the appliance when not in use.

SETUP

1. Unpack all components: hair dryer, concentrator nozzle, volumizing diffuser, and styling clips.
2. Ensure the appliance is unplugged before attaching or detaching any accessories.
3. To attach the Concentrator Nozzle or Volumizing Diffuser, align the attachment with the front barrel of the dryer and push firmly until it clicks into place.
4. To remove, gently pull the attachment off the barrel.
5. Plug the dryer into a standard 110-volt electrical outlet.

Dry and Diffuse with Ease

With added concentrator
and diffuser attachments
for precision and variety.

+ includes hair styling clips!



Figure 3: Attaching the diffuser or concentrator for styling.

OPERATING INSTRUCTIONS

Controls:

- **Heat Settings:** Use the top switch to select between HOT and WARM.
- **Speed Settings:** Use the middle switch to select between HIGH, OFF, and LOW.
- **Cool Shot Button:** Press and hold the button on the handle to instantly deliver cool air, which helps to set your style for long-lasting results.



Pretty, Sleek, and Hassle-Free

2 Speed Settings

Low, High

Cool Shot Button

Locks in style

Hanging Ring

For easier storage

Figure 4: Control panel for heat and speed settings.

Drying Techniques:

1. Towel-dry hair to remove excess moisture before styling.
2. For fast drying, use the HIGH speed and HOT heat setting.
3. For precise styling, attach the Concentrator Nozzle and direct airflow to specific sections of hair using a brush.
4. For enhancing curls and adding volume, attach the Volumizing Finger Diffuser. Gently cup sections of hair with the diffuser and lift towards the scalp, using a circular motion.
5. Finish your style by pressing the Cool Shot button to lock in the look and add shine.

MAINTENANCE

Regular maintenance ensures optimal performance and extends the life of your hair dryer.

- **Cleaning the Air Filter:** Periodically, the rear filter screen may become clogged with dust and lint. To clean, ensure the dryer is unplugged and cool. Gently twist or pull off the rear cap (depending on model design). Use a soft brush or vacuum

cleaner to remove any accumulated debris. Replace the cap securely before next use.

- **General Cleaning:** Wipe the exterior of the dryer with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- **Storage:** Store the dryer in a cool, dry place. You can use the hanging ring for convenient storage. Do not wrap the cord tightly around the dryer, as this can damage the cord.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Dryer does not turn on.	No power to the outlet; GFCI tripped; Damaged cord/plug.	Check power outlet; Reset GFCI; Do not use if cord/plug is damaged, contact customer support.
Dryer overheats or shuts off.	Air intake filter is blocked; Prolonged use.	Unplug and allow to cool; Clean the air filter; Allow dryer to rest between uses.
Reduced airflow or weak drying.	Air filter is clogged.	Clean the air filter.
Hair is frizzy after drying.	Not using Tourmaline Ionic Technology effectively; Hair not fully dry.	Ensure proper use of ionic technology (e.g., using cool shot); Ensure hair is completely dry.

SPECIFICATIONS

- **Model Number:** RVDR5264
- **Brand:** REVLON
- **Wattage:** 1875 watts
- **Power Source:** Corded Electric
- **Voltage:** 110 volts (US standard)
- **Material:** Ceramic
- **Color:** White
- **Product Dimensions:** 4.1 x 11 x 9.7 inches
- **Item Weight:** 2.05 Pounds
- **Manufacturer:** Helen of Troy
- **Country of Origin:** China

WARRANTY AND SUPPORT

This REVLON product is covered by a manufacturer's warranty. For specific warranty details, including duration and coverage, please refer to the warranty card included in your product packaging or visit the official REVLON website. For technical support, troubleshooting assistance, or to inquire about replacement parts, please contact REVLON customer service. Keep your purchase receipt as proof of purchase for warranty claims.

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B07GZWQDPR>

More documents and user manuals: **<https://manuals.plus/>**