

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Maxima](#) /

› [Maxima Beverage Dispenser User Manual](#)

Maxima 09300542

Maxima Beverage Dispenser User Manual

Model: 09300542

INTRODUCTION

Thank you for choosing the Maxima Beverage Dispenser. This robust and non-electric dispenser is designed for serving large quantities of beverages, featuring two 8-liter containers and a central cooling tube for maintaining optimal drink temperature. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your new appliance.

SAFETY INSTRUCTIONS

- Always place the dispenser on a stable, level surface to prevent tipping.
- Do not use the dispenser for hot liquids. It is designed for cold beverages only.
- Handle glass or plastic components with care to avoid breakage.
- Ensure all parts are properly assembled before filling with liquid.
- Keep out of reach of children.
- Clean all components thoroughly before first use and after each use.

PRODUCT OVERVIEW

The Maxima Beverage Dispenser (Model 09300542) is a non-electric unit designed for efficient beverage service. Key components include:

- Two (2) 8-liter transparent beverage containers.
- Two (2) stainless steel cooling tubes.
- Two (2) dispensing spigots.
- A sturdy stainless steel base with two integrated drip trays.
- Two (2) stainless steel lids.



Figure 1: Exploded view showing all components of the Maxima Beverage Dispenser, including the base, containers, cooling tubes, spigots, lids, and drip trays.

SETUP INSTRUCTIONS

- 1. Unpack Components:** Carefully remove all parts from the packaging. Verify that all components listed in the "Product Overview" section are present and undamaged.
- 2. Assemble Spigots:** Attach the dispensing spigots to the bottom of each beverage container. Ensure they are securely tightened to prevent leaks.
- 3. Place Containers on Base:** Position the two beverage containers onto the designated spots on the stainless steel base. Ensure they are stable.
- 4. Insert Cooling Tubes:** Place the stainless steel cooling tubes into the central opening of each container.
- 5. Fill Cooling Tubes (Optional):** For chilled beverages, fill the stainless steel cooling tubes with ice cubes or crushed ice. Do not overfill.
- 6. Place Lids:** Securely place the stainless steel lids on top of each beverage container.
- 7. Position Drip Trays:** Slide the drip trays into their slots on the base directly below the spigots.



Figure 2: Fully assembled Maxima Beverage Dispenser, ready for use.

OPERATING INSTRUCTIONS

1. **Prepare Beverages:** Ensure your beverages are pre-chilled if you are not using ice in the cooling tubes.
2. **Fill Containers:** Carefully pour your desired cold beverages into each 8-liter container. Do not fill above the maximum fill line (if indicated) or to the very top to prevent spills.
3. **Dispense Beverage:** To dispense, push the spigot handle down. To stop the flow, release the handle. For continuous flow, some spigots may have a locking mechanism (push down and pull forward).
4. **Monitor Drip Trays:** Regularly check and empty the drip trays to prevent overflow.



Figure 3: Front view of the dispenser, highlighting the spigots and drip trays.

MAINTENANCE AND CLEANING

Regular cleaning and maintenance will ensure the longevity and hygienic operation of your Maxima Beverage Dispenser.

1. **Empty and Disassemble:** After each use, empty any remaining liquid. Disassemble all removable parts: lids, containers, cooling tubes, spigots, and drip trays.
2. **Wash Components:** Wash all parts with warm, soapy water. Use a soft brush for the spigots to ensure no residue remains.
3. **Rinse Thoroughly:** Rinse all components thoroughly with clean water to remove all soap residue.
4. **Dry Completely:** Allow all parts to air dry completely before reassembling or storing. This prevents water spots and bacterial growth.
5. **Clean Base:** Wipe the stainless steel base with a damp cloth and mild detergent. Dry immediately with a soft, clean cloth to prevent streaks.
6. **Storage:** Store the dispenser in a clean, dry place when not in use.

TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Liquid leaking from spigot.	Spigot not tightened properly or seal is damaged.	Ensure spigot is securely tightened. Check rubber seals for damage and replace if necessary.
Liquid not dispensing or slow flow.	Spigot clogged or airlock.	Check spigot for pulp or debris and clean. Ensure lid is not creating a vacuum (briefly lift lid to check).
Beverage not staying cold.	Insufficient ice in cooling tube or warm initial beverage.	Ensure cooling tubes are filled with ice. Use pre-chilled beverages. Refill ice as needed.

SPECIFICATIONS

Feature	Detail
Brand	Maxima
Model Number	09300542
Capacity	2 x 8 Liters (Total 16 Liters)
Material	Stainless Steel, Transparent Containers (likely PC/Acrylic)
Color	Metallic
Dimensions (L x W x H)	36 x 55 x 56 cm (approximately 14.2 x 21.7 x 22 inches)
Operation	Non-electric, passive cooling via ice tube
Country of Origin	China

WARRANTY AND SUPPORT


For warranty information and customer support, please refer to the documentation provided at the time of purchase or visit the official Maxima Kitchen Equipment website. Maxima is committed to providing quality equipment and reliable service.

Contact Information: Please refer to your purchase receipt or the Maxima Kitchen Equipment website for the most up-to-date contact details for service and support.



© 2024 Maxima Kitchen Equipment. All rights reserved.

Related Documents - 09300542

 <p>MAXIMA PLANETARY MIXER 7L</p> <p>USER MANUAL GEBRUIKSHANDLEIDING</p> <p>CE</p>	<p>Maxima Planetary Mixer 7L User Manual</p> <p>User manual for the Maxima Planetary Mixer 7L, providing detailed instructions on installation, operation, safety precautions, cleaning, maintenance, and warranty information for professional kitchen use.</p>
 <p>maxima</p> <p>USE AND INSTRUCTION MANUAL PROOFER</p>	<p>Maxima Proofer Use and Instruction Manual MKL 1064 S</p> <p>This manual provides detailed instructions for the Maxima Proofer, model MKL 1064 S (08561106). It covers installation, operation, safety warnings, technical specifications, maintenance, troubleshooting, and warranty information for professional kitchen use.</p>
 <p>maxima</p> <p>USER MANUAL</p> <p>ELECTRIC WAFFLE MAKER</p>	<p>Maxima Electric Waffle Maker User Manual</p> <p>Comprehensive user manual for the Maxima Electric Waffle Maker, covering specifications, features, safety guidelines, installation, operation, troubleshooting, cleaning, and warranty information.</p>
 <p>maxima</p> <p>USER MANUAL</p> <p>ELECTRIC POFFERTJES / MINI PANCAKE PLATE</p>	<p>Maxima Electric Poffertjes / Mini Pancake Plate User Manual & Guide</p> <p>Official user manual for the Maxima Electric Poffertjes / Mini Pancake Plate (models 09374125, 09374130, 09374131, 09374132). Find detailed information on specifications, features, safety guidelines, installation, operation, troubleshooting, cleaning, and warranty.</p>
 <p>maxima</p> <p>USER MANUAL</p> <p>ELECTRIC CHOCOLATE MELTING MACHINE</p>	<p>Maxima Electric Chocolate Melting Machine User Manual</p> <p>User manual for the Maxima Electric Chocolate Melting Machine, covering models 09374050, 09374051, 09374052, and 09374053. Provides detailed information on specifications, safety guidelines, installation, operation, maintenance, troubleshooting, and warranty.</p>
 <p>maxima</p> <p>BAR COOLER SERIES</p> <p>USER MANUAL GEBRUIKSHANDLEIDING</p> <p>CE</p>	<p>Maxima Bar Cooler Series User Manual</p> <p>User manual for the Maxima Bar Cooler Series, providing instructions for installation, operation, safety guidelines, and maintenance.</p>