

ASHATA ASHATAumkxhb6sd4

ASHATA 14-Inch Portable Digital TV User Manual

Model: ASHATA 14 Inch Portable Digital TV (ASHATAumkxhb6sd4)

1. INTRODUCTION

This manual provides detailed instructions for the safe and efficient use of your ASHATA 14-inch portable digital TV. Please read this manual thoroughly before operating the device and keep it for future reference. This portable digital TV is designed for versatile use, offering high-definition viewing and multiple connectivity options.

2. SAFETY INFORMATION

To ensure safe operation and prevent damage, please observe the following safety precautions:

- Do not expose the device to rain or moisture.
- Avoid placing the device near heat sources or in direct sunlight.
- Do not block ventilation openings.
- Use only the provided power adapter.
- Keep the device away from strong magnetic fields.
- Do not attempt to disassemble or repair the unit yourself. Refer all servicing to qualified personnel.
- Clean the screen with a soft, dry cloth. Avoid liquid cleaners.

3. PACKAGE CONTENTS

Please check the package for the following items:

- 1 x ASHATA 14-inch Portable Digital TV
- 1 x User Manual
- 1 x Remote Control
- 1 x AV Cable
- 1 x Antenna
- 1 x Power Adapter (EU Plug)

4. PRODUCT OVERVIEW

The ASHATA 14-inch portable digital TV features a high-resolution 1080P TFT-LED screen and a high-sensitivity tuner for clear reception of digital and analog television signals. It includes dual 32mm stereo speakers and supports multiple external input sources.



Image Description: Front and rear view of the ASHATA 14-inch Portable Digital TV. The front shows the screen, while the rear displays the integrated stand and speaker grilles. This image illustrates the physical design and the stand for tabletop use.

**14IN LCD
GIVES A SUPER CLEAR VISION.**

1080P HIGH RESOLUTION



Image Description: The ASHATA 14-inch Portable Digital TV screen displaying a vibrant, high-resolution image of various berries in a basket, demonstrating its 1080P display capability.



HIGH SENSITIVITY TV TUNER

A HIGH SENSITIVITY TUNER STRENGTHENS SIGNAL
RECEIVING ABILITY TO MAKE TV PLAYING SMOOTHER

Image Description: The ASHATA 14-inch Portable Digital TV positioned on a desk, showing a clear image of a baby on a beach. This image emphasizes the high sensitivity TV tuner, which ensures smooth and stable television playback.

CAR DIGITAL TV

YOU CAN WATCH 1080P ANALOG TV, DIGIAL TV AND ATV.



ATV: 48.25MHZ-863.25MHZ
DIGITAL TV VHF: 50MHZ-230MHZ
DIGITAL TV UHF: 474MHZ-862MHZ

Image Description: The ASHATA 14-inch Portable Digital TV installed in a car, with passengers in the background appearing to enjoy the content displayed on the screen. This illustrates its use as a car digital TV, capable of displaying 1080P analog TV, digital TV, and ATV.

5. SETUP

5.1 Power Connection

Connect the provided power adapter to the DC input port on the TV and then plug it into a suitable power outlet (AC100-220V). The TV has a built-in 1800mAh rechargeable lithium battery for portable use.

5.2 Antenna Connection

Connect the included antenna to the antenna input port on the TV. For optimal signal reception, position the antenna in an area with good signal strength.

5.3 Connecting External Sources

The TV supports multiple external sources including AV input/output, SD and MMC card, USB devices, HDMI port, and VGA port.

MULTIPLE EXTERNAL SOURCES



Image Description: A diagram illustrating the various external connectivity options available on the ASHATA Portable Digital TV. Icons represent HDMI, AV, USB, VGA, and SD & MMC card slots, with examples of devices like speakers, laptops, game consoles, and external monitors connected.

- **HDMI:** Connect HDMI-compatible devices such as game consoles or media players.
- **AV:** Use the AV cable to connect older devices like DVD players.
- **USB:** Insert a USB flash drive or external hard disk to play media files or record TV programs.
- **VGA:** Connect to a computer or laptop for use as an external monitor.
- **SD & MMC:** Insert an SD or MMC card to view photos or play videos.

6. OPERATING INSTRUCTIONS

6.1 Power On/Off

Press the **POWER** button on the TV or remote control to turn the device on or off.

6.2 Initial Channel Scan

Upon first use or after moving to a new location, perform an automatic channel scan to find available TV channels. Navigate to the **MENU**, select **CHANNEL**, and then **AUTO SCAN**.

6.3 Channel and Volume Control

- Use the **CH+/-** buttons on the remote or TV to change channels.
- Use the **VOL+/-** buttons on the remote or TV to adjust the volume.

6.4 Source Selection

Press the **SOURCE** button on the remote control to switch between different input sources (TV, AV, HDMI, USB, VGA, SD/MMC).

6.5 Recording TV Programs

HD TV programs can be recorded and stored on a connected USB device or external hard disk.

TV PROGRAM RECORDING

HD TV PROGRAMS CAN BE RECORDED AND STORED IN A USB DEVICE OR A HARD DISK




Image Description: The ASHATA 14-inch Portable Digital TV screen showing a group of people in a jeep, with text indicating the "TV Program Recording" feature. This highlights the ability to record and store HD TV programs on external storage.

To record, ensure a USB storage device is connected. Consult the on-screen menu for recording options.

6.6 Remote Control Usage

The included remote control provides full functionality for operating the TV.

REMOTE CONTROL

REMOTE CONTROL MAKES OPERATION MORE CONVENIENT AND EASIER.



Image Description: A hand holding the ASHATA Portable Digital TV remote control, with a car interior and a person driving in the background. This image demonstrates the convenience of using the remote control for easier operation.

Familiarize yourself with the buttons for power, volume, channel, menu, source, and playback controls.

7. MAINTENANCE

7.1 Cleaning

Wipe the screen and exterior surfaces with a soft, dry, lint-free cloth. Do not use liquid cleaners, aerosols, or abrasive materials, as they may damage the finish or screen.

7.2 Battery Care

The device contains a built-in rechargeable lithium battery. To prolong battery life:

- Avoid fully discharging the battery frequently.
- Charge the battery regularly, even if the device is not in use for extended periods.
- Store the device in a cool, dry place when not in use.

8. TROUBLESHOOTING

Problem	Possible Cause	Solution
No power	Power adapter not connected; battery discharged.	Ensure power adapter is securely connected and plugged in. Charge the battery.
No signal/Poor picture quality	Antenna not connected; poor antenna position; weak signal.	Connect antenna securely. Adjust antenna position. Perform an auto channel scan. Check signal strength in your area.
No sound	Volume too low; mute function active.	Increase volume. Press the MUTE button on the remote to deactivate.
Remote control not working	Batteries depleted; obstruction between remote and TV.	Replace remote control batteries. Ensure no obstructions and point remote directly at the TV's IR sensor.
Cannot play media from USB/SD	Unsupported file format; device not properly connected.	Ensure media files are in a supported format (MKV, MOV, AVI, WMV, MP4, FLV, MPEG1-4, RMVB, 1080p video, MP3). Reconnect the USB/SD device.

9. SPECIFICATIONS

Feature	Detail
Product Type	Portable Digital TV
Screen Size	14 Inches
Display Type	TFT-LED
Resolution	1080p
Refresh Rate	60 Hz
Aspect Ratio	1.77:1 (16:9)
Supported Formats	MKV, MOV, AVI, WMV, MP4, FLV, MPEG1-4, RMVB, 1080p video, MP3
Receiving Channels (ATV)	48.25MHz - 863.25MHz
Receiving Channels (Digital TV VHF)	50 MHz - 230 MHz
Receiving Channels (Digital TV UHF)	474MHz - 862MHz
External Sources	AV Input/Output, SD & MMC Card, USB Devices, HDMI Port, VGA Port
Speakers	2 x 32mm Round Stereo Speakers
Audio Output	2W maximum
Power Consumption	18W
Battery Capacity	1800mAh (Rechargeable Lithium)
Input Power	AC100-220V
Model Number	ASHATAumkxhb6sd4

Feature	Detail
Manufacturer	ASHATA
Country of Origin	China

10. WARRANTY AND SUPPORT

ASHATA products are manufactured to high-quality standards. This product has been professionally inspected and tested.

For any quality issues or questions regarding this product, please contact ASHATA customer service. A professional online customer service team is available 24 hours a day to assist you.

Please refer to your purchase documentation for specific warranty terms and conditions.