

[Manuals.plus](#) /

› [iLive Electronics](#) /

› iLive ISBW108TQ Portable Bluetooth Waterproof Speaker User Manual

iLive Electronics ISBW108TQ

iLive ISBW108TQ Portable Bluetooth Waterproof Speaker User Manual

Model: ISBW108TQ | Brand: iLive Electronics

INTRODUCTION

This manual provides essential instructions for the safe and efficient operation of your iLive ISBW108TQ Portable Bluetooth Waterproof Speaker. Please read this manual thoroughly before using the device and retain it for future reference.

The iLive ISBW108TQ is a compact, waterproof (IPX5 rated) Bluetooth speaker designed for portability. It features a built-in microphone for hands-free calling and a rechargeable battery for extended use.

PACKAGE CONTENTS

Verify that all items are present in the package:

- iLive ISBW108TQ Portable Bluetooth Waterproof Speaker
- Detachable Carabiner Clip
- Micro-USB to USB Charging Cable
- User's Guide (this document)
- Warranty Information

PRODUCT OVERVIEW

Familiarize yourself with the speaker's components and controls.





Image 1: Top View of iLive ISBW108TQ Speaker. This image shows the top surface of the turquoise speaker, highlighting the control buttons for power, volume, and playback.

Controls and Indicators:

- **Power Button:** Used to turn the speaker on or off.
- **Volume Up (+):** Increases the speaker volume.
- **Volume Down (-):** Decreases the speaker volume.
- **Play/Pause Button:** Controls audio playback (play, pause).
- **Pairing/Answer Phone Button:** Initiates Bluetooth pairing mode and answers/ends phone calls.
- **Microphone:** For hands-free calling.

Ports:

- **Micro-USB Port:** For charging the internal battery.



Image 2: iLive ISBW108TQ Speaker with Carabiner Clip. This image displays the turquoise speaker from a side angle, showing the attached carabiner clip for easy portability.

SETUP

1. Charging the Speaker

1. Locate the Micro-USB port on the speaker.
2. Connect the small end of the included Micro-USB to USB cable to the speaker's Micro-USB port.
3. Connect the larger USB end of the cable to a powered USB port (e.g., computer, USB wall adapter).
4. Allow the speaker to charge fully before first use. A full charge provides approximately 2.5 hours of playback at 100% volume.

2. Powering On/Off

- To power on, press and hold the **Power Button** until an indicator light illuminates or an audible tone is heard.
- To power off, press and hold the **Power Button** again until the indicator light turns off or an audible tone is heard.

3. Bluetooth Pairing

To connect your speaker to a Bluetooth-enabled device:

1. Ensure the speaker is powered on and within 60 feet of your Bluetooth device.
2. Press and hold the **Pairing/Answer Phone Button** to enter pairing mode. The indicator light will typically flash to indicate it is discoverable.
3. On your Bluetooth device (smartphone, tablet, laptop), navigate to the Bluetooth settings and enable Bluetooth.
4. Search for available devices. The speaker should appear as "ISBW108TQ" or similar.
5. Select the speaker from the list to initiate pairing. Once paired, the indicator light may change or an audible confirmation will sound.
6. If prompted for a password, enter "0000".



Image 3: Bluetooth Wireless Connectivity. This image shows a person relaxing on a couch, using a smartphone to stream audio wirelessly to the iLive speaker, demonstrating its Bluetooth capability.

OPERATING

Playing Audio

- Once paired, begin playing audio from your connected Bluetooth device.
- Use the **Play/Pause Button** on the speaker to pause or resume playback.
- Adjust volume using the **Volume Up (+)** and **Volume Down (-)** buttons on the speaker, or directly from your connected device.

Hands-Free Calling

- When a call is received on your paired smartphone, the speaker will ring.
- Press the **Pairing/Answer Phone Button** once to answer the call.
- Speak into the built-in microphone on the speaker.
- Press the **Pairing/Answer Phone Button** again to end the call.

MAINTENANCE

Water Resistance

The iLive ISBW108TQ speaker features an IPX5 waterproof rating, meaning it is protected against low-pressure water jets from any direction. This makes it suitable for use in environments where it may be exposed to splashes, such as by a pool or in a shower.

- Do not submerge the speaker in water.
- Ensure the Micro-USB port cover is securely closed when using the speaker near water to maintain its water resistance.
- If the speaker gets wet, wipe it dry with a soft cloth before charging or opening the port cover.



Image 4: Speaker by the Pool. This image shows the iLive ISBW108TQ speaker placed on a wooden surface next to a swimming pool, illustrating its suitability for outdoor and splash-prone environments.

Cleaning

To clean the speaker, use a soft, dry, or slightly damp cloth. Do not use abrasive cleaners or solvents.

TROUBLESHOOTING

Problem	Possible Solution
Speaker does not power on.	Ensure the battery is charged. Connect the speaker to a power source using the Micro-USB cable.

Problem	Possible Solution
Cannot pair with Bluetooth device.	• Ensure the speaker is in pairing mode (indicator light flashing). • Make sure Bluetooth is enabled on your device. • Move the speaker closer to your device (within 60 feet). • Turn off and on both the speaker and your Bluetooth device, then try pairing again. • Clear previous Bluetooth connections on your device if necessary.
No sound or low volume.	• Increase the volume on both the speaker and your connected device. • Ensure the speaker is properly paired and connected to your device. • Check if the audio source on your device is playing.
Call quality is poor.	• Ensure you are speaking directly towards the speaker's microphone. • Reduce background noise. • Move closer to your paired device.

SPECIFICATIONS

Model Number	ISBW108TQ
Brand	iLive Electronics
Connectivity Technology	Bluetooth, USB
Wireless Range	Up to 60 feet
Water Resistance Level	IPX5 (Waterproof)
Speaker Type	Portable
Speaker Maximum Output Power	3 Watts
Battery Type	1 Lithium Ion (included)
Battery Life (100% volume)	Approximately 2.5 hours
Product Dimensions	3.4"D x 2.56"W x 2.56"H
Item Weight	10.4 ounces
Included Components	Detachable carabiner clip, Micro-USB to USB cable, User's Guide
UPC	047323108044

WARRANTY AND SUPPORT

This product comes with a limited warranty. Please refer to the included warranty information in your package for details regarding coverage and terms.

For technical support or customer service inquiries, please visit the iLive Electronics website or contact their customer

support line as provided in your warranty documentation.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question