

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

Manuals.plus /

› [Rosseto](#) /

› Rosseto LD115 1-1/2-Gallon Beverage Dispenser Instruction Manual

Rosseto LD115

Rosseto LD115 1-1/2-Gallon Beverage Dispenser Instruction Manual

Model: LD115

INTRODUCTION

Thank you for choosing the Rosseto LD115 1-1/2-Gallon Beverage Dispenser with Stainless Base. This manual provides important information regarding the assembly, operation, maintenance, and troubleshooting of your new beverage dispenser. Please read these instructions carefully before use and retain them for future reference.

SAFETY INSTRUCTIONS

- Always handle the dispenser with care to prevent damage to the acrylic container or stainless steel base.
- Do not use abrasive cleaners or scouring pads, as these can scratch the acrylic and stainless steel surfaces.
- This dispenser is **not dishwasher safe**. Hand wash all components.
- Ensure the spigot is securely tightened before filling the dispenser to prevent leaks.
- Do not fill with boiling hot liquids. Allow liquids to cool to a safe temperature before pouring into the dispenser.
- Keep out of reach of children when filled with liquids.

PARTS LIST

Before assembly, ensure all parts are present and undamaged:

- Acrylic Beverage Container (1.5 Gallon capacity)
- Stainless Steel Base
- Lid

- Spigot Assembly (includes spigot, washers, and nut)



Image: Fully assembled Rosseto LD115 Beverage Dispenser. This image shows the clear acrylic container resting on its decorative stainless steel base, with the spigot attached. The dispenser is filled with a beverage, ice, and fruit garnishes.

SETUP AND ASSEMBLY

1. **Unpack Components:** Carefully remove all parts from the packaging. Inspect for any damage.
2. **Clean Before First Use:** Wash all parts (acrylic container, lid, spigot assembly, stainless steel base) with warm, soapy water. Rinse thoroughly and dry completely.
3. **Assemble Spigot:**
 - Insert the spigot through the hole in the acrylic container from the outside.
 - Place a silicone washer on the inside of the container over the spigot thread.
 - Secure with the nut, tightening firmly by hand. Do not overtighten with tools, as this may crack the acrylic.
4. **Place Container on Base:** Position the assembled acrylic container onto the stainless steel base, ensuring it sits securely.
5. **Test for Leaks:** Before adding your desired beverage, fill the dispenser with water and check for any leaks around the spigot. If a leak occurs, tighten the spigot nut slightly more.

OPERATING INSTRUCTIONS

1. **Prepare Beverage:** Prepare your desired beverage. Ensure it is at a suitable serving temperature.
2. **Fill Dispenser:** Carefully pour the beverage into the acrylic container. You may add ice, fruit slices, or other garnishes as desired.
3. **Secure Lid:** Place the lid firmly on top of the container to keep the beverage fresh and protected.

4. **Dispense Beverage:** To dispense, push the spigot handle down. To stop, release the handle. For continuous flow, some spigots may have a locking mechanism (push down and pull forward slightly).
5. **Refilling:** When the beverage level is low, remove the lid and refill as needed.

MAINTENANCE AND CLEANING

Proper cleaning and maintenance will extend the life of your Rosseto beverage dispenser.

- **After Each Use:**
 - Empty any remaining beverage.
 - Disassemble the spigot for thorough cleaning.
 - Wash all parts with warm, soapy water using a soft cloth or sponge.
 - Rinse thoroughly with clean water.
 - Dry all components completely before storing to prevent water spots and bacterial growth.
- **Do Not Use:** Abrasive cleaners, steel wool, or harsh chemicals, as these can damage the surfaces.
- **Storage:** Store the dispenser in a clean, dry place when not in use.

TROUBLESHOOTING

| Problem | Possible Cause | Solution |
|--|--|---|
| Leakage from spigot | Spigot nut is loose or washers are not correctly seated. | Tighten the spigot nut by hand. Ensure washers are flat against the container walls. |
| Slow flow from spigot | Spigot may be clogged by fruit pulp or ice. | Remove spigot and clean thoroughly. Ensure beverage is strained if it contains pulp. |
| Container appears cloudy or scratched | Abrasive cleaning materials used. | Avoid using abrasive cleaners. Minor scratches may be polished with acrylic polish (follow product instructions). |

SPECIFICATIONS

- **Model:** LD115
- **Brand:** Rosseto
- **Material:** Stainless Steel (Base), Acrylic (Container)
- **Capacity:** 1.5 Gallons
- **Color:** Stainless Steel (Base), Clear (Container)
- **Style:** Modern
- **Lid:** Yes
- **Dishwasher Safe:** No (Hand wash only)
- **UPC:** 826726794609
- **ASIN:** B07H79WNRR

WARRANTY AND SUPPORT

Rosseto products are manufactured to high-quality standards. For specific warranty information or technical support, please refer to the warranty card included with your purchase or visit the official Rosseto website. Please have your model number (LD115) and purchase date available when contacting support. For further assistance, you may visit: www.rosseto.com