

Tolino Shine 3

Tolino Shine 3 eBook Reader User Manual

Model: Shine 3 (4016621126872)

1. INTRODUCTION

This manual provides essential information for setting up, operating, and maintaining your Tolino Shine 3 eBook Reader. Please read it thoroughly to ensure proper use and to maximize your reading experience.

2. WHAT'S IN THE BOX

Upon unpacking your Tolino Shine 3, please verify that all the following items are included:

- Tolino Shine 3 eBook Reader
- Micro-USB Charging Cable
- Quick Start Guide (this document serves as the full user manual)

3. PRODUCT OVERVIEW

Familiarize yourself with the physical components of your Tolino Shine 3.

3.1 Front View



Figure 3.1: Front view of the Tolino Shine 3 eBook Reader, showing the E Ink Carta display with text content and the Tolino logo at the bottom.

The front of the device features the 6-inch E Ink Carta touchscreen display, which provides a paper-like reading experience. The display resolution is 1072 x 1448 pixels. The Tolino logo is located at the bottom center.

3.2 Back View



Figure 3.2: Back view of the Tolino Shine 3 eBook Reader, featuring a textured black surface for improved grip and the embossed Tolino logo.

The back of the device has a textured surface designed for comfortable handling and grip. The Tolino logo is subtly embossed in the center.

3.3 Bottom View (Ports and Controls)



Figure 3.3: Bottom view of the Tolino Shine 3 eBook Reader, highlighting the Micro-USB port for charging and data transfer, and the power button.

On the bottom edge, you will find the Micro-USB port, used for charging the device and connecting it to a computer for data transfer. The power button is also located on this edge, typically next to the charging port.

4. SETUP

4.1 Initial Charging

Before first use, fully charge your Tolino Shine 3. Connect the supplied Micro-USB cable to the device's Micro-USB port and the other end to a USB power adapter (not included) or a computer's USB port. The charging indicator light will show the charging status.

4.2 Powering On/Off

- **To Power On:** Press and hold the power button (located on the bottom edge) for a few seconds until the screen activates.
- **To Power Off:** Press and hold the power button until a menu appears, then select 'Power Off'. A short press will put the device into sleep mode.

4.3 Initial Configuration

Upon first power-on, the device will guide you through an initial setup process. This typically includes:

- **Language Selection:** Choose your preferred language for the device interface.
- **Wi-Fi Connection:** Connect to a wireless network to access online features, download books, and receive updates. Select your network from the list and enter the password.
- **Registration:** You may be prompted to register your device with a Tolino partner bookstore. Follow the on-screen instructions to complete this step. Registration is often necessary to access cloud services and purchase content directly from the device.

5. OPERATING THE DEVICE

5.1 Navigation

The Tolino Shine 3 features a responsive touchscreen for navigation. Use the following gestures:

- **Tap:** To select an item, open a book, or activate a menu option.
- **Swipe:** To turn pages in a book, scroll through lists, or navigate between home screen panels.
- **Pinch-to-Zoom:** In some contexts, this gesture may be used to adjust text size or zoom into images.

5.2 Reading Books

To open a book, tap its cover on the home screen or in your library. While reading:

- **Turning Pages:** Tap the left or right side of the screen, or swipe left/right.
- **Accessing Reading Menu:** Tap the center of the screen to bring up options for font size, line spacing, brightness, and other settings.
- **SmartLight:** The integrated SmartLight feature automatically adjusts the color temperature of the front light from cool white to warm white, adapting to the time of day for comfortable reading. This can also be adjusted manually in the reading menu.

5.3 Managing Your Library

Books can be stored on the device's internal 8 GB memory. You can organize your library by creating collections or using search and filter functions.

5.4 Transferring Books

- **Via Wi-Fi (Tolino Cloud):** If registered, you can download purchased books directly from your Tolino cloud library.
- **Via Computer (Micro-USB):** Connect your Tolino Shine 3 to a computer using the Micro-USB cable. The device will appear as a removable drive. You can then drag and drop compatible eBook files (e.g., EPUB, PDF, TXT) into the device's 'Books' folder.

6. MAINTENANCE

6.1 Cleaning

- **Screen:** Use a soft, lint-free cloth, slightly dampened with water or a screen cleaner, to gently wipe the E Ink display. Avoid harsh chemicals.
- **Body:** Wipe the device body with a soft, dry cloth.

6.2 Battery Care

- To prolong battery life, avoid exposing the device to extreme temperatures.
- Charge the device regularly, but it is not necessary to fully discharge it before recharging.

7. TROUBLESHOOTING

7.1 Device Unresponsive

If the device becomes unresponsive, try a soft reset. Press and hold the power button for approximately 10-15 seconds until the device restarts.

7.2 Wi-Fi Connectivity Issues

- Ensure your Wi-Fi network is active and within range.
- Verify that you have entered the correct Wi-Fi password.
- Try restarting your Wi-Fi router.
- On the Tolino Shine 3, turn Wi-Fi off and then on again in the settings.

7.3 Books Not Appearing

- Ensure the book files are in a compatible format (EPUB, PDF, TXT).
- If transferred via USB, verify the files were placed in the correct folder (e.g., 'Books').
- If downloaded from the cloud, check your internet connection and library synchronization.

8. SPECIFICATIONS

Feature	Specification
Model Name	Shine 3
Item Model Number	4016621126872
Display Technology	E Ink Carta
Screen Size	6 Inches (15.2 cm)

Display Resolution	1072 x 1448 Pixels
Human Interface Input	Touchscreen
Memory Storage Capacity	8 GB
Connectivity Technology	Micro-USB, Wireless (Wi-Fi)
Special Features	Bluetooth Connectivity, SmartLight
Color	Black
Batteries	1 Lithium Ion battery (included)
Product Dimensions	6.54 x 0.33 x 6.16 inches
Item Weight	3.89 ounces (110.2 Grams)
Supported Formats	EPUB, PDF, TXT (with DRM support)


9. WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the official Tolino website or contact your point of purchase. Keep your proof of purchase for warranty claims.
Online resources and FAQs may also be available on the Tolino support pages.



© 2023 Tolino. All rights reserved.

Related Documents - Shine 3

Handbuch 	tolino eReader Handbuch: Ihr Leitfaden für digitales Lesen Entdecken Sie die Funktionen Ihres tolino eReaders mit diesem umfassenden Handbuch. Erfahren Sie, wie Sie eBooks lesen, verwalten und Ihr Gerät optimal nutzen, von der Einrichtung bis zu fortgeschrittenen Einstellungen.
tolino^{page 2} tolino^{shine 3} Handbuch Deutsch	Tolino Shine 3 & Page 2 User Manual Comprehensive user manual for the Tolino Shine 3 and Tolino Page 2 e-readers, covering setup, reading features, internet connectivity, e-book management, cloud services, maintenance, and warranty.
	tolino flip Quick Start Guide: Activate, Pair, and Use Concise guide to activating, pairing, and replacing the battery for your tolino flip e-reader accessory. Learn how to connect it to your tolino eReader for seamless page turning.

	tolino flip: Fernbedienung für tolino eReader Technische Daten & Funktionen Entdecken Sie den toline flip, die praktische Fernbedienung für Ihren toline eReader. Erfahren Sie mehr über technische Daten, Funktionen wie intuitive Seitenwahl und lange Akkulaufzeit. Kompatibel mit toline vision color, toline shine (5. Gen.) und toline shine color.
	Tolino Stylus: Enhance Your E-Reading Experience Discover the Tolino Stylus, designed for creating notes, highlighting text, and scribbling on your Tolino Vision Color e-reader. Features USB-C charging and a magnetic grip.
	tolino stylus: Notieren, Markieren und Gestalten auf Ihrem tolino eReader Entdecken Sie den toline stylus, die ideale Ergänzung für Ihren toline vision color eReader. Erstellen Sie handschriftliche Notizen, markieren Sie Text und lassen Sie Ihrer Kreativität freien Lauf. Mit USB-C Aufladung und magnetischer Haftung.