

[Manuals.plus](#) /

› [NANAMI](#) /

› NANAMI X1 Bluetooth Wireless Headphones User Manual

NANAMI X1

NANAMI X1 Bluetooth Wireless Headphones User Manual

Model: X1

Your guide to optimal performance and care.

INTRODUCTION

Thank you for choosing NANAMI X1 Bluetooth Wireless Headphones. These earbuds are designed to provide a superior audio experience with advanced features like Bluetooth 5.3, IPX7 waterproofing, and a comfortable magnetic neckband. This manual will guide you through the setup, operation, and maintenance of your new headphones.



NANAMI X1 Bluetooth Wireless Headphones, Black with Red accents.

WHAT'S IN THE BOX

Please check the package contents to ensure all items are present:

- NANAMI X1 Bluetooth Wireless Headphones
- Type C Charging Cable
- Eartips (various sizes)
- User Manual (this document)

What's in the Box



All components included with your NANAMI X1 headphones.

SETUP

1. Charging Your Headphones

Before first use, fully charge your NANAMI X1 headphones. The 200mAH polymer Lithium battery provides up to 18 hours of playtime on a full charge.

1. Locate the Type-C charging port on the control module.
2. Connect the provided Type-C charging cable to the port and the other end to a USB power source (e.g., wall adapter, computer USB port).
3. The LED indicator will show charging status. A full charge typically takes about 2 hours.



Type-C Fast Charge 2 Hours

Long Lasting Battery 18-20 Hours

The NANAMI X1 offers up to 18 hours of playtime and supports Type-C fast charging.


2. Pairing with Your Device

The NANAMI X1 headphones utilize Bluetooth 5.3 for fast and stable connectivity.


1. Ensure your headphones are powered off.
2. Press and hold the Multi-Function Button (MFB) for 3 seconds until the LED indicator flashes red and blue, indicating pairing mode.

3. On your device (smartphone, tablet, laptop), enable Bluetooth and search for available devices.
4. Select "NANAMI X1" from the list of devices.
5. Once connected, the LED indicator will turn solid blue, and you will hear a voice prompt confirming the connection.

Premium **Bluetooth 5.3** for excellent performance



Premium Bluetooth 5.3 ensures excellent performance and stable connection.



Universal Compatibility

Press and hold MFB button 3s and pair with "NANAMI X1"



Universal compatibility with iOS, Android, and other Bluetooth-enabled devices.

Setup and Pairing Video Guide

Your browser does not support the video tag.

Official video demonstrating the Bluetooth connection process for NANAMI headphones.

Your browser does not support the video tag.

Official video showcasing the NANAMI Update Bluetooth Headphones and their features.

OPERATING INSTRUCTIONS

In-Line Control Buttons

The NANAMI X1 features convenient in-line control buttons for easy management of your audio and calls without touching your phone.

- **Power On/Off:** Press and hold MFB for 3 seconds.
- **Play/Pause:** Press MFB once.
- **Volume Up:** Press '+' once.
- **Volume Down:** Press '-' once.
- **Next Track:** Press and hold '+' for 2 seconds.
- **Previous Track:** Press and hold '-' for 2 seconds.
- **Answer Call:** Press MFB once.
- **Hang Up Call:** Press MFB once during a call.
- **Reject Call:** Press and hold MFB for 3 seconds.
- **Activate Siri/Voice Assistant:** Press both '+' and '-' simultaneously.

Great Sound Quality

Immerse yourself in the pleasant music all day



Detailed view of the easy-to-use in-line control buttons.



Comprehensive guide to the functions of the control buttons.

Audio and Call Quality

Experience rich, deep bass and high-fidelity ultra-clear sound for an immersive music experience. The built-in MEMS microphone filters out background noise for clearer voice during hands-free calling.



Noise Cancellation



Hands-free Call



Microphone



Play/Pause

Enjoy clear calls and immersive audio with CVC 8.0 Noise Cancellation.

KEY FEATURES

- **Bluetooth 5.3:** Equipped with an advanced chip for faster pairing, stable connectivity, and efficient power

consumption.

- **IPX7 Waterproof Technology:** Designed to withstand sweat and light rain, making them ideal for workouts and outdoor activities.
- **Powerful Audio:** Acoustic design provides rich, deep bass and HiFi ultra-clear sound. Features 10mm drivers and supports SBC & AAC audio.
- **Magnetic Neckband:** Built-in magnets on the earbuds allow them to attach when not in use, forming a necklace for convenient, tangle-free storage and wear.
- **Comfortable Wearing:** Ergonomically designed flex neckband made of ultra-soft, high-quality materials ensures a comfortable and secure fit for an active lifestyle.



IPX7 WATERPROOF

Sweat & rain resistant design keeps Bluetooth Running Headphones fully functional

IPX7 waterproof rating ensures durability against sweat and rain.

Type-C Charging Port

Type-C Charging Port

Volume+/Next Track

Multi-Function Button(MFB)

Volume-/Previous Track

LED Indicator



Power On

Press and hold MFB 3s



Power Off

Press and hold MFB 5s



Answer Call

Press MFB once



Hang Up

Press MFB once



Reject Call

Press and hold MFB 3s



Activate Siri

Press both + and -



Volume Up

Press + once



Volume Down

Press - once



Previous Track

Press and hold - 2s



Next Track

Press and hold + 2s

The IPX7 rating allows for worry-free use during intense workouts or light rain.



MAGNETIC DESIGN

Magnetic headphones, easy to carry when not in use

Magnetic design allows for easy and secure carrying when not in use.

Long Lasting Battery Life



Magnetic earbuds provide easy storage and prevent tangling.

Easy Operation

In-line control buttons allow you easy access to the audio and phone call



Advanced audio components deliver great sound quality with deep bass.

Magnetic Earbuds, Easy Storage



Enjoy extended listening sessions with long-lasting battery life.

MAINTENANCE

To ensure the longevity and optimal performance of your NANAMI X1 headphones, follow these maintenance guidelines:

- **Cleaning:** Regularly wipe the earbuds and neckband with a soft, dry cloth. For sweat or light moisture, gently clean with a damp cloth and allow to air dry completely before storage or use.
- **Storage:** When not in use, utilize the magnetic feature to secure the earbuds together. Store them in a cool, dry place away from direct sunlight and extreme temperatures.
- **Charging:** Use only the provided Type-C charging cable. Avoid using damaged cables or chargers.
- **Water Exposure:** While IPX7 rated, avoid prolonged submersion in water or exposure to high-pressure water jets. Dry thoroughly if exposed to water.

TROUBLESHOOTING

If you encounter any issues with your NANAMI X1 headphones, please refer to the following common solutions:

Problem	Possible Solution
Headphones won't turn on	Ensure the headphones are fully charged. Press and hold the MFB for 3-5 seconds.
Cannot pair with device	Ensure headphones are in pairing mode (flashing red/blue LED). Turn off and on Bluetooth on your device. Move headphones closer to the device. Clear previous Bluetooth connections on your device.
No sound or low volume	Check volume levels on both headphones and your device. Ensure headphones are properly connected. Try re-pairing.
Intermittent connection	Ensure no obstacles between headphones and device. Move away from other wireless devices that may cause interference. Ensure battery is not low.

Problem	Possible Solution
Charging issue	Check the charging cable and power source. Ensure the charging port is clean and free of debris.

If the problem persists, please contact NANAMI customer support for further assistance.

SPECIFICATIONS

Feature	Detail
Model Name	NANAMI X1 Earbuds
Connectivity Technology	Wireless, Bluetooth
Wireless Communication Technology	Bluetooth, True Wireless
Bluetooth Version	5.3
Bluetooth Range	10 Meters
Water Resistance Level	IPX7 Waterproof
Battery Life	15-18 Hours (Playtime)
Charging Time	2 Hours
Headphones Jack	Micro USB (for charging)
Noise Control	Sound Isolation
Audio Driver Type	Dynamic Driver (10mm)
Control Type	Button Control
Item Weight	25 Grams (0.882 ounces)
Material	Plastic
Color	Black with red
UPC	791309891443

WARRANTY AND SUPPORT

NANAMI is committed to maintaining the highest quality standards and providing our customers with a superb experience.

If you have any questions or encounter problems during use, please do not hesitate to contact us via Amazon. We are dedicated to resolving any issues promptly.

For further assistance, please visit the official NANAMI store on Amazon:[NANAMI Store](#)

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question