Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Garosa Garosa2coitdnxv9-01

Garosa G1/2 Brass Wall Mounted Faucet Instruction Manual

Model: Garosa2coitdnxv9-01 | Brand: Garosa

1. Introduction

This manual provides detailed instructions for the installation, operation, and maintenance of your Garosa G1/2 Brass Wall Mounted Faucet. Designed for washing machines, laundry areas, and utility sinks, this faucet features a durable brass construction and a classic design. Please read this manual thoroughly before installation and use to ensure proper function and longevity of the product.

2. Product Features

- **Wall Mounted Design:** Saves space and integrates seamlessly with various wall types.
- **Solid Brass Construction:** Made from oil-rubbed solid brass, ensuring corrosion resistance, anti-rust properties, and long-term durability.
- **Vintage Aesthetic:** Features a European classic antique design with an oil-rubbed bronze finish, enhancing the decor of your space.
- **Single Cross Handle:** Provides convenient control over cold/hot water flow and on/off function.
- **Easy Connection:** Tap spout is designed for direct connection with washing machine inlet pipes (G1/2 connection thread).





Image: Front view of the Garosa G1/2 Brass Wall Mounted Faucet, showcasing its antique brass finish and cross handle.



Image: Multiple detailed views of the Garosa faucet, highlighting the cross handle, spout, and wall connection point.

3. Safety Information

Always prioritize safety during installation and use. If you are unsure about any step, consult a qualified plumber. Ensure the main water supply is turned off before beginning any installation or maintenance work. Wear appropriate personal protective equipment, such as gloves and eye protection. Do not overtighten connections, as this can damage the faucet or plumbing.

4. Package Contents

Verify that all components are present before starting installation:

- Garosa G1/2 Brass Wall Mounted Faucet
- Decorative Cover/Escutcheon

- Raw Material Belt (PTFE tape)
- Instruction Manual



Image: The Garosa faucet partially enclosed in a protective brown cloth bag, as it arrives in the package.

5. Installation Instructions

Follow these steps for proper installation of your Garosa wall-mounted faucet:

1. **Prepare Water Inlets:** Ensure pre-buried water inlet pipes are left at the appropriate height on the wall.
2. **Apply PTFE Tape:** Wrap raw material belt (PTFE tape) around the thread of the faucet.
3. **Attach Decorative Cover:** Place the decorative cover onto the faucet.
4. **Screw into Inlet Pipe:** Screw the faucet into the water inlet pipe. Tighten clockwise by hand first.
5. **Final Tightening:** Use a screwdriver to insert into the water outlet for leverage and tighten the faucet.**Do not use a wrench** to tighten the threaded port to avoid damage.
6. **Check for Leaks:** After tightening, turn on the water source to the pipeline to check for any leaks and ensure the thread is properly sealed.





Image: Diagram illustrating the installation method, showing the embedded pipeline, decorative cover, faucet, and raw material belt

(PTFE tape).



Image: The Garosa faucet installed on a wall, with its G1/2 connection thread visible, ready to connect to a washing machine's inlet pipe.

Installation Video

Your browser does not support the video tag.

Video: A demonstration of the Garosa Washing Machine Water Faucet in use, showing water flow and the cross handle operation.

6. Operating Instructions

The Garosa faucet features a single cross handle for easy operation:

- **To Turn On:** Rotate the cross handle counter-clockwise to open the water flow.
- **To Turn Off:** Rotate the cross handle clockwise to close the water flow.
- **Water Temperature:** This faucet is designed for a single water line (cold or hot, depending on connection). It does not mix hot and cold water.

7. Maintenance

To maintain the appearance and functionality of your brass faucet:

- **Cleaning:** Clean the faucet regularly with a soft cloth and mild soap. Avoid abrasive cleaners, harsh chemicals, or scouring pads, as these can damage the oil-rubbed bronze finish.
- **Preventing Mineral Buildup:** In areas with hard water, wipe the faucet dry after each use to prevent water spots and mineral buildup.
- **Inspection:** Periodically check all connections for tightness to prevent leaks.

8. Troubleshooting

If you encounter issues with your faucet, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Water Leakage at Connection	Loose connection, insufficient PTFE tape, damaged threads.	Turn off water supply. Re-apply PTFE tape generously and tighten the connection firmly by hand, then use a screwdriver for final tightening as per installation instructions. Do not overtighten with a wrench.
Low Water Flow	Partially closed water supply, debris in the line.	Ensure the main water supply valve is fully open. Check for any blockages in the water inlet pipe.
Handle is Stiff	Mineral buildup or internal component issue.	Regular cleaning can prevent buildup. If the issue persists, professional inspection may be required.

9. Specifications

Specification	Detail
Brand	Garosa
Model Name	Garosa2coitdnxv9-01
Material	Brass
Finish Type	Oil Rubbed
Mounting Type	Wall Mount
Number of Handles	1 (Cross Handle)
Hole Count	1
Special Feature	Rust-Resistant
Spout Reach	12.5 Centimeters
Item Weight	0.26 Kilograms (9.2 ounces)
Product Dimensions	9.84 x 7.87 x 1.97 inches

Specification	Detail
GTIN / UPC	798382920749

10. Warranty and Support

For warranty information or technical support, please refer to the product packaging or contact Garosa customer service directly. Keep your purchase receipt as proof of purchase.

© 2024 Garosa. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07H83ZLTF

More documents and user manuals: **https://manuals.plus/**