

Humixx HY-S1-001

Humixx Wireless Headphones-Jet Black User Manual

Model: HY-S1-001

INTRODUCTION

Thank you for choosing the Humixx Wireless Headphones-Jet Black. This manual provides essential information for setting up, operating, and maintaining your new headphones. Please read it carefully to ensure optimal performance and longevity of your device.

PRODUCT OVERVIEW



Image: The Humix Wireless Headphones in Jet Black. This image displays two individual earbuds, highlighting their sleek design and subtle gold accents. The background features soft white feathers, suggesting lightness and comfort.

The Humix Wireless Headphones are designed for an active lifestyle, offering high-fidelity stereo sound with aptX codec and CSR8645 chipset. They feature advanced Bluetooth 4.1 CSR technology for seamless connectivity up to 33 feet and CVC 6.0 noise isolation for clear audio. Built to withstand dripping sweat with an IPX Level 4 rating, these headphones provide comfort and durability for various activities.

SETUP

Charging the Headphones

Before first use, fully charge your Humix Wireless Headphones. Connect the charging cable to the charging port on the headphones and to a USB power source. A full charge typically takes 1-2 hours. The indicator light will change to show charging status and completion.

Pairing with a Bluetooth Device

1. Ensure the headphones are charged and powered off.
2. Press and hold the power button until the indicator light flashes, indicating pairing mode.

3. On your device (smartphone, tablet, etc.), enable Bluetooth and search for available devices.
4. Select "Humix Headphones" (or similar name) from the list of found devices.
5. Once connected, the indicator light on the headphones will change, and you will hear an audible confirmation.

The headphones can connect seamlessly with all Bluetooth-enabled devices up to 33 feet away.

OPERATING INSTRUCTIONS

Power On/Off

- **To Power On:** Press and hold the power button for approximately 3 seconds until the indicator light turns on.
- **To Power Off:** Press and hold the power button for approximately 5 seconds until the indicator light turns off.

Music Playback

- **Play/Pause:** Press the multi-function button once.
- **Next Track:** Press and hold the Volume + button.
- **Previous Track:** Press and hold the Volume - button.
- **Volume Up:** Short press the Volume + button.
- **Volume Down:** Short press the Volume - button.

Call Management

- **Answer/End Call:** Press the multi-function button once.
- **Reject Call:** Press and hold the multi-function button for 2 seconds.
- **Redial Last Number:** Double-press the multi-function button.

MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the headphones. Do not use abrasive cleaners or solvents.
- **Water Resistance:** The headphones are IPX Level 4 rated, meaning they can withstand dripping sweat and light splashes. Do not submerge them in water or expose them to heavy rain.
- **Storage:** When not in use, store the headphones in a cool, dry place, away from direct sunlight and extreme temperatures. The convenient built-in magnets allow you to attach the earphones together to avoid tangling.
- **Battery Care:** To preserve battery life, charge the headphones regularly, even if not used frequently. Avoid fully discharging the battery for extended periods.

TROUBLESHOOTING

Problem	Possible Solution
Headphones won't turn on.	Ensure the headphones are fully charged. Connect to a power source and wait a few minutes before attempting to power on again.

Problem	Possible Solution
Cannot pair with device.	<ul style="list-style-type: none"> Ensure headphones are in pairing mode (flashing indicator light). Turn off and on Bluetooth on your device. Move headphones closer to your device. Clear previous Bluetooth connections on your device if too many are stored. Restart both the headphones and your device.
No sound or low volume.	<ul style="list-style-type: none"> Check volume levels on both the headphones and your connected device. Ensure the headphones are properly connected to your device. Try playing different audio sources.
Poor sound quality or crackling.	<ul style="list-style-type: none"> Move closer to your connected device to reduce interference. Avoid obstacles between the headphones and your device. Ensure no other strong wireless signals are interfering.

SPECIFICATIONS

Feature	Detail
Model Number	HY-S1-001
Connectivity Technology	Bluetooth 4.1 CSR
Wireless Range	Up to 33 feet (10 meters)
Sound Quality	High-fidelity stereo with aptX codec
Noise Control	CVC 6.0 Noise Isolation
Water Resistance Rating	IPX Level 4 (sweatproof)
Battery Life (Talk Time)	Up to 5 hours
Battery Life (Music Play Time)	Up to 6 hours
Standby Time	Up to 100 hours
Charging Time	1-2 hours
Item Weight	18 Grams
Control Type	Volume Control
Form Factor	In Ear
Color	Jet Black

WARRANTY AND SUPPORT

Humix provides a **three-month no hassle replacement** for your headphones. If you encounter any issues or have questions regarding your Humix Wireless Headphones, please do not hesitate to contact our customer support team. Your satisfaction is our main priority.

For support, please refer to the contact information provided with your purchase or visit the official Humixx website.

© 2024 Humixx. All rights reserved.