

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Intex](#) /
- › [Intex Seahawk 3 Inflatable Boat Set Instruction Manual](#)

### Intex Seahawk 3 (2x68380EP)

# Intex Seahawk 3 Inflatable Boat Set Instruction Manual

Model: Seahawk 3 (2x68380EP)

Brand: Intex

## INTRODUCTION

This manual provides essential instructions for the safe assembly, operation, and maintenance of your Intex Seahawk 3 Inflatable Boat Set. Please read all instructions carefully before use and retain this manual for future reference.

The Intex Seahawk 3 is designed for recreational use on calm waters, suitable for up to three persons. It features heavy-duty PVC construction, an I-beam floor, and three air chambers for durability and stability.

## SAFETY INFORMATION

**WARNING: This is not a life-saving device. Do not leave child unattended while device is in use. See product for additional warnings.**

- Always wear a U.S. Coast Guard approved personal flotation device (PFD).
- Do not exceed the maximum weight capacity of 790 pounds (360 kg) or the maximum number of persons (3 adults).
- Never operate the boat under the influence of alcohol or drugs.
- Be aware of weather conditions and water currents. Avoid using in strong winds, rough waters, or during storms.
- Always check the boat for damage or leaks before each use.
- Keep away from sharp objects, hot surfaces, and open flames.
- Ensure all air chambers are properly inflated before entering the water.
- Children should only use the boat under competent adult supervision.

## PACKAGE CONTENTS

Verify that all components are present in your Intex Seahawk 3 package:

- 1 x Intex Seahawk 3 Inflatable Boat
- 2 x 48-inch Aluminum Oars
- 1 x Intex High-Output Hand Pump
- 1 x Repair Patch Kit (typically included)
- 1 x Instruction Manual



Image: The Intex Seahawk 3 boat set packaging, illustrating the inflatable boat, aluminum oars, and high-output pump included in the package.

## SETUP

### 1. Inflation

1. Unfold the boat on a clean, flat surface free of sharp objects.
2. Locate the Boston valves on each air chamber. The Seahawk 3 has three main air chambers.
3. Open the outer cap of the Boston valve. Insert the nozzle of the high-output hand pump into the valve.
4. Inflate each chamber sequentially until it is firm to the touch but not hard. Do not overinflate. The I-beam floor should be inflated last.
5. Once inflated, quickly remove the pump nozzle and close the inner and outer caps of the Boston valve securely. Ensure all valves are tightly sealed.



Image: A close-up view of the Intex Seahawk 3 inflatable boat, showing the high-output pump and one of the aluminum oars, ready for inflation and assembly.

## 2. Oar Assembly

1. Connect the two sections of each aluminum oar by aligning the push-button with the hole and snapping them together.
2. Insert the assembled oars into the oar locks located on the sides of the boat. Secure them in place.



Image: A detailed view of the Intex Seahawk 3 boat, highlighting the assembled aluminum oars securely placed in the oar locks on the side of the inflatable boat.

## OPERATING INSTRUCTIONS

### 1. Launching the Boat

- Carefully carry the inflated boat to the water's edge. Avoid dragging it over rough surfaces.
- Ensure the water is deep enough to prevent the boat from scraping the bottom.
- Enter the boat one person at a time, distributing weight evenly.

### 2. Rowing

- Sit comfortably on the inflatable seats.
- Place your hands on the oar handles and use a smooth, coordinated motion to propel the boat.
- The oar holders allow for easy rowing and can be used to secure the oars when not in use.

### 3. General Use

- Always maintain a safe distance from other watercraft and swimmers.

- Avoid standing up in the boat while on the water to maintain stability.
- If equipped, use the grab rope for assistance when entering or exiting the boat, or for holding onto in choppy water.



Image: Three individuals are shown enjoying a leisurely ride in the Intex Seahawk 3 inflatable boat on a calm body of water, demonstrating its capacity and use.

## MAINTENANCE

### 1. Cleaning

- After each use, rinse the boat thoroughly with fresh water to remove salt, sand, or dirt.
- Use a mild soap solution and a soft cloth to clean stubborn stains. Avoid harsh chemicals or abrasive cleaners.
- Ensure the boat is completely dry before deflating and storing to prevent mildew.

### 2. Storage

- Deflate all air chambers by opening the Boston valves.
- Fold the boat loosely to avoid sharp creases.
- Store the boat in a cool, dry place, away from direct sunlight and extreme temperatures.

### 3. Repairing Leaks

- If a small leak occurs, locate it by applying soapy water to the inflated surface; bubbles will indicate the leak.

- Clean and dry the area around the leak.
- Apply a repair patch from the included kit according to the kit's instructions. Allow sufficient time for the adhesive to cure before reinflating.

## TROUBLESHOOTING

- **Boat loses air quickly:** Check all Boston valves to ensure they are tightly closed. Inspect the boat surface for punctures or seam leaks. Use the repair kit for small punctures.
- **Difficulty inflating:** Ensure the pump nozzle is fully inserted into the Boston valve and the valve's inner cap is open during inflation.
- **Oars do not stay in place:** Verify that the oars are correctly assembled and securely placed in the oar locks.

## SPECIFICATIONS

Feature	Detail
Model Number	2x68380EP
Capacity	3 Persons
Maximum Weight Capacity	790 pounds (360 kg)
Dimensions (L x W x H)	116 x 54 x 17 inches (295 x 137 x 43 cm)
Material	Heavy-duty PVC
Air Chambers	3 (including I-beam floor)
Included Accessories	2 Aluminum Oars, High-Output Hand Pump
Color	Green

## PRODUCT OVERVIEW VIDEO

Your browser does not support the video tag.

Video: An official product video from Spreetail showcasing the Intex Seahawk 3 inflatable boat in various outdoor settings, demonstrating its features and use. This video provides a visual guide to the boat's capabilities and design.

## WARRANTY AND SUPPORT

For warranty information and customer support regarding your Intex Seahawk 3 Inflatable Boat Set, please refer to the documentation included with your purchase or contact the retailer directly. The product is manufactured by Intex. For purchases made through Spreetail, a 30-day easy returns policy and customer support are typically available. Please check your purchase details for specific terms.

