

[Manuals.plus](#) /

› [BALI OUTDOORS](#) /

› BALI OUTDOORS Fire Pit User Manual

BALI OUTDOORS Wood Burning Fire Pit, 32in

BALI OUTDOORS Fire Pit User Manual

Model: Wood Burning Fire Pit, 32in

Brand: BALI OUTDOORS

INTRODUCTION

Thank you for choosing the BALI OUTDOORS 32 inch Wood Burning Fire Pit. This versatile outdoor fire pit is designed to provide warmth, ambiance, and a convenient grilling surface for your patio or backyard gatherings. Its robust construction ensures long-term durability and safe operation.



The BALI OUTDOORS 32 inch Fire Pit, ready for use in an outdoor setting.

SAFETY INFORMATION

WARNING: This product can expose you to chemicals including carbon monoxide, which is known to the State of California to cause birth defects or other reproductive harm. For more information go to www.P65Warnings.ca.gov.

- Always use the fire pit on a flat, non-combustible surface, away from structures, trees, and other flammable materials.
- Do not use gasoline, kerosene, diesel fuel, lighter fluid, or alcohol to start or rekindle a fire.
- Never leave a burning fire pit unattended.
- Keep children and pets away from the fire pit.
- Ensure the fire is completely extinguished before leaving the area or covering the fire pit.
- Wear protective gloves or oven mitts when handling hot components, especially the grill.

Wear protective gloves or oven mitts to touch the handle of grill



Always wear protective gloves or oven mitts when touching the grill handle or any hot parts of the fire pit.

PACKAGE CONTENTS

Before assembly, ensure all parts are present and undamaged. Refer to the diagram below for component identification.

- Fire Bowl (24 inch)
- Grill (swivels 360 degrees, adjustable height)
- Fire Poker
- Collapsible Rack (for wood)
- Four Legs and Circular Steel Ring (base)
- Assembly Hardware (bolts, nuts, washers)



Key components of the BALI OUTDOORS Fire Pit, including the grill, fire poker, and collapsible wood rack.

ASSEMBLY INSTRUCTIONS

The BALI OUTDOORS Fire Pit is designed for quick and convenient assembly. Most users can complete assembly in less than 20 minutes.

1. Carefully unpack all components and lay them out on a clean, flat surface.
2. Attach the four legs to the main fire bowl using the provided hardware. Ensure all connections are secure.
3. Connect the circular steel ring to the bottom of the legs to provide additional stability.
4. Insert the collapsible rack into the fire bowl. This rack helps elevate the wood for better airflow and burning efficiency.
5. Assemble the grill support arm and attach it to the side of the fire pit.
6. Place the grill onto the support arm. The grill is designed to swivel 360 degrees and its height can be adjusted for optimal cooking.
7. Confirm all bolts are tightened and the fire pit is stable before use.




Grill swivels 360 Degree



Grill Height adjustment



Sturdy base design
features four legs



Make woods crisscross
for fully burning



Visual guide for assembly and key features like grill adjustment and base stability.

OPERATING INSTRUCTIONS

This fire pit is designed for use with wood as fuel. Its humanized design and stable structure ensure a safe and enjoyable experience.

1. **Placement:** Position the fire pit on a level, non-combustible surface, ensuring adequate clearance from any overhead or surrounding flammable materials.
2. **Fueling:** Place dry, seasoned firewood onto the collapsible rack within the fire bowl. The 24-inch fire bowl is designed to effectively contain sparks.
3. **Ignition:** Use appropriate fire starters to ignite the wood. Never use flammable liquids.
4. **Grilling (Optional):** If using the grill for cooking, rotate it into position over the flames. The grill can be easily rotated 360 degrees and adjusted up and down in height to control cooking temperature. Remember to wear protective gloves when adjusting the hot grill.

5. **Fire Management:** Use the provided fire poker to safely adjust logs and manage the fire. The grille screen around the bowl increases airflow for beautiful flames.
6. **Extinguishing:** Allow the fire to burn down naturally. Do not use water to extinguish the fire as this can damage the metal and create steam hazards. Once the embers are cool, dispose of ash safely.



Double Duty and Sturdy Construction

The 2-in-1 BALI OUTDOORS Wood-Burning Fire Pit provides heat and hotdogs, great for backyard BBQ's, family gatherings or staying warm.

The fire pit in use, demonstrating its capability for both warmth and grilling.

CARE AND MAINTENANCE

Proper care will extend the life of your BALI OUTDOORS Fire Pit, which is made of high-quality metal for long-term durability.

- **Cleaning:** After the fire pit has completely cooled, remove any ash and debris from the fire bowl. Use a stiff brush to clean the grill and fire bowl. Avoid abrasive cleaners that could damage the finish.
- **Protection:** To protect the fire pit from the elements and prevent rust, store it in a dry place or use a weather-resistant cover when not in use, especially during inclement weather or off-season.
- **Inspection:** Periodically inspect all components for signs of wear, damage, or loose connections. Tighten any loose bolts as needed.

TROUBLESHOOTING


Problem	Possible Cause	Solution
Difficulty starting fire	Wood is damp; insufficient kindling; poor airflow.	Use dry wood; add more kindling; ensure wood is placed on the collapsible rack for airflow.

Problem	Possible Cause	Solution
Excessive smoke	Damp wood; too much fuel; insufficient airflow.	Use dry wood; reduce amount of fuel; ensure proper spacing of logs.
Fire pit unstable after assembly	Loose connections; uneven ground.	Re-tighten all bolts; move fire pit to a level surface.

SPECIFICATIONS

Feature	Detail
Brand	BALI OUTDOORS
Model Number	Wood Burning Fire Pit, 32in
Material	Metal (Steel)
Product Dimensions	32"D x 32"W x 25"H
Item Weight	27 Pounds
Fuel Type	Wood
Color	Black
UPC	883432107499

DETAILED DIMENSION



Detailed dimensions of the BALI OUTDOORS Fire Pit.

WARRANTY AND SUPPORT

For warranty information, technical support, or any inquiries regarding your BALI OUTDOORS Fire Pit, please contact the manufacturer directly. Refer to the product packaging or the official BALI OUTDOORS website for contact details.

You can also visit the official BALI OUTDOORS store on Amazon for more information and products: [BALI OUTDOORS Store](#).

© 2023 BALI OUTDOORS. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B07H94KMZL>

More documents and user manuals: **<https://manuals.plus/>**