

[Manuals.plus](#) /

› [ASHATA](#) /

› ASHATA Wall Mounted Corded Landline Telephone User Manual

ASHATA

ASHATA Wall Mounted Corded Landline Telephone User Manual

Model: ASHATAugg95bshcw-01

INTRODUCTION

This manual provides comprehensive instructions for the setup, operation, and maintenance of your ASHATA Wall Mounted Corded Landline Telephone. This compact and functional telephone is designed for reliable communication in various environments, including homes, offices, and hotels. Please read this manual thoroughly before using the product to ensure proper functionality and longevity.

PRODUCT OVERVIEW

The ASHATA Corded Landline Telephone features a compact design with essential functions for daily communication. Key components include the handset, keypad, LCD display, and connection ports.



Front view of the ASHATA Wall Mounted Corded Landline Telephone, showing the keypad and LCD display.



The telephone unit with the handset separated, illustrating its compact design.

Key Features:

- **Dual Caller ID System:** Supports both DTMF and FSK caller ID protocols for incoming call identification.
- **LCD Display:** Shows month, date, hour, and minute, providing real-time information during calls or standby.
- **Incoming Call Memory:** Stores up to 38 sets of incoming call numbers, allowing for easy review and callback.
- **Multi-functional:** Includes features for checking and erasing incoming call memories.
- **Call Back Function:** Enables redialing of the last dialed number or a number from the incoming call memory.

SETUP INSTRUCTIONS

Follow these steps to set up your ASHATA Corded Landline Telephone:

1. **Unpack the Telephone:** Carefully remove all components from the packaging. Ensure you have the telephone unit and the telephone line cord.
2. **Connect the Telephone Line:** Locate the telephone line port on the back or side of the telephone unit. Insert one end of the provided telephone line cord into this port.
3. **Connect to Wall Jack:** Insert the other end of the telephone line cord into a standard RJ11 telephone wall jack.
4. **Place the Handset:** Place the handset onto the main telephone unit.
5. **Initial Power-Up:** The telephone draws power directly from the telephone line. The LCD display should illuminate, indicating the unit is powered on.



The telephone unit shown with its coiled handset cord and the straight telephone line cord for connection to the wall jack.

OPERATING INSTRUCTIONS

Making a Call:

1. Lift the handset.
2. Listen for a dial tone.
3. Dial the desired telephone number using the keypad.
4. Once the call is complete, replace the handset.

Answering a Call:

1. When the telephone rings, lift the handset.
2. Begin your conversation.
3. Once the call is complete, replace the handset.

Using Caller ID:

When an incoming call is received, the LCD display will show the caller's number (if available and subscribed to caller ID service). The telephone supports both DTMF and FSK systems.



LCD Display

Displaying month, date, hour, minute.
To let you know the real time when you dial/answer the telephone



Close-up view of the LCD display showing time and a sample phone number.

Reviewing Incoming Call Memories:

The telephone stores up to 38 incoming call records.

- Press the **"UP"** or **"DOWN"** arrow buttons (usually located near the LCD) to scroll through the stored numbers.
- To erase a specific memory, navigate to it and press the **"DEL"** button.
- To erase all memories, press and hold the **"DEL"** button for a few seconds.



Illustration highlighting the capacity to store 38 incoming call memories.

Using the Redial Function:

To redial the last number called:

1. Lift the handset.
2. Press the **"REDIAL"** button. The telephone will automatically dial the last outgoing number.

Re-dial Function

Allows you to call back the last number when you're not there to answer the phone in time



Close-up of the telephone's keypad, highlighting the "REDIAL" button.

Mute Function:

During a call, press the "**MUTE**" button to temporarily silence your microphone. The other party will not hear you. Press "**MUTE**" again to resume speaking.

MAINTENANCE

To ensure the longevity and optimal performance of your telephone, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to clean the exterior of the telephone. Do not use liquid cleaners, aerosols, or harsh chemicals, as these can damage the surface or internal components.
- **Avoid Moisture:** Keep the telephone away from water and excessive humidity. Do not operate it with wet hands.
- **Temperature:** Store and operate the telephone within normal room temperatures. Avoid extreme heat or cold.
- **Cable Management:** Ensure telephone cords are not tangled or pinched, which can lead to damage and signal loss.

TROUBLESHOOTING

If you encounter issues with your ASHATA telephone, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
No dial tone.	Telephone line not connected properly or line issue.	Ensure the telephone line cord is securely plugged into both the telephone and the wall jack. Test the wall jack with another phone if possible.
LCD display is blank or dim.	Insufficient power from the telephone line.	Check the telephone line connection. If the issue persists, the telephone line itself might have a low voltage issue.

Problem	Possible Cause	Solution
Caller ID not displaying.	Not subscribed to Caller ID service or service issue.	Contact your telephone service provider to confirm Caller ID service is active. Ensure the telephone is connected to a line that supports Caller ID.
Cannot hear caller or caller cannot hear me.	Handset not seated correctly or Mute function active.	Ensure the handset is properly placed on the unit. Check if the MUTE button is engaged.

SPECIFICATIONS

Feature	Detail
Brand	ASHATA
Model Number	ASHATAugg95bshcw-01
Telephone Type	Corded Landline
Caller ID System	DTMF/FSK Dual System
Display	LCD (Month, Date, Hour, Minute)
Incoming Memory	Up to 38 sets
Redial Function	Yes
Mute Function	Yes
Power Source	Corded Electric (Line Powered)
Product Dimensions (L x W x H)	7.68 x 2.36 x 2.17 inches (19.5 x 6 x 5.5 cm)
Item Weight	9.6 ounces (272 grams)
Color	Black



Diagram showing the dimensions of the telephone unit.

WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the documentation included with your purchase or contact ASHATA customer service. Keep your purchase receipt as proof of purchase for any warranty claims.

Manufacturer: ASHATA

Country of Origin: China

© 2024 ASHATA. All rights reserved.