

[Manuals.plus](#) /

› [SUPERJARE](#) /

› SUPERJARE Adjustable Counter Height Bar Stools (Model 7111Z) - Instruction Manual

SUPERJARE 7111Z

SUPERJARE Adjustable Counter Height Bar Stools (Model 7111Z) - Instruction Manual

INTRODUCTION

This manual provides comprehensive instructions for the assembly, operation, maintenance, and troubleshooting of your SUPERJARE Adjustable Counter Height Bar Stools (Model 7111Z). Please read this manual thoroughly before assembly and use to ensure safe and optimal performance of your product. Keep this manual for future reference.



Image: Two SUPERJARE Adjustable Counter Height Bar Stools, retro brown color.

SAFETY INFORMATION

- **WARNING:** Do not exceed the weight limit of 265 lbs.
- Ensure the stool is placed on a stable, flat surface to prevent tipping.
- Do not use on uneven or slippery surfaces.
- Keep hands and fingers clear of moving parts during height adjustment.
- Regularly check all bolts and connections to ensure they are tight.



Image: Detail of the stable and sturdy base with a plastic ring and the stainless steel lift mechanism.

PACKAGE CONTENTS

Before beginning assembly, verify that all parts are present and undamaged. If any parts are missing or damaged, please contact customer support.

- Seat with backrest (2 units)
- Central column with footrest (2 units)
- Base (2 units)
- Gas lift cylinder (2 units)
- Assembly hardware (screws, L-wrench)



Image: Exploded diagram illustrating all components required for assembly, including the seat, central column, footrest, and base.

SETUP AND ASSEMBLY

Assembly is straightforward and typically takes 5-10 minutes per stool. All necessary tools are included.

1. **Attach Seat to Central Column:** Align the seat with the top plate of the central column. Secure it using the provided screws and L-wrench.
2. **Insert Gas Lift into Base:** Place the gas lift cylinder into the center hole of the stool's base.
3. **Connect Seat Assembly to Base:** Carefully place the assembled seat and central column onto the gas lift cylinder, ensuring it is firmly seated.

Video: A detailed demonstration of the assembly process for the SUPERJARE Adjustable Counter Height Bar Stools, showing each step from unboxing to final setup.

OPERATING INSTRUCTIONS

Adjusting Height

The SUPERJARE bar stools feature a hydraulic cylinder for easy height adjustment. The height can be adjusted from 33.8 inches to 42.5 inches.

- **To Raise:** While standing, pull the height-adjustable lever upwards. The seat will automatically rise.

- **To Lower:** While seated, pull the height-adjustable lever upwards. Your weight will cause the seat to lower. Release the lever when the desired height is reached.

Swivel Function

The stools are designed with a 360-degree swivel function, allowing for smooth rotation without creaking.

360° SWIVEL ADJUSTABLE BAR STOOL



Max Weight
Capacity:
265lb

Image: The bar stool demonstrating its 360-degree swivel feature, indicating ease of rotation.

Video: A brief overview of the SUPERJARE Adjustable Bar Stools, highlighting their design and functionality.

MAINTENANCE

Proper care will extend the life and appearance of your bar stools.

- **Cleaning:** Wipe the seat and base with a damp cloth. For stubborn stains on the hot-stamping cloth, use a mild soap solution and wipe dry immediately. Avoid harsh chemicals.
- **Inspection:** Periodically check all screws and connections for tightness. Tighten if necessary to maintain stability.
- **Floor Protection:** The wider base includes a plastic ring to prevent floor scratching. Ensure this ring remains intact and in place.

OTHER BRAND



SUPERJARE



Safety is our top priority.
Ensure more stability, no need to worry about tipping over.

Image: Key features of the bar stool, including the soft gilded fabric and the plastic ring on the base for floor protection.

TROUBLESHOOTING

If you encounter any issues with your bar stools, refer to the following common solutions:

- **Stool feels unstable:** Ensure all assembly screws are securely tightened. Verify the stool is on a flat, even surface.
- **Height adjustment not working:** Check if the hydraulic lever is fully engaged. If the stool does not raise, ensure no weight is on the seat. If it does not lower, apply full body weight while pulling the lever.
- **Squeaking during swivel:** Apply a small amount of silicone-based lubricant to the swivel mechanism beneath the seat.

SPECIFICATIONS

Feature	Specification
Product Dimensions	18.5"D x 18.1"W x 42.5"H
Color	Retro Brown
Brand	SUPERJARE
Size (Height Range)	24.4" to 42.5"
Style	Modern/Industrial
Furniture Finish	Retro Brown
Seat Height	Adjustable, up to 32.2 Inches
Maximum Weight Recommendation	265 Pounds
Product Care Instructions	Wipe with Damp Cloth
Assembly Required	Yes
Number of Items	2
Item Weight	33.8 pounds
Frame Material	Metal
Seat Material Type	Unique hot-stamping cloth

Dimensions

Maximum Load: 265lbs




Image: Dimensional drawing of the bar stool, detailing its height, width, depth, and maximum load capacity of 265 lbs.

WARRANTY AND SUPPORT

SUPERJARE products are designed for quality and durability. For specific warranty information, please refer to the product packaging or contact SUPERJARE customer service directly. If you have any questions, require assistance, or need to report a defect, please visit the official SUPERJARE website or contact their customer support team.

Contact Information: Please refer to the contact details provided on the product packaging or the official SUPERJARE website for the most up-to-date support information.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B07H9SBJDJ>

More documents and user manuals: <https://manuals.plus/>