

Vifa Copenhagen 2.0

Vifa Copenhagen 2.0 Portable Bluetooth Speaker User Manual

Model: Copenhagen 2.0

1. INTRODUCTION

The Vifa Copenhagen 2.0 is a high-quality portable Bluetooth speaker designed to deliver authentic sound with a minimalist aesthetic. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your speaker to ensure optimal performance and longevity.



Front view of the Vifa Copenhagen 2.0 speaker, showcasing its minimalist design and fabric grille.



Detail shot of the Vifa logo subtly embossed on the speaker's integrated handle.

An official video showcasing the Vifa Copenhagen 2.0 speaker's design, portability, and integration into daily life, emphasizing its aesthetic and sound quality.

2. PACKAGE CONTENTS

Please check that all items are present in the package:

- Vifa Copenhagen 2.0 Speaker
- Power Cable
- AUX 3.5 mm Mini Jack Cable
- Travel Bag
- Quick-Guide
- Warranty Information

3. SETUP

3.1 Powering On/Off

- To power on the speaker, press and hold the power button (usually indicated by a circle icon) on the side of the unit until the indicator light illuminates.
- To power off, press and hold the power button again until the indicator light turns off.

3.2 Charging the Battery

Before first use, fully charge the speaker. Connect the provided power cable to the speaker's power input and then to a wall outlet. The charging indicator light will show the charging status.

- The speaker is powered by 1 Lithium Ion battery (included).

3.3 Initial Connection (Bluetooth)

1. Ensure the speaker is powered on.
2. Activate Bluetooth on your audio device (smartphone, tablet, computer).
3. On your device, search for available Bluetooth devices and select "Vifa Copenhagen 2.0".
4. Once connected, the speaker will indicate a successful pairing, and you can begin playing audio.

3.4 Wi-Fi Setup & Vifa Home App

For advanced features like Wi-Fi streaming and multi-room audio, download the Vifa Home App from your device's app store.

1. Download and install the Vifa Home App.
2. Follow the in-app instructions to connect your Vifa Copenhagen 2.0 speaker to your Wi-Fi network.
3. The app allows streaming from services like Spotify, TIDAL, iHeartRadio, Napster, Qobuz, and Amazon Music, as well as Airplay and DLNA.



A smartphone screen displaying the Vifa Home application interface, used for managing speaker settings and multi-room configurations.


4. OPERATING THE SPEAKER

4.1 Audio Playback

- **Bluetooth:** Connect your device via Bluetooth as described in Section 3.3.
- **Wi-Fi Streaming:** Use the Vifa Home App to stream music directly from supported services or via Airplay/DLNA.
- **AUX Input:** Connect an audio device using the provided 3.5 mm mini jack cable to the AUX port on the speaker.

4.2 Volume Control


Adjust the volume using the dedicated volume buttons on the speaker or through your connected audio device.



Close-up view of the control buttons located on the side of the speaker, including power, volume up, and volume down.

4.3 Multi-Room System

The Vifa Home App allows you to create a multi-room audio system by interconnecting multiple Vifa Copenhagen 2.0 or Stockholm 2.0 speakers. Refer to the app's instructions for detailed setup.



Graphic depicting icons for multi-room audio setup, indicating the speaker's capability to connect with other units.

5. MAINTENANCE

5.1 Cleaning

- Gently wipe the speaker's exterior with a soft, dry cloth.
- Do not use liquid cleaners or abrasive materials, as these can damage the finish or fabric.

5.2 Battery Care

- To prolong battery life, avoid fully discharging the battery frequently.
- Store the speaker in a cool, dry place when not in use for extended periods.

6. TROUBLESHOOTING

If you encounter issues with your Vifa Copenhagen 2.0, refer to the following common solutions:

- **No Power:** Ensure the speaker is charged. Connect the power cable and verify the charging indicator.
- **Bluetooth Connectivity Issues:**
 - Ensure the speaker is in pairing mode.
 - Check that your audio device's Bluetooth is enabled and within range (up to 100 meters).
 - Try unpairing and re-pairing the speaker from your device's Bluetooth settings.
- **Wi-Fi Streaming Problems:**
 - Verify your Wi-Fi network is active and the speaker is connected via the Vifa Home App.
 - Ensure the Vifa Home App is updated to the latest version for compatibility with your device's operating system.
 - Restart your Wi-Fi router and the speaker.
- **No Sound:**
 - Check the volume levels on both the speaker and your connected device.
 - Ensure the correct input source (Bluetooth, Wi-Fi, AUX) is selected.
- **Speaker Not Responding:** If the speaker becomes unresponsive, try a soft reset by holding down

the power button for an extended period (e.g., 10-15 seconds) until it powers off and then restart it.

7. SPECIFICATIONS




Diagram illustrating the dimensions of the Vifa Copenhagen 2.0 speaker: 14.8 inches (36.2 cm) wide, 10.6 inches (26.8 cm) high, and 3.5 inches (9 cm) deep.

Feature	Detail
Model Name	Copenhagen 2.0
Speaker Type	Surround Sound Speaker
Special Feature	Portable
Recommended Uses	Music, Home, Multi-room Audio System
Surround Sound Channel Configuration	2.0
Color	Gray
Item Weight	10.25 pounds
Product Dimensions	3.54 x 14.25 x 10.55 inches
Is Waterproof	FALSE
Control Method	App
Wireless Communication Technology	Airplay, Bluetooth, Wi-Fi
Power Source	Battery Powered

Number of Batteries	1 Lithium Ion batteries required (included)
Audio Driver Type	Dynamic Driver (two tweeters, two midrange drivers, and two woofers)
Bluetooth Range	100 Meters
Speaker Maximum Output Power	25 Watts
Manufacturer	Vifa

8. WARRANTY AND SUPPORT

The Vifa Copenhagen 2.0 includes warranty information within its packaging. For detailed warranty terms and conditions, please refer to the included documentation. For further support, technical assistance, or service inquiries, please visit the official Vifa website or contact their customer service department.