

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [LitterMaid](#) /

› [LitterMaid Multi-Cat Self-Cleaning Litter Box 10 Piece Set \(Version 3.2\) Instruction Manual](#)

LitterMaid P-70016

LitterMaid Multi-Cat Self-Cleaning Litter Box (Version 3.2)

Model: P-70016

Brand: LitterMaid

INTRODUCTION

The LitterMaid Multi-Cat Self-Cleaning Litter Box is designed to provide a clean and fresh environment for your cats with minimal effort. This system automatically scoops waste, helping to maintain hygiene and reduce odors. It is suitable for multiple cats weighing over 15 lbs.

When used as directed, the self-cleaning mechanism eliminates the need for daily scooping for up to 7 days, offering a low-maintenance solution for cat owners.

SAFETY INFORMATION

CAUTION: Not intended for use with kittens less than 6 months old or weighing less than 5 lbs. If your kitten is under 6 months of age or weighs less than 5 pounds, leave the unit UNPLUGGED and scoop waste manually until the kitten is 6 months old and weighs more than 5 pounds.

Always ensure the unit is unplugged before performing any maintenance or cleaning tasks to prevent accidental activation.

PACKAGE CONTENTS

Your LitterMaid Multi-Cat Self-Cleaning Litter Box 10 Piece Set includes the following items:

- 1 x Self-Cleaning Litter Box Unit
- 4 x Waste Receptacles
- 4 x Carbon Filters
- 1 x Scoop and Rake Cleaner
- 1 x Paw Cleaning Ramp



Image: The LitterMaid Multi-Cat Self-Cleaning Litter Box shown with its main unit, four waste receptacles, four carbon filters, a scoop and rake cleaner, and a paw cleaning ramp.

SETUP INSTRUCTIONS

Follow these steps for initial setup of your LitterMaid Self-Cleaning Litter Box:

1. **Prepare the Waste Receptacle:** Place a waste receptacle underneath the compartment cover in the designated space. Ensure the front edge is securely positioned under the 5 tabs on the front edge of the litter tray.
2. **Attach Waste Receptacle Lid:** Insert the PUSH tabs of the waste receptacle lid into the round holes on the compartment cover. Secure the lid by slipping its edges under the tabs on the waste receptacle compartment cover.
3. **Install Carbon Filter:** Remove a carbon filter from its plastic sleeve and peel off the paper strip to expose the adhesive. Place the filter, adhesive side down, into the diamond-shaped insert in the center of the waste receptacle lid.
4. **Attach Paw Cleaning Ramp:** Snap the two notches of the paw cleaning ramp into the attachment posts on the top housing, directly in front of the waste receptacle compartment cover. Tug slightly on the ramp to ensure it is firmly in place.
5. **Fill with Litter:** Fill the litter tray with hard clumping litter so that the litter level is between the MIN and MAX fill lines located on either side of the box. Use the provided scoop to evenly distribute the litter.
6. **Connect Power:** Plug the unit into a standard electrical outlet.


Easy Setup Instructions:



1.
Load receptacle and charcoal filter.



2.
Allow to automatically work for up to 7 days.



3.
Receptacles seal tight for easy, no-smell disposal.

Image: Visual guide illustrating the three easy setup steps: loading the receptacle and charcoal filter, allowing automatic operation, and sealing receptacles for disposal.

OPERATING INSTRUCTIONS

The LitterMaid Self-Cleaning Litter Box operates automatically to maintain a clean litter bed.

- **Automatic Cleaning Cycle:** The unit features a smart-detection motion sensor. When your cat uses the litter box, the sensor is blocked. As your cat exits the box, the sensor becomes unblocked and initiates a cleaning cycle. The cleaning cycle will officially begin after a 10-minute delay to ensure your cat has fully left the box.
- **Rake Mechanism:** During the cleaning cycle, an automatic rake moves across the litter tray, sifting through the litter and scooping solid waste into the covered waste receptacle.
- **Odor Control:** The waste receptacles, combined with carbon filters, effectively contain odors until they are ready for disposal.
- **Litter Scatter Prevention:** High walls on the litter box help prevent litter scatter, and the paw cleaning ramp helps remove litter from your cat's paws, reducing tracking around the box.



Image: The LitterMaid unit highlighting its key features: removable automatic rake, high walls, smart-detection motion sensor, paw cleaning ramp, scoop & rake cleaner, and waste receptacle with carbon filter.

LITTER RECOMMENDATIONS

For optimal performance, use **hard clumping litter** with your LitterMaid Self-Cleaning Litter Box. All clumping litters are safe to use with this box.

Ensure the litter level is maintained between the MIN and MAX fill lines to allow the rake to function correctly and prevent issues.

MAINTENANCE

The LitterMaid Self-Cleaning Litter Box is designed for low maintenance, requiring no daily scooping for up to 7 days when used as directed.

- **Waste Receptacle Replacement:** Regularly check the waste receptacle. When full, simply remove the old receptacle, seal it for odor containment, and dispose of it. Replace with a new waste receptacle and carbon filter.
- **Rake Cleaning:** Periodically inspect the automatic rake for any stuck litter or debris. Use the provided scoop and rake cleaner to remove any buildup.

- **Unit Cleaning:** For deeper cleaning, unplug the unit and wipe down the litter tray and surrounding areas with a pet-safe cleaner.

SPECIFICATIONS

Feature	Detail
Model Number	P-70016
Item Weight	14.15 Pounds
Product Dimensions	27"L x 18"W x 10"H
Material	Plastic
Target Audience	House-cats (Adult, Multi-Cat over 15 lb)
Included Components	Litter Box, 4 Waste Receptacles, 4 Carbon Filters, 1 Scoop and Rake Cleaner, 1 Paw Cleaning Ramp
First Available Date	September 13, 2018

TROUBLESHOOTING

If the unit is not functioning as expected, please check the following:

- Ensure the unit is properly plugged into a working electrical outlet.
- Verify that the litter level is between the MIN and MAX lines. Incorrect litter levels can impede rake movement.
- Check for any obstructions in the litter tray that might be blocking the rake.
- Confirm that the waste receptacle and its lid are correctly installed.
- If the sensor light is blinking, ensure no cat is currently in the box or has recently exited, allowing the 10-minute delay to complete.

WARRANTY & SUPPORT

This LitterMaid product comes with a **1-year Limited Warranty**.

For further assistance, troubleshooting, or warranty claims, please refer to the contact information provided in your product packaging or visit the official LitterMaid website.