

[Manuals.plus](#) /

› [Superer](#) /

› Superer AC Charger Instruction Manual for Amazon Kindle Paperwhite E-Reader (Model PSD0502000US)

## Superer PSD0502000US

# Superer AC Charger Instruction Manual

Model: PSD0502000US

## 1. INTRODUCTION

This manual provides essential instructions for the safe and effective use of your Superer AC Charger. This charger is designed to provide reliable power for various Amazon Kindle E-readers and tablets. Please read this manual thoroughly before use and retain it for future reference.

### Package Contents:

- 1 x Superer AC Wall Charger
- 1 x 5FT Micro USB Charging Cable

## 2. PRODUCT OVERVIEW

The Superer AC Charger is a compact and efficient power adapter designed for compatibility with a range of Amazon devices. It features a durable casing and a 5-foot long Micro USB cable for convenient charging.

# UL Listed & Safety Protection

UL Listed meets the highest standards for electrical safety. Providing VI security protection.



# VI



**Short  
Circuiting  
Protection**



**Overvoltage  
Protection**



**Overcurrent  
Protection**



**Overheating Pro-  
tection**

Image: The Superer AC charger unit connected to its Micro USB cable.

## Key Features:

- **UL Listed:** Meets high electrical safety standards.
- **Safety Protections:** Includes safeguards against short-circuiting, overvoltage, overcurrent, and overheating.
- **Portable Design:** Compact and easy to carry.
- **Durable Cable:** 5-foot long Micro USB cable with aluminum shielding and 30-AWG wiring for enhanced durability.

# Why Choose Us?



- ✓ Our charger are listed by **Underwriters Laboratories (UL)** and meet or exceed National Electrical Code requirements
- ✓ Tested to meet US **Department of Energy(DOE)** and **Occupational Safety and Health Administration (OSHA)**
- ✓ We have the most **professional technical engineers, qualified auditors**, passionate and patient **customer service** personnel.



- ✗ **NO UL Listed,Failure to meet electrical safety standards**
- ✗ **Cheaper materials may cause laptop damage !**
- ✗ **Unknown channels of production**



Image: Diagram illustrating the UL listing and various safety protections (short circuit, overvoltage, overcurrent, overheating) integrated into the charger.

# Portable Design

Smaller appearance than the iPhone

Efficient  
Charging

Compact  
Design

Robust Casing




Image: The compact Superer charger shown next to a smartphone to illustrate its portable size.

## About our Customer Service



## Superior Durability

UL Power Cord effortlessly withstands every tug, twist, and tangle



## Extra Long Power Cord

Total 5Ft Power Cable provides more convenience for your life



Image: An illustration detailing the internal wiring (aluminum shielding, insulation, 30-AWG wiring) of the durable 5-foot power cord.

### 3. SETUP INSTRUCTIONS

Follow these steps to set up your Superer AC Charger:

1. **Verify Compatibility:** Ensure your device uses a Micro USB port for charging. This charger is not compatible with USB Type-C ports.



Image: A visual comparison between a Micro USB connector (correct for this charger) and a USB Type-C connector (incorrect).

2. **Connect Cable:** Insert the Micro USB end of the charging cable into the charging port of your Amazon Kindle E-reader or compatible device.
3. **Plug into Power:** Insert the AC wall charger into a standard 110V electrical outlet.

## 4. OPERATING INSTRUCTIONS

Once connected, your device will begin charging automatically. The charging indicator on your device (if available) will typically illuminate or change status to show that it is receiving power.

- For optimal charging, ensure the charger and cable are securely connected.
- Charging times may vary depending on the device model and its current battery level.
- Disconnect the charger from the wall outlet and your device once charging is complete or when not in use.

## 5. MAINTENANCE

To ensure the longevity and proper functioning of your Superer AC Charger:

- Keep the charger and cable clean and dry. Avoid exposure to liquids or excessive humidity.
- Do not expose the charger to extreme temperatures.
- Avoid bending or twisting the cable excessively, especially near the connectors, to prevent internal damage.
- Store the charger in a cool, dry place when not in use.
- Regularly inspect the cable and charger for any signs of damage, such as frayed wires or cracked casing. Discontinue use if damage is observed.

## 6. TROUBLESHOOTING

If you encounter issues with your Superer AC Charger, refer to the following common solutions:

| Problem             | Possible Cause                                                                    | Solution                                                                                                                                                                        |
|---------------------|-----------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Device not charging | Loose connection<br>Faulty outlet<br>Incompatible device<br>Damaged cable/charger | Ensure cable is firmly connected to both charger and device. Try a different wall outlet. Verify device uses Micro USB. Inspect cable/charger for damage; replace if necessary. |

| Problem           | Possible Cause                                           | Solution                                                                                                                                                     |
|-------------------|----------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Slow charging     | Device in heavy use during charging<br>Cable degradation | Avoid using the device for demanding tasks while charging. Ensure the cable is not damaged.                                                                  |
| Charger feels hot | Normal operation<br>Overload/Fault                       | A slight warmth is normal. If the charger becomes excessively hot to touch or emits smoke/smell, immediately unplug it and discontinue use. Contact support. |

## 7. SPECIFICATIONS

| Feature            | Detail                                                                                                                                                                                                                                                                         |
|--------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Model Number       | PSD0502000US                                                                                                                                                                                                                                                                   |
| Input Voltage      | 110 Volts                                                                                                                                                                                                                                                                      |
| Amperage           | 2 Amps                                                                                                                                                                                                                                                                         |
| Total USB Ports    | 1                                                                                                                                                                                                                                                                              |
| Connector Type     | Micro USB Connector                                                                                                                                                                                                                                                            |
| Cable Length       | 5 Feet                                                                                                                                                                                                                                                                         |
| Color              | Black                                                                                                                                                                                                                                                                          |
| Weight             | 2.89 ounces                                                                                                                                                                                                                                                                    |
| Compatible Devices | Amazon Kindle Paperwhite E-reader, Kindle Voyage, Echo Dot, Kindle Oasis E-reader, Fire HD 10, Fire HD 8 / HD 8 Kids Edition Tablet, Kindle Fire HDX 8.9", Fire 7 / Fire 7 Kids Edition / HDX 7" Tablet, Fire HD 6 tablet, Amazon Tap, Kindle Fire HD 10 Tablet 9th generation |

## 8. WARRANTY AND SUPPORT

Superer stands behind the quality of its products.

- **30-Day Money Back Guarantee:** If you are not satisfied with your purchase, you may return it within 30 days for a full refund.
- **1-Year Warranty:** This product is covered by a 1-year warranty against manufacturing defects.
- **Customer Service:** For any questions, concerns, or warranty claims, please contact Superer customer service.

© 2026 Superer. All rights reserved.

**ASK A QUESTION ABOUT THIS MANUAL**

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

---

Open the live page

<https://manuals.plus/asin/B07HCGFTJZ>

More documents and user manuals: <https://manuals.plus/>