

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [TOWER](#) /

› [Duo Electric Salt/Pepper Mill, Black Instruction Manual](#)

TOWER T847004B

TOWER Duo Electric Salt/Pepper Mill Instruction Manual

Model: T847004B

INTRODUCTION

Thank you for choosing the TOWER Duo Electric Salt/Pepper Mill. This elegantly designed mill provides effortless seasoning for your culinary needs. Its dual-chamber design allows for both salt and pepper grinding from a single unit, offering convenience and style to your kitchen or dining table. Please read this manual thoroughly before use to ensure proper operation and maintenance.

SAFETY INFORMATION

- Keep out of reach of children.
- Do not immerse the unit in water or any other liquid.
- Do not use abrasive cleaners or scouring pads to clean the unit.
- Ensure hands are dry when handling batteries.
- Do not mix old and new batteries, or different types of batteries.
- Remove batteries if the unit is not used for extended periods.
- This appliance is for domestic use only.

PRODUCT OVERVIEW

The TOWER Duo Electric Salt/Pepper Mill features a durable ABS body with clear acrylic chambers for easy viewing of contents. It is designed for convenient, one-handed operation.





Figure 1: Front view of the TOWER Duo Electric Salt/Pepper Mill.

DUO ELECTRIC SALT & PEPPER MILL



Space
Saving



Stylish
Silver
Accents



Battery
Operated



Individual
Push
Buttons



Adjustable
Ceramic
Grinders



Figure 2: Key features including 2-in-1 design, stylish accents, battery operation, individual buttons, and adjustable ceramic grinders.



Figure 3: Product dimensions for placement and storage.

SETUP

1. Battery Installation

1. Twist the top section of the mill counter-clockwise to separate it from the clear acrylic chambers.
2. Locate the battery compartment. The mill requires 6 x AA batteries (not included).
3. Insert the batteries according to the polarity markings (+/-) inside the compartment.
4. Align the top section with the clear chambers and twist clockwise to secure.



With Adjustable Ceramic Grinders



Figure 4: View of the battery compartment and the adjustable ceramic grinders.

2. Filling the Chambers

1. With the top section removed, you will see two separate clear acrylic chambers.
2. Fill one chamber with salt (e.g., coarse sea salt or Himalayan salt) and the other with whole peppercorns.
3. Avoid overfilling to prevent spillage when reattaching the top section.
4. Carefully reattach the top section by aligning and twisting clockwise until secure.



Durable & Smooth ABS Body Construction

Easy to fill clear acrylic chambers with large capacity, never run out of salt or pepper on the dinner table

Presented in a stylish black coating and modern silver accents, perfect for a contemporary kitchen



Figure 5: The clear acrylic chambers are easy to fill with salt and pepper.

OPERATING INSTRUCTIONS

1. Grinding Salt or Pepper

- Identify the 'S' button for salt and the 'P' button for pepper on the side of the mill.
- Hold the mill over your food or dish.
- Press and hold the desired button ('S' or 'P') to activate the grinding mechanism. Release the button to stop grinding.



TOWER

Individual Push Buttons to Grind Salt or Pepper

Effortless grinding with simple button operation.
The 2-in-1 duo mill saves space on your worktop.

Figure 6: The mill features individual push buttons for effortless salt or pepper seasoning.

2. Adjusting Grind Size

- The mill features an adjustable ceramic grinder.
- To adjust the grind size (fine to coarse), locate the adjustment mechanism at the bottom of the mill (underneath the clear chambers).
- Turn the adjustment knob or ring to your desired setting. Turning clockwise typically results in a finer grind, while counter-clockwise results in a coarser grind.

MAINTENANCE

Cleaning

- The TOWER Duo Electric Salt/Pepper Mill is **NOT** dishwasher safe.
- To clean, wipe the exterior with a damp cloth.
- For the grinding mechanism, use a small brush to remove any residual salt or pepper.

- Ensure all parts are completely dry before reassembling or storing.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Mill not grinding.	Batteries are low or incorrectly installed.	Replace batteries with 6 new AA batteries, ensuring correct polarity.
Mill not grinding.	Chambers are empty.	Refill salt or pepper chambers.
Mill not grinding.	Grinding mechanism is jammed.	Carefully clear any blockages from the grinding mechanism using a small brush.
Mess during refilling.	Chambers overfilled or not properly aligned.	Do not overfill chambers. Ensure the top section is securely twisted onto the base after refilling.
Grind size is inconsistent.	Grind adjustment needs fine-tuning.	Adjust the ceramic grinder setting at the bottom of the mill until desired consistency is achieved.

SPECIFICATIONS

Brand: TOWER

Model: T847004B

Material: Plastic (ABS Body)

Color: Black

Operation Mode: Automatic

Product Dimensions: 2.72"W x 8.46"H

Item Weight: 10.8 ounces

Batteries Required: 6 x AA (not included)

Care Instructions: Hand Wash Only (Not Dishwasher Safe)

WARRANTY & SUPPORT

The TOWER Duo Electric Salt/Pepper Mill comes with a standard 1-year manufacturer's guarantee. An optional 2-year extension is available upon product registration online, providing a total of 3 years of coverage.

For further support, please refer to the contact information provided with your purchase or visit the official TOWER website.

**Trusted
Tower® Quality**



***Standard 1 year manufacturer's guarantee
and a 2 year extension, subject to product
registration online**

Figure 7: Information regarding the 3-year guarantee.