

[Manuals.plus](#) /

› [DRomance](#) /

› DRomance Flameless Flickering Candles with Remote and Timer Instruction Manual

DRomance DDDSET-6LL

DRomance Flameless Flickering Candles Instruction Manual

Model: DDDSET-6LL

INTRODUCTION

Thank you for choosing DRomance Flameless Flickering Candles. This set of six ivory LED pillar candles provides a safe and elegant lighting solution with the realistic appearance of dripping wax. Designed for indoor use, these battery-operated candles feature a remote control and timer functions for convenient operation. Please read this manual thoroughly before use to ensure proper setup and enjoyment of your product.



Image: A complete set of DRomance flameless flickering candles with the included remote control.

PACKAGE CONTENTS

Your DRomance Flameless Flickering Candles package includes the following items:

- 1 x Dripping Wax Flameless Candle (2.2" x 4")
- 1 x Dripping Wax Flameless Candle (2.2" x 5")
- 1 x Dripping Wax Flameless Candle (2.2" x 6")
- 1 x Dripping Wax Flameless Candle (2.2" x 7")
- 1 x Dripping Wax Flameless Candle (2.2" x 8")
- 1 x Dripping Wax Flameless Candle (2.2" x 9")
- 1 x 10-Key Remote Control (battery included)
- 1 x User Manual

SETUP

1. Battery Installation (Candles)

1. Locate the battery compartment at the bottom of each candle.
2. Twist the battery cover counter-clockwise to open.
3. Insert **two high-quality AA batteries** into each candle, ensuring the correct polarity (+/-). Batteries are **not included** with the candles.
4. Replace the battery cover by twisting it clockwise until securely closed.



Image: View of the candle's base, illustrating battery insertion.

2. Remote Control

The 10-key remote control comes with a pre-installed battery. If the remote does not function, check if the plastic insulation tab needs to be removed from the battery compartment. If the remote's battery needs replacement, use a CR2025 coin cell battery.



Image: The 10-key remote control for operating the candles.

OPERATING INSTRUCTIONS

The candles can be operated using the included 10-key remote control. Ensure the remote is pointed towards the candles for optimal response.

Remote Functions:

- **ON/OFF:** Press the **ON** button to turn all candles on. Press the **OFF** button to turn all candles off.
- **Timer:** Select a timer setting (2H, 4H, 6H, 8H). Once set, the candles will automatically turn on for the selected duration and then turn off, repeating the cycle every 24 hours.
- **Mode:** Toggle between **Candle** mode (flickering flame) and **Light** mode (steady glow).
- **Brightness:** Use the **+** and **-** buttons to adjust the brightness level of the candles.

Your browser does not support the video tag.

Video: This video demonstrates the flickering and non-flickering modes, as well as the brightness adjustment features of the DRomance LED Flickering Pillar Candles using the remote control.

MAINTENANCE

- **Cleaning:** Wipe the candles with a soft, dry cloth to remove dust. Do not use abrasive cleaners or immerse in water.
- **Battery Replacement:** Replace batteries when the light dims or the candles stop responding. Always replace all batteries in a set at the same time for consistent performance.
- **Storage:** If storing the candles for an extended period, remove the batteries to prevent leakage and damage. Store in a cool, dry place away from direct sunlight.
- **Heat Exposure:** Although made of real wax, avoid placing candles in direct sunlight or near heat sources, as this may cause the wax to melt or deform.

TROUBLESHOOTING

- **Candles not turning on:**
 - Ensure batteries are inserted correctly with the correct polarity.
 - Replace old batteries with new, high-quality AA batteries.
 - Check if the battery compartment cover is securely closed.
- **Remote control not working:**
 - Ensure the plastic insulation tab has been removed from the remote's battery compartment.
 - Replace the remote's CR2025 battery if necessary.
 - Point the remote directly at the candles within a reasonable range.
- **Timer function not working as expected:**
 - Setting the timer manually resets any previous timer cycle. If you manually turn candles on/off, you may need to re-set the timer.
 - Ensure the remote has a clear line of sight to the candles when setting the timer.
- **Candles appear dim:**
 - Adjust brightness using the '+' button on the remote.
 - Replace batteries if they are low.

SPECIFICATIONS

Feature	Detail
Material	Real Wax
Color	Ivory
Diameter	2.2 inches
Heights	4", 5", 6", 7", 8", 9"

Feature	Detail
Light Type	LED Flickering
Light Color	Amber Yellow
Battery (Candles)	2 x AA Batteries (Not Included)
Battery (Remote)	CR2025 (Included)
Timer Settings	2H, 4H, 6H, 8H
Control Method	10-Key Remote Control (Infrared)
Indoor/Outdoor Usage	Indoor Use Only
Model Number	DDDSET-6LL
UPC	799649798477




Image: Visual representation of the different candle heights included in the set.

SAFETY INFORMATION

- This product is intended for indoor use only.
- Keep out of reach of children and pets.
- Do not mix old and new batteries, or different types of batteries.
- Dispose of used batteries responsibly according to local regulations.
- Do not attempt to modify or disassemble the candles or remote control.
- Avoid prolonged exposure to direct sunlight or high temperatures, as this may damage the wax or internal components.

WARRANTY AND SUPPORT

Each DRomance LED candle is thoroughly tested before leaving the factory to ensure quality and performance. We offer a satisfaction guarantee for our products.

If any problems occur with your dripping wax candles, please contact our customer support team. We are committed to providing a satisfactory solution to any issues you may encounter.

For customer support, please refer to the contact information provided with your purchase or visit the DRomance official website.