

HiLIFE HL7


HiLIFE Portable Handheld Garment Steamer Instruction Manual

Model: HL7 | Brand: HiLIFE

1. IMPORTANT SAFETY INSTRUCTIONS

Please read all instructions carefully before using your HiLIFE Garment Steamer. Failure to follow these instructions may result in injury or damage to the product.

- **Power Requirement:** This steamer is designed for use **ONLY** in 110-120V countries and regions (e.g., US, Canada, Japan). Plugging into a 220V-240V outlet will damage the product and may pose a safety risk.
- **Water Level:** Do not exceed the 'MAX' water line indicated on the tank. Overfilling may cause hot water to spray.
- **Water Type:** For a longer lifespan and to prevent mineral buildup, we recommend using purified or distilled water. Avoid adding any chemical substances, perfumes, or other additives to the water tank, as this can damage the device and cause hot water spray.
- **Operating Position:** Always hold the steamer upright during operation. Do not tilt the steamer excessively, as this may cause hot water to spill or spray.
- **Hot Surfaces:** The steam nozzle and surrounding areas become extremely hot during use. **DO NOT TOUCH** the nozzle while it is hot. Allow the steamer to cool completely before handling or storing.
- **Steam Direction:** Only point the working steamer against clothes or other applicable fabrics. Do not point the steamer at humans, pets, or any part of your body.





Not over the Max water line!
It may cause hot water spray.



Please hold the steamer upright.



Please only point the working steamer
against clothes or other applicable fabrics



Please only use distilled or purified. Other-
wise the deposition of impurities in the
water tank which may cause water spray.



Please do not touch
the nozzle while it is hot



No tilting the steamer



Please do not point the steamer
against human or pets



Please do not add any chemical substance
into the water, it will cause damage to the
device and hot water spray.

Visual guide for safe operation of the HiLIFE Garment Steamer, highlighting correct water levels and handling.

2. PRODUCT OVERVIEW

The HiLIFE Portable Handheld Garment Steamer is designed for quick and efficient wrinkle removal from various fabrics, offering a convenient alternative to traditional ironing.



The HiLIFE Portable Handheld Garment Steamer.

What's in the Box:

- HiLIFE Garment Steamer Unit
- Measuring Cup
- Fabric Brush Attachments (2)

**Continuously
Steaming For
15 Minutes**

1 High Power
700W

2 Large Capacity
240ML

3 Long Working Time
Up to 15
Minutes Continuous Steaming



Key features: 700W power, 240ml capacity for up to 15 minutes of continuous steam.

Lightweight, Compact and Portable

Easy to use, store and perfect for home, office and travel



The steamer's lightweight, compact, and portable design makes it ideal for home, office, and travel.

3. SETUP

1. **Remove Steam Head:** Twist the steam head counter-clockwise to detach it from the main unit.
2. **Fill Water Tank:** Using the provided measuring cup, carefully pour purified or distilled water into the water tank opening. Ensure the water level does not exceed the 'MAX' line.
3. **Reattach Steam Head:** Place the steam head back onto the unit and twist clockwise until it locks securely into place.
4. **Attach Fabric Brush (Optional):** For certain fabrics or to remove lint, you may attach one of the fabric brush guards to the steam head by clipping it on.

02.

9.2 FT

Easily iron clothes
from a distance



Garment steamer



Filling the water tank of the HiLIFE steamer.

4. OPERATING INSTRUCTIONS

1. **Power On:** Plug the steamer into a 110-120V electrical outlet. Press the power button (usually red) to turn the unit on. The indicator light will illuminate.
2. **Heat-Up Time:** Allow approximately 2 minutes for the steamer to heat up and produce steam. You will hear the water boiling and see steam emerging from the nozzle.
3. **Steaming Technique:** Hold the garment taut with one hand and move the steamer slowly up and down over the fabric with the other. Maintain an upright position to ensure continuous steam flow. The 9-foot power cord provides ample reach.
4. **Continuous Steaming:** The 240ml water tank provides up to fifteen minutes of continuous steaming, allowing you to de-wrinkle multiple garments without frequent refills.



Chiffon

Silk

Wool

Cotton

Linen

Nylon

Strong Penetrating Power
Suitable for a Wide Range of Fabrics

Steaming a garment to remove wrinkles.



Instantly Freshen Your Clothes

The steamer quickly freshens clothes, removing wrinkles effectively.

5. FABRIC COMPATIBILITY

The HiLIFE Garment Steamer creates strong penetrating steam suitable for a wide range of fabrics, including but not limited to:

- Chiffon
- Silk
- Wool
- Cotton
- Linen
- Nylon

6. MAINTENANCE & STORAGE

- **Empty Water Tank:** After each use, unplug the steamer and allow it to cool down completely. Once cool, remove the steam head and carefully empty any remaining water from the tank.
- **Prevent Mineral Buildup:** Always use purified or distilled water to minimize mineral deposits. If you notice any mineral buildup, you may clean the tank with a solution of equal parts white vinegar and water, then rinse thoroughly.
- **Cleaning:** Wipe the exterior of the steamer with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- **Storage:** Store the steamer in a cool, dry place, away from direct sunlight and moisture. Ensure the unit is completely dry before storing.

7. TROUBLESHOOTING

- **No Steam or Low Steam:**
 - Check if the water tank is empty or below the minimum level. Refill with purified water.
 - Ensure the steamer has had sufficient time to heat up (approx. 2 minutes).
 - Verify the steam head is securely attached.
- **Water Spitting or Leaking:**
 - Do not overfill the water tank beyond the 'MAX' line.
 - Ensure the steamer is held upright during operation and not tilted excessively.
 - Allow the steamer to fully heat up before use.
- **Product Not Turning On:**
 - Check if the power cord is securely plugged into a working 110-120V outlet.
 - Ensure the power button is pressed firmly.

8. SPECIFICATIONS

Attribute	Detail
Brand	HiLIFE
Model Number	HL7
Color	Blue
Product Dimensions	6.8"L x 5.5"W x 7"H
Item Weight	1.7 Pounds

Style	Handheld
Wattage	700 watts
Voltage	120 Volts
Heat Time	2 minutes
Capacity	240 Milliliters
Manufacturer	Shenzhen Tengben Technology Co., Ltd.

9. WARRANTY & SUPPORT

For warranty information or product support, please refer to the official user guide or contact HiLIFE customer service directly. The user guide can be accessed via the following link: [HiLIFE User Guide \(PDF\)](#)

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Email

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Details

Submit question